

APPENDIX 29-7. INCINERATOR MANAGEMENT PLAN



AGNICO EAGLE

MELIADINE GOLD MINE

Incineration Management Plan

MARCH 2025

VERSION 9

EXECUTIVE SUMMARY

Agnico Eagle Mines Limited (Agnico Eagle) is operating the Meliadine Gold Mine (Mine), located approximately 25 kilometres (km) north of Rankin Inlet, and 80 km southwest of Chesterfield Inlet in the Kivalliq Region of Nunavut.

This document presents the Incineration Management Plan, prepared in accordance with best management practices, Environment and Climate Change Canada's *Technical Document for Batch Waste Incineration*, and guidelines issued by the Nunavut Impact Review Board for the Mine.

Solid waste incinerators and waste oil burners are regulated in Nunavut under the *Nunavut Public Health Act*, the *Nunavut Environmental Protection Act*, and the federal *Environmental Protection Act*. Performance limits for the incinerator at the Mine will be in accordance with the emission guidelines set out by the Canadian Council of Ministers of the Environment. Ash produced from the incineration process will be disposed of in accordance with the *Nunavut Environmental Guideline for Industrial Waste Discharges*.

The Mine is operating its incinerators based on Environment and Climate Change Canada (ECCC)'s *Technical Document for Batch Waste Incineration*. In addition to incinerator technology, the implementation of a waste segregation program is limiting emissions (e.g., dioxins and furans, mercury) from the incinerators.

Two incinerators are used at the Meliadine Mine. The primary incinerator is a typical modern controlled-air, batch, dual chamber incinerator model - ECO 1.75TN 1PVC100L 16-1MS. The secondary incinerator is dual-chamber system that operates under starved -air conditions KETEK CY-100-CA-D incinerator.

Monitoring and testing are conducted for incinerator stack emissions and incinerator ash. Results are part of the Annual Report for the Mine. Agnico Eagle also reports emissions to the environment through ECCC's National Pollutant Release Inventory (NPRI) and Greenhouse Gas Reporting Program (GHGRP).

Section 6 • Waste Management	13
6.1 Approach	13
6.2 Acceptable Waste for Incineration.....	13
6.3 Unacceptable Waste for Incineration	13
6.4 Waste Volumes.....	14
6.4.1 Solid Waste and Incinerator Ash	14
6.4.2 Used Oil and Waste Fuel.....	14
6.5 Waste Incineration Rate	15
Section 7 • Monitoring and Testing.....	16
7.1 Incinerator Emissions Testing.....	16
7.2 Used Oil/Waste Fuel Testing	16
7.3 Ash Testing	16
Section 8 • Reporting	18
8.1 National Pollutant Release Inventory.....	18
8.2 Greenhouse Gas Emissions.....	18
Section 9 • Plan Review and Adaptive Management	19
References 20	
Appendix A • TECHNICAL SPECIFICATIONS OF THE INCINERATOR	22
Appendix B • SECONDARY INCINERATOR DESIGN REPORT	23
Appendix C • TECHNICAL SPECIFICATIONS OF WASTE OIL BURNER	24
Appendix D • REGISTRATION FORM FROM THE NUNAVUT DEPARTMENT OF ENVIRONMENT: USED OIL AND WASTE FUEL APPLIANCE	25

Figures

Figure 1.1 Location of the primary and secondary incinerators at the Meliadine Mine	3
---	----------

Tables

Table 4-1 Emission Regulations for Solid Waste Incinerators	6
Table 4-2 Summary of Used Oil and Waste Fuel Guideline.....	7

Table 4-3 Used Oil Impurity Limit8

Table 6-1 Estimation of Ash over the Life of the Mine 14

Table 7-1 Summary of Incinerator Emissions Testing..... 16

Table 7-2 Environmental Guideline for Industrial Waste Discharges into Municipal Solid Waste and Sewage Treatment Facilities..... 17

DOCUMENT CONTROL

Version	Date	Section	Page	Revision	Author
1	October 2012			First draft of the Incineration Management Plan	John Witteman, Env. Consultant, Agnico Eagle
2	March 2013			DEIS re-submission; rebranding	
3	April 2014	7.4.2	15	Revision made to address review comments and commitments	John Witteman, Env. Consultant, Agnico Eagle
4	April 2015			First version of Supporting Documents for Type A Water Licence Application, submitted to Nunavut Water Board for review	John Witteman, Env. Consultant, Agnico Eagle
5	February 2018			Reviewed internally	Agnico Eagle Environment Dept.
6	February 2019			Reviewed internally (added changes that the construction phase brought and review of the grammatical tense)	Agnico Eagle Environment Dept.
7	February 2022	All		General Update	Agnico Eagle Environment Department
8_NWB	January 2024	A yellow arrow in the right-hand margin indicates where updates have been made		Submitted to Nunavut Water Board as part of the Meliadine Water Licence Amendment.	Permitting Department
8	March 2024	All	1.4, 4.1, 5, 6.4.1, 6.5	General Update Addition of information related to Secondary Incinerator	Agnico Eagle Environment Department
9	March 2025	1		Updated following Approval of the amended Water Licence.	Agnico Eagle Environment Dept
		3.3, 4.2, 5.2		Review of Used Oil and Waste Fuel environmental guidelines.	

ACRONYMS

Agnico Eagle	Agnico Eagle Mines Limited
CCME	Canadian Council of Ministers of the Environment
CEPA	Canadian Environmental Protection Act
CIRNAC	Crown-Indigenous Relations and Northern Affairs Canada
CWS	Canada-Wide Standards
ECCC	Environment and Climate Change Canada
GHGRP	Greenhouse Gas Reporting Program
GN	Government of Nunavut
IMP	Incineration Management Plan
IOL	Inuit Owned Lands
KivIA	Kivalliq Inuit Association
Mine	Meliadine Gold Mine
NIRB	Nunavut Impact Review Board
NPRI	National Pollutant Release Inventory
NWB	Nunavut Water Board

SECTION 1 • INTRODUCTION

Agnico Eagle Mines Ltd. (Agnico Eagle) operates the Meliadine Gold Mine (the Mine) located approximately 25 kilometres (km) north of Rankin Inlet (Figure 1), Nunavut, and 80 km southwest of Chesterfield Inlet in the Kivalliq Region of Nunavut.

The Mine is subject to the terms and conditions of both the amended Project Certificate 006 issued by the Nunavut Impact Review Board (NIRB) in accordance with the Nunavut Land Claims Agreement Article 12.5.12 on March 2, 2022 (NIRB, 2022) and the Amended Water Licence No. 2AM-MEL1631 (the Licence), issued by the Nunavut Water Board (NWB) on October 25, 2024 and approved by the Minister of Northern Affairs on November 22, 2024 (NWB, 2024).

The purpose of the Incineration Management Plan (the Plan) is to provide consolidated information on the specifications, operations, management, monitoring, and reporting of the incinerator process for the Mine. This Plan will be reviewed and updated on a regular basis to reflect changes to the Mine.

1.1 Concordance

This Plan has been developed to be consistent with the guidance provided in the Environment and Climate Change Canada's (ECCC) Technical Document for Batch Waste Incineration (EC, 2018).

1.2 Related documents

Related documents include the following:

- Landfill and Waste Management Plan;
- Hazardous Materials Management Plan;
- Interim Closure and Reclamation Plan; and
- Occupational Health and Safety Plan.

The Incineration Management Plan is part of the Environmental Management and Protection Plan, which provides overarching environmental direction for the Mine.

1.3 Objectives

At the Mine site, all wastes are safely managed from the time they are produced to their final disposal. All wastes are segregated at the mine site and are predominately landfilled, incinerated, or recycled. Used oil burning will be maximized as much as possible using the second chamber of the incinerator. Remaining wastes, including hazardous waste¹, are packaged for shipment to a certified waste management facility for treatment, recycling, and/or disposal.

¹ Please refer to the Hazardous Materials Management Plan for further information on the handling and management of hazardous waste.

Incineration is an essential part of waste management at the mine site. The incineration of acceptable solid waste from the accommodation complex, kitchen, lunch rooms, shops, warehouses, and offices diverts waste from directly reporting to the on-site landfill. It has the advantage of eliminating putrescible waste that could potentially attract wildlife to the landfill, thereby reducing possible dangerous interactions between humans and wildlife.

The objectives of this Plan are summarized as follows:

- 1) To understand the quantity and composition of the waste generated at the mine site, and separate waste acceptable for incineration from waste that is not;
- 2) To operate the batch waste incinerators based on the characteristics and quantity of waste, and to locate them in appropriate buildings away from other site infrastructure;
- 3) To properly maintain the incinerators' functionality;
- 4) To operate the incinerators for optimal combustion, and avoid the formation of dioxins and furans in the combustion process;
- 5) To safely handle and dispose of incinerator residues; and
- 6) To establish a record keeping system for managing the facility and for future reporting.

As a component of the Mine Environmental Management System, the Plan will be updated to ensure that site experience is reflected in the Plan and subsequently communicated to all parties. The Mine Environment Superintendent or designate is responsible for managing and implementing the Incineration Management Plan.

1.4 Incinerators Location

The incinerators are located on the south end of the industrial pad. The primary and secondary incinerators are located next to each other, as shown in Figure 1 below.



Figure 1-1: Location of the primary and secondary incinerators at the Meliadine Mine

SECTION 2 • REGULATORY SETTING

Solid waste incinerators and waste oil burners are regulated in Nunavut under the *Nunavut Public Health Act*, the *Nunavut Environmental Protection Act*, and the federal *Environmental Protection Act*. Various regulations and guidelines under these Acts, as well as guidelines developed by the Canada Council of Ministers of the Environment (CCME), were reviewed in preparing the Plan. They are as follows:

- *Canadian Environmental Protection Act (CEPA)*
 - Schedule 1: List of Toxic Substances
 - *Interprovincial Movement of Hazardous Waste Regulations*
 - *Export and Import of Hazardous Waste and Hazardous Recyclable Material Regulations*
- ECCC Technical Document for Batch Waste Incineration (EC, 2018)
- Canada-Wide Standard for Dioxins and Furans (CCME, 2001a)
- Canada-Wide Standard for Mercury (CCME, 2000)
- *Nunavut Environmental Protection Act*
 - Environmental Guideline for Industrial Waste Discharges into Municipal Solid Waste and Sewage Treatment Facilities (GN, 2011b)
 - Environmental Guideline for the Burning and Incineration of Solid Waste (GN, 2012)
 - Environmental Guideline for Ambient Air Quality (GN, 2011)
 - Environmental Guideline for Mercury-Containing Products and Waste Mercury (GN, 2010)
 - Environmental Guideline for Used Oil and Waste Fuel (GN, 2012)
- *Nunavut Public Health Act*

Performance limits for the incinerators at the Mine will be in accordance with the emission guidelines set out by the CCME: Canada-Wide Standard for Dioxins and Furans (CCME, 2001a), and Canada-Wide Standards for Mercury Emissions (CCME 2000). The CCME Guidelines for dioxins and furans and mercury emissions were adopted by the GN Department of Environment in their Environmental Guideline for the Burning and Incineration of Solid Waste (GN 2012).

The management of used oil is guided in Nunavut through the *Environment Guideline for Used Oil and Waste Fuel* (GN, 2012).

Ash produced from the incineration process will be disposed of in accordance with the Nunavut Environmental Guideline for Industrial Waste Discharges (GN, 2014).

SECTION 3 • BACKGROUND INFORMATION

3.1 Dioxins and Furans

Polychlorinated dibenzo-p-dioxins and polychlorinated dibenzofurans, commonly known as dioxins and furans, are toxic, persistent, and bioaccumulative chemicals. Their presence in the environment results predominantly from human activity. The biggest source of dioxins and furans in Canada is the large-scale burning of municipal and medical waste. Other major sources include:

- the production of iron and steel;
- backyard burning of household waste, especially plastics;
- fuel burning, including diesel fuel and fuel for agricultural purposes and home heating;
- wood burning, especially if the wood has been chemically treated;
- electrical power generation; and
- tobacco smoke.

Due to their environmental persistence and ability to accumulate in biological tissues, dioxins and furans are slated for virtual elimination under the CEPA, the Environment Canada Toxic Substances Management Policy (EC, 2004) and the CCME *Policy Statement for the Management of Toxic Substances* (CCME, 1998).

3.2 Mercury

Mercury is a naturally occurring substance, which can be transformed through biological processes to methyl mercury, a persistent substance which bioaccumulates in the food chain and is particularly toxic to humans and wildlife. Mercury contamination originates from natural and anthropogenic sources, the latter including combustion of waste. Under a variety of regional, national, bi-national, and internal programs, treaties and agreements, mercury is being targeted for emissions reductions consistent with the CCME *Policy Statement for the Management of Toxic Substances* (CCME, 1998), which identifies that mercury shall be managed through its lifecycle to minimize release.

3.3 Used Oil and Waste Fuel

The following definitions are provided in the *Environmental Guideline for Used Oil and Waste Fuel* (GN, 2012).

Used Oil: Engine, turbine and gear lubricating oil, hydraulic and transmission fluid and insulating coolant (i.e. transformer fluid) that is unsuitable for its intended purpose due to the presence of impurities or the loss of original properties, but does not include waste derived from animal or vegetable fat or a petroleum product spilled on land or water.

Waste Fuel: A flammable or combustible petroleum hydrocarbon that is unsuitable for its intended purpose due to the presence of impurities or the loss of original properties, and includes gasoline, diesel and fuel oil, aviation fuel, kerosene and naphtha, but does not include paint, solvent or propane.

SECTION 4 • PERFORMANCE LIMITS

4.1 Incinerators Selection

The Mine selected its incinerators based on Environment and Climate Change Canada's *Technical Document for Batch Waste Incineration*. The primary incinerator for the Mine is a camp waste incinerator (model no. ECO 1.75TN 1PVC100L 16-1MS) from Eco-Waste Solutions. The secondary incinerator is a KETEK CY -1 00 -C A -D incinerator dual-chamber system that operates under starved-air conditions. The incinerators comply with the guidelines listed in Table 4-1, where the maximum emissions are expressed as a concentration in the exhaust gas exiting the facility's stack. The specifications of the primary and secondary incinerators are available in Appendix A and B, respectively. In addition to incinerator technology, the implementation of a waste segregation program limits emissions of dioxins and furans, and mercury from the incinerator.

Table 4-1 Emission Regulations for Solid Waste Incinerators

Emissions	Sector	Guideline (max) ^(a)	Units	Reference
Dioxins and Furans	Municipal Solid Waste ^(b)	80	pg I-TEQ/Rm ³	CCME 2001a
Dioxins and Furans	Sewage Sludge Incineration	80	pg I-TEQ/Rm ³	CCME 2001a
Mercury	Municipal Waste	20	µg/Rm ³	CCME 2000
Mercury	Sewage Sludge Incineration	70	µg/Rm ³	CCME 2000

^(a) Stack concentrations are corrected for 11% oxygen.

^(b) According to the Canada-Wide Standards (CWS), "municipal solid waste" includes any waste that might be disposed of in a non-secure landfill site if not incinerated (i.e., non-hazardous wastes regardless of origin), but does not include "clean" wood waste.

Compliance to these performance limits are confirmed with annual stack testing.

4.2 Used Oil and Waste Fuel

Agnico Eagle will manage used oil and waste fuel according to the *Environmental Guideline for Used Oil and Waste Fuel* (GN, 2012) as presented in Table 4-2.

Table 4-2 Summary of Used Oil and Waste Fuel Guideline

Activity	Summary of Guideline
Disposal	<ul style="list-style-type: none"> • Used oil/Waste fuel will not be disposed of directly into the environment
Storage	<ul style="list-style-type: none"> • Storage is not acceptable for the long-term management of these wastes except under extraordinary circumstances and should be considered as a temporary measure only. • Store used oil and waste fuel in its original container or another container certified by the Canadian Standards Association for this purpose. • Containers should be located so as to enable their physical inspection for damage or leakage and should be protected from the sun, weather and physical damage. • Waste oil/Waste fuel will be stored as per the <i>Hazardous Materials Management Plan</i>
Sampling and Analysis	<ul style="list-style-type: none"> • Used oil/waste fuel will be tested for: <ul style="list-style-type: none"> • Flash point; and • Existence and amount of each impurity Listed in Table 4-3.
Burning	<ul style="list-style-type: none"> • Open burning used oil and waste fuel should be avoided. • Used oil and waste fuel appliances should not be operated on property that is zoned residential. • Waste Oil that exceeds guidelines will not be burned.
Records	<ul style="list-style-type: none"> • The following is recorded in association with the incineration of used oil: <ul style="list-style-type: none"> • Volume of Used oil generated • Volume of used oil incinerated/consumed • Name and Address of person in charge, management or control of the used oil • A summary of maintenance performed on incinerator or processing equipment • The destination of the used oil products shipped from the facility (if any)

Table 4-3 summarizes the maximum level of contaminants in used oil that can be incinerated as stipulated in the *Environmental Guideline for Used Oil and Waste Fuel* (GN, 2012). Under the regulations blending of used oil that exceeds one or more of the criteria listed in Table 4-3 is not allowed.

Table 4-3 Used Oil Impurity Limit

Impurity	Maximum Level Allowed in Used Oil (ppm)
Cadmium	2
Chromium	10
Lead	100
Total Organic Halogens (as Chlorine)	1,000
Polychlorinated Biphenyls	2

4.3 Incinerator Ash

Provided the materials that go into the incinerators are controlled to exclude all hazardous materials, the incinerator ash should be non-hazardous. Even small quantities of hazardous waste, such as batteries, should not be mixed with waste to be incinerated. The purpose of sampling ash is to determine its acceptability for disposal in the landfill, pursuant to the GN Environmental Guidelines for Industrial Discharge (GN, 2011b). No sampling frequency is specified in those guidelines. To ensure compliance with the Guideline parameters, ash will be sampled quarterly by Agnico Eagle. Should an exceedance be measured, an investigation will be undertaken to identify the cause and eliminate the source for this exceedance. Agnico Eagle may increase the testing frequency of the ash following the exceedance. If deemed necessary, the ash will be packaged in drums to be sent to a certified waste management facility for appropriate treatment, recycling, and/or disposal.

SECTION 5 • INCINERATOR SPECIFICATIONS AND OPERATION

The Mine has selected a dual chamber, high-temperature incinerator as the primary incinerator and dual-chamber system that operates under starved-air conditions as the secondary incinerator. The technical specifications are included in Appendix A and B. The primary incinerator is housed inside a building with sufficient floor space to manage all Mine wastes in one convenient location.

On August 17, 2023, a design report was submitted to the NWB for the Secondary Incinerator design report and drawings. The design report was approved by the NWB on September 26, 2023. The secondary incinerator will be housed within its own building, next to the primary incinerator building.

5.1 Incinerator Specifications

Primary Incinerator

Typical modern, controlled-air, batch, dual chamber incinerators are design using the principles of pyrolysis (starved-air burning condition) in the primary chamber and complete oxidation (high temperature, excess oxygen, and sufficient combustion time) in the secondary chamber. The incineration system is a two-stage process. In the first stage, waste is converted to gas in the primary chamber at approximately 650 to 850 degrees Celsius (°C). This process is self fueling until the volume is reduced by 90 %. Gasses from the primary chamber enter the secondary chamber of oxygen-rich and turbulent conditions, which is typically at a higher temperature – around 1,000°C. Combustion is complete after a retention time of about two seconds. The temperature of combustion gases exiting the stack is anticipated to exceed 700°C and to flash cool in the ambient air, thereby leaving little opportunity for the *de novo* synthesis of dioxins/furans. Heat capture is not used on the exhaust gases.

Critical process parameters, such as temperature, air flow, and burner output is computer-controlled to maintain optimal combustion conditions.

For an incinerator capacity suitable for the predicted volumes of waste to be generated at the Mine, the total particulate matter generated is expected to be extremely low. Therefore, dust collection technologies, such as baghouse filters, will not be necessary, as very minor amount of fly ash will be generated. Ash residues generated in the primary chamber are manually removed on a daily basis using a shovel emptied into a metal bin.

Secondary Incinerator

The primary chamber is the first stage of the incinerator where two (2) Becket 2X WIC -2 01 7 70,000 BTU/hr. diesel fired burners are used to increase the temperature of the chamber to ensure that the waste will ignite. To save fuel and reduce pollutants, the burn process becomes self fueling once the chamber reaches the appropriate temperature. This chamber is insulated and has the appropriate refractory to retain the required heat inside the chamber. The primary and secondary chambers are connected by a flame -port. Combustion air is delivered to the secondary chamber through the flame

-port using a blower. The secondary chamber is the second stage of the incinerator where one (1) Becket WIC -3 01 1,600,00 B TU/hr. diesel fired burner is used to maintain the high temperature required to keep the waste ignited and maintain turbulence from the delivery of oxygen by the blower which ensures no black smoke is generated from the system.

The burner controls include a thermostat, relay protection, the option for limited recycle, limited reset, three (3) status lights, valve-on delay/motor-off delay signals, 15-second lockout time option, interrupted and intermittent duty ignition, technician pump priming mode, disable function and a communication port.

Additional information can be found in the Meliadine Secondary Incinerator Design Report and Drawings (Agnico Eagle 2023).

5.1.1 Operation Procedures

General operating procedures for the incinerator include:

1. Sort the waste on the basis of origin and heating value. Food waste and waste that has been in contact with food will have priority for incineration.
2. Mix the waste to ensure a calorific value within the incinerator's specification and to achieve good combustion inside the primary chamber.
3. Observe the start of the burn cycle to ensure the incinerator is operating correctly.
4. The door to the incinerator is only opened after the burn cycle is complete and the unit cooled.
5. The ash is removed from the incinerator before it is charged with the next load of waste to be incinerated.
6. The ash is placed in bins digitated for ash.
7. The ash is disposed of in the on-site landfill. If the concentration of trace metals exceeds the Government of Nunavut's *Environmental Guideline for Industrial Waste Discharges* (GN, 2014), ash will be either packaged and sent to an approved disposal facility or buried in the dry stack tailings.

The system has a sizable front door for easy access to manually load/feed waste into the unit with a front-end loader. The proposed waste streams are layered wherever possible during loading to ensure proper combustion.

5.1.2 Emissions

The incinerators are designed to meet performance limits described in Section 4.1. Good engineering practices will be used to ensure required incineration temperatures and dispersion of gases meet applicable air quality standards/guidelines.

The incinerators stack design incorporates appropriate sampling ports, with caps where necessary, at appropriate locations to allow for stack testing to be undertaken during incinerator operation.

5.1.3 Dust/Odour Control Measures

Modern incinerators are commonly designed such that the non-turbulent atmosphere in the primary burn chamber reduces the formation of particulate matter. Therefore, the need for additional dust and/or odour control measures is not anticipated. Organic/putrescible wastes will be given incineration priority to limit odours.

5.1.4 Staffing and Equipment

The computerized incinerator typically requires one operator to interact with the equipment for approximately 1 to 3 hours per day, largely for ash removal, loading, and start-up. Operators are not typically required to be in attendance during the rest of the operation, as it is normally a fully automated process.

The Ecowaste (primary) incinerator is designed, installed, and operated so that the operators are not exposed to high temperatures during loading or ash removal due to complete cool down after the burn cycle. Also, the waste is not allowed to combust until the chamber is sealed thus isolating the worker from smoke and high temperatures.

The Ketek (secondary) incinerator can be loaded before burn cycle on startup but also during its burn cycle. Ashes are removed after cool down cycle for the safety of the operator and the proper burn of the waste. A protection barricade prevent operator from risk while stirring the ashes.

5.1.5 Inspections

Weekly inspections will be undertaken of the incinerator building for cleanliness and the proper management of waste delivered to the facility. The Environment Department will carry out the inspections. Weekly preventive maintenance is done including the review of the incinerators' operating parameters to ensure effective operation.

5.2 Used Oil and Waste Fuel

The incinerator is able to efficiently burn used oil and waste fuel. A quantity of about 365,000 litres of used oil and waste fuel may be incinerated per year. The quantity of waste fuel is expected to be small and will be dependent on the adherence to standard operating procedures. The goal is to avoid practices that could result in waste fuel. The principal sources of the used oil will be from oil changes on the mining equipment and light vehicles, as well as oil changes to mechanical gearboxes within the mill. Typically used oil and waste fuel furnaces include a storage tank and a filter to recover sludge prior to burning. Sludge collected in the filters will be drummed and shipped, as needed, to a certified waste management facility for treatment, recycling, and/or disposal.

5.3 Shipboard Incinerator

Refer to the Shipping Management Plan.

5.4 Closure Plan

In accordance with the Interim Closure and Reclamation Plan, salvageable buildings and surface structures, including the incinerator and waste management buildings, will be dismantled and demobilized from the site.

SECTION 6 • WASTE MANAGEMENT

One method of waste reduction is by implementing purchasing policies that focus on reduced packaging. Reduce, reuse, and recycle initiatives as well as the waste segregation program at the Mine as per the Landfill and Waste Management Plan minimizes the quantity of waste incinerated or directed to the landfill.

6.1 Approach

A waste segregation program is implemented at the site. This allows materials that are unsuitable for incineration to be either landfilled on-site or shipped off-site to a certified waste management facility for treatment, recycling, and/or disposal.

6.2 Acceptable Waste for Incineration

Acceptable wastes for incineration will include the following:

- organic matter including food;
- food containers and wrappings, including plastics that are contaminated by food;
- medical waste from the Health Care Station;
- paper, cardboard, and the like;
- hydrocarbon spill absorbents;
- plastic and Styrofoam except plastic containing chlorine;
- dead animals; and
- used oils and waste fuel.

6.3 Unacceptable Waste for Incineration

Materials that are not listed above would be unacceptable for incineration. These materials include, but are not limited to:

- chlorinated plastics;
- inert materials, such as concrete, bricks, ceramics, ash, asbestos, drywall;
- bulky materials such as machinery parts or large metal goods such as appliances;
- radioactive materials, such as smoke detectors and laboratory wastes;
- potentially explosive materials, such as propane tanks, other pressurized vessels, unused or ineffective explosives;
- hazardous materials such as organic chemicals (pesticides), other toxic substances (arsenic, cyanide);
- electronics;
- batteries;
- vehicles and machinery;
- fluorescent light bulbs;

- whole tires;
- paint and solvents;
- any materials containing mercury, lead, and cadmium;
- used oil or waste fuel that exceeds the maximum impurity limits for parameters listed in Table 4-3; and
- propane.

6.4 Waste Volumes

6.4.1 Solid Waste and Incinerator Ash

The number of people working on-site and the activities occurring at the time have a direct bearing on the volume of waste destined for the landfill, the incinerator, and the amount removed from waste streams for reuse and recycling.

It has been assumed that each person will produce 1 tonne of refuse per year². Mean camp populations of 680 during operation and 50 during closure have been estimated. Fifty percent of the refuse by weight can be incinerated, approximately 30% of incinerated material by mass is converted into ash, thereby reducing the mass of waste by approximately 70 %. Table 6-1 estimates the annual tonnes of ash resulting from incineration for each project phase, based on the number of people on site, and cumulatively over the life of mine.

Table 6-1 Estimation of Ash over the Life of the Mine

Project Phase	Workers On-Site	Annual Tonnes of Waste Incinerated	Annual Tonnes of Ash	Numbers of Years	Cumulative Tonnes of Ash
Construction	200	100	30	4	120
Operation	680	340	102	8	816
Closure	50	25	7.5	3	22.5
Total					958.5

6.4.2 Used Oil and Waste Fuel

Approximately 365,000 litres of used oil may be used in the primary incinerator for burning the waste. This is based on the maximum capacity of the incinerator burn rate which is approximately 1000 litres/day. The quantity of waste fuel is expected to be small but may vary between years.

² Environment and Climate Change Canada's "State of the Environment InfoBase", Environmental Indicator Series 2003 (<http://www.ec.gc.ca>), indicates that the per capita non-hazardous solid waste generation in 2000 for Canada was almost 1 tonne per person per year.

6.5 Waste Incineration Rate

The primary incinerator has an approximate incineration capacity of 1,560 kilogram per day. These wastes are primarily associated with food and small amount of medical waste.

The secondary incinerator contributes to Meliadine's overall waste management strategy by maintaining continuity of the waste burns when there is maintenance work being conducted on the site's primary incinerator and also by providing additional capacity of waste material that can be burnt, reducing the likelihood of incinerable waste backlog.

SECTION 7 • MONITORING AND TESTING

The following presents the monitoring and testing plan for the incinerator.

7.1 Incinerator Emissions Testing

The incinerators stack design incorporates appropriate sampling ports at appropriate locations, in a right angle configuration, to allow for stack testing to be undertaken during incinerator operation. Table 7-1 summarizes the frequency of testing that will be completed as per relevant guidelines (see also CCME, 2001b).

Table 7-1 Summary of Incinerator Emissions Testing

	Frequency	Number of Test Required	Reference
Dioxins and Furans	Annual	3	CCME 2001a
Mercury	Annual	3	CCME 2000

7.2 Used Oil/Waste Fuel Testing

No sampling frequency for waste oil is specified in the *Environmental Guideline for Used Oil and Waste Fuel* (GN, 2012). To ensure compliance with the Guideline parameters, Agnico Eagle will sample the waste oil feedstock twice a year. Waste oil that does not meet the regulation impurity limits is drummed and shipped off site as hazmat to a re-refining facility or licensed disposal facility. Agnico Eagle may increase the testing frequency of the waste oil if any exceedance to *Environmental Guideline for Used Oil and Waste Fuel* (GN, 2012).

7.3 Ash Testing

An ash testing protocol is implemented on site to ensure that the incinerator ash is suitable for disposal in the landfill. Ash is disposed of and then covered immediately to prevent mobilization.

Ash samples are collected and tested quarterly and compared to the regulatory requirements as outlined in Table 7-2.

If monitoring indicates the ash is above the guidelines and not suitable for landfilling, an investigation will be undertaken to identify the cause and eliminate the source for the exceedance. If deemed necessary, the ash will be packaged in drums and sent to a certified waste management facility for treatment, recycling, and/or disposal.

Table 7-2 Environmental Guideline for Industrial Waste Discharges into Municipal Solid Waste and Sewage Treatment Facilities

Parameter	Maximum Concentration (mg/L)
Arsenic	2.5
Barium	100
Cadmium	0.5
Chromium	5
Lead	5
Mercury	0.1
Selenium	1
Silver	5
Zinc	5

SECTION 8 • REPORTING

As part of the annual reporting, results from periodic stack emissions and ash monitoring, will be provided.

8.1 National Pollutant Release Inventory

The National Pollutant Release Inventory (NPRI) is a Canadian database containing information on the annual on-site release of specific substances to the air, water, and land from industrial and institutional sources (EC, 2012). The NPRI provides a list of tracked substances and requirements for reporting incinerator emissions. In addition, there are certain substances that may require reporting depending on the quantity of incinerator emissions. Whether or not reporting is necessary will depend on results of periodic stack emission testing data and the quantity of annual emission calculated with emissions factors.

Agnico Eagle Meliadine reports emissions to the NPRI program every year as required.

8.2 Greenhouse Gas Emissions

Agnico Eagle is committed to reporting greenhouse gas emissions in support of Canada's Greenhouse Gas Reporting Program (GHGRP).

SECTION 9 • PLAN REVIEW AND ADAPTIVE MANAGEMENT

The Plan is updated regularly to reflect the operating conditions at the Mine during construction, operation, and closure. The Plan is reviewed annually, and an updated version will be produced as needed.

REFERENCES

- Agnico Eagle (Agnico Eagle Mines Limited). (2014). Meliadine Gold Project, Nunavut. Final Environmental Impact Statement. Submitted to the Nunavut Impact Review Board. April 2014.
- CCME (Canadian Council of Ministers of the Environment). (1998). Policy Statement for the Management of Toxic Substances. Available on-line:
http://www.ccme.ca/assets/pdf/toxics_policy_e.pdf
- CCME. (2000). Canada-Wide Standards for Mercury.
- CCME. (2001a). Canada-Wide Standards for Dioxins and Furans.
- CCME. (2001b). Canada-Wide Standard for Waste Incineration – Stack Testing Requirements.
- EC. (Environment Canada). 2004. Toxic Substances Management Policy (TSMP).
- EC. (2010). Technical Document for Batch Waste Incineration.
- EC. (2012). National Pollutant Release Inventory (NPRI).
- GN (Government of Nunavut). (2010). Environmental Guideline for Mercury-Containing Products and Waste Mercury. Government of Nunavut, Department of Environment, Environmental Protection Service.
- GN. (2011). Environmental Guideline for Ambient Air Quality.
- GN. (2011b). Environmental Guidelines for Industrial Waste Discharges into Municipal Solid Waste and Sewage Treatment Facilities.
- GN. (2012). Environment Guideline for Used Oil and Waste Fuel. Government of Nunavut, Department of Environment, Environmental Protection Service
- GN. (2012). Environmental Guideline for the Burning and Incineration of Solid Waste. Government of Nunavut, Department of Environment.
- GN. (2014). Environmental Guideline for Industrial Waste Discharges into Municipal Solid Waste and Sewage Treatment Facilities. Government of Nunavut, Department of Environment, Environmental Protection Service.
- Minister of Justice. (1999). CEPA (Canadian Environment Protection Act). Available on-line:
<http://laws-lois.justice.gc.ca/PDF/C-15.31.pdf>
- NIRB (Nunavut Impact Review Board). (2012). Guidelines for the Preparation of an Environmental Impact Statement for Agnico-Eagle Mines Ltd. Meliadine Project (NIRB File No. 11MN034)

NWT. (2012). Used Oil and Waste Fuel Management Regulations, Department of Environment, Government of Nunavut.

APPENDIX A • TECHNICAL SPECIFICATIONS OF THE INCINERATOR

Meliadine Incinerator ECO 1.75TN 1PVC100L 16-1MS

CORPORATE OFFICE

Corporate Office:

Eco Waste Solutions

5195 Harvester Road, Unit 14

Burlington, ON, Canada L7L 6E9

Tel: 905-634-7022 Fax: 905-634-0831

Email: info@ecosolutions.com

Web: www.ecosolutions.com



Corporate Head Office

Eco Waste Solutions	14-5195 Harvester Road Burlington, Ontario, Canada L7L 6E9
Phone	(905) 634-7022
Toll Free	1-866-326-2876
Fax	(905) 634-0831
E-Mail	info@ecosolutions.com
Ask for/Address to	Customer Service Manager
Reference	ECO 1.75TN 1PVC100L

Table of Contents

Section 1 Health & Safety Precautions.....	4
Section 2 General Description.....	7
Section 3 Photos of the Incinerator.....	18
Section 4 Assembly & Installation Instructions.....	27
Section 5 Operating Instructions.....	45
Section 6 Maintenance Instructions.....	80
Section 7 Spare Parts Lists.....	123

SECTION 1

HEALTH & SAFETY PRECAUTIONS

Health and Safety Precautions

This machine has a number of energy sources:

- e.g. Electricity
- Heavy mechanical parts which may move due to gravity
- High Temperature
- Explosive Gases
- Flammable Liquids



- **THE INCINERATOR HAS THE POWER TO CAUSE SERIOUS INJURY OR DEATH**
- **KEEP CLEAR OF ANY MOVING PARTS AT ALL TIMES**
- **BEFORE STARTING THE CYCLE ENSURE THAT ALL PERSONNEL ARE CLEAR OF THE INCINERATOR**
- **DO NOT ATTEMPT TO START OR OPERATE THIS EQUIPMENT UNTIL THIS MANUAL IS READ THOROUGHLY AND IS UNDERSTOOD.**
- **RESPONSIBILITY FOR THE SAFE OPERATION AND MAINTENANCE OF THE EQUIPMENT SUPPLIED RESTS SOLELY ON THOSE OPERATING IT.**

OBEY THE FOLLOWING SAFETY INSTRUCTIONS:



A qualified person is a person whom the owner of the equipment deems as having the required experience, training and skills to perform the required work.

1. Keep the electrical panel doors closed at all times except when doing electrical troubleshooting.
2. Allow only qualified people to perform maintenance and troubleshooting on the machine.
3. Open and lockout the Main Disconnect Switch on the electrical control panel while working on the machine.
4. Do not bypass or tie down any of the door safety switches.
5. Do not open any of the doors while the Primary or Secondary Chambers are above 90°C
6. Do not enter the chamber unless the Emergency Stop Button is pushed in
7. When opening or closing the chamber door keep clear of the door and ensure that the path for the door is clear.
8. Secure the chamber door when it is open so it cannot move accidentally.
9. Immediately correct any fuel leaks.
10. Do not fill the Primary Chamber more than $\frac{3}{4}$ full. Overfilling can result in poor burning and damage to the oxidizer.
11. Use proper tools, wear goggles, dust mask and gloves while loading and cleaning the oxidizer.
12. This unit is a confined space. Follow the safety rules for working in a confined space.
13. Ensure that all personnel who are going to operate or work on the machine read and understand the above points and are trained in the operation and maintenance of the machine.

SECTION 2

GENERAL DESCRIPTION

General Description - Thermal Oxidation Concept

The **ECO 1.75 TN 1PVC100L Incinerator system** consists of a **Primary Chamber** and a **Secondary Chamber** (also known as the Afterburner). Both chambers are vessels constructed of steel with a special insulating liner known as refractory.

The **Primary Chamber** has **Hydraulic Roof Lifters** installed for loading of the waste material from the top of the **Primary Chamber** and the front door is used for the removal of residual ash.

The waste material is loaded into the **Primary Chamber** until it is $\frac{3}{4}$ full. Once $\frac{3}{4}$ full the **Primary Chamber** is sealed and the combustion cycle begins. This type of system is known as *batch-fed* processing.

Primary Chamber

In the first stage, a burner is used to elevate the temperature of the **Primary Chamber** to ignite the waste. Once the **Primary Chamber** reaches a temperature of approximately 650-850°C, the burn process becomes self-fuelling and the burner will shut off. To save fuel and control temperatures, only when the energy contained within the waste is depleted, will the burner periodically turn on. At these operating temperatures, waste is allowed to fully combust and is rendered sterile.

The **Primary Chamber** operates under *controlled temperature* conditions. The amount of heat released, from the burning of the waste, is controlled by limiting the air into the **Primary Chamber** to less than what is required to complete combustion. This is described as *starved air* conditions. With controlled air and temperature the waste is dried, heated and burned thereby releasing moisture and volatile components. The non-volatile, combustible portion of the waste is burned in the **Primary Chamber** to provide heat while the non-combustible portion accumulates as ash.

In the end, the waste volume is reduced by over 90%. Independent tests have shown that the residual ash is non-hazardous, non-leaching and essentially inert. After enduring the combustion process, metals and glass remain intact. Preservation of metals and glass not only protects the refractory lining from damage caused by melted and fused metals and glass, but also allows for post-combustion recycling where possible.

Remaining in the **Primary Chamber** are non-combustibles, such as metal and glass, and carbonaceous residue. The incoming air, subjecting the non-combustibles to high temperatures, further burns the carbonaceous residue. The result is an oxidized ash product.

Controlling the gas velocity through the system is an important factor in limiting pollution. The gases flowing from the **Primary Chamber** are a result of the interaction of the air with the waste during the controlled burning process. Both the quantity and velocity of the gas product vary according to chamber temperature conditions and the type of waste being burned. The integrated controls for the **Primary** and **Secondary Chamber** act to minimize peaking activity thus controlling pollution automatically.

The combustion gases released in the **Primary Chamber** then pass into the **Secondary Chamber** through a turbulent mixing zone where ignition takes place and additional combustion air is provided to complete the burning process.

Secondary Chamber

As waste burns in the **Primary Chamber**, gases containing the products of combustion enter the high temperature zone of the **Secondary Chamber** for cleansing. The **Secondary Chamber** is sized to retain the incoming gases for a minimum of 2 seconds at 1000°C. This chamber utilizes a high output, fully modulating dual fuel (diesel & waste oil) burner to maintain the required temperature (even in the absence of energy input from the first stage which is important when processing wet or low energy waste). This stage employs a large blower, tightly controlled by the control system using a variable frequency drive on the motor. The blower creates the turbulence required to mix the gases and oxygenate them. This fosters the high efficiency combustion required to break hydrocarbon chains into carbon dioxide and water vapour.

The **Secondary Chamber Blower** air is introduced into the **Secondary Chamber** by an air ring manifold that surrounds the **Secondary Chamber**. The manifold has small air jets called tweeters that open into the **Secondary Chamber** at the side walls and create a powerful vortex of excess air to mix the incoming gases and ensure complete combustion. The flow of air is tightly managed by the control system using a Variable Frequency Drive (VFD) by controlling the speed of the fan and modulating motors on the blower inlet dampers.

The **Secondary Chamber Blower** is extremely important as it creates the turbulence required to mix the gases and oxygenate them. This fosters the high efficiency combustion required to break hydrocarbon chains into carbon dioxide and water vapour. It also acts to cool the **Primary Chamber** and prevent temperature overruns.

The **Secondary Chamber** burner is a high output burner and its output is self modulated over a broad range for very precise temperature control.

The **Secondary Chamber** is sized to allow two seconds of retention time. This is the time that the gases from the **Primary Chamber** are retained in the **Secondary Chamber** before they exit to the next stage. Two seconds of retention is considered to be ideal to destroy any harmful organic hydrocarbons produced from the **Primary Chamber**.

Main Control Panel

There is one **Main Control Panel** that controls all of the interconnecting modules. The Operator has one simple **Human Machine Interface (HMI)** to start the equipment, view system status and change control settings if required. The system utilizes a PLC (programmable logic controller) to automate its functions. All critical process parameters such as temperature, combustion airflow and burner output are operated using EWS' patented system control program to maintain optimal combustion and air pollution abatement.

Protecting the Environment

Why Incinerate?

As society becomes more environmentally conscious, environmental regulations on the proper disposal of solid waste have become more stringent. As a result, incineration has become an environmentally responsible and socially acceptable alternative for handling waste at the point of need. However, incineration does not eliminate the need to landfill waste but it does reduce the amount of waste that must be placed in landfills.

Primary advantages of incineration are:

- It greatly reduces the weight and volume of waste material that must be disposed of in landfills
- It destroys organic materials that may be harmful or that may be degradable to harmful materials in landfills
- The incinerator sterilizes the waste; that is, the high temperatures in incinerators can destroy any pathogens that may be in infectious waste materials
- The incinerator destroys animal or human pathological wastes that the general public finds objectionable to handle or see.

Environmental Concerns

The general public will not accept incineration as an option for treating waste of any kind, if they do not believe that it is safe environmentally. The primary concerns are about air pollutants produced by the incinerator and the toxicity of the residual ash. This section will present some of the terminology that is important to understanding these concerns. The remainder of the manual will describe how an incineration system can be operated and maintained in a way that keeps environmental releases at an acceptable level.

Air Pollutants of Concern

Particulate matter may be defined as fine liquid or solid matter such as dust, smoke, mist, or fumes found in the gaseous emissions from the incinerator. Particulate matter emissions may have a dark or light color. Particulate matter emissions can be described in terms of opacity. Opacity is the degree to which light is obscured by a polluted gas (a clear window has 0 percent opacity while black paper has 100 percent opacity). Opacity may be measured with the naked eye or using an opacity monitor. Particulate matter is a problem because it can cause or aggravate respiratory problems in humans. It also creates aesthetic problems since it is readily noticed and is a nuisance because of soiling of exposed surfaces on houses and cars.

Hydrochloric (HCl) acid is generated when polyvinyl chloride (PVC) plastic (usually clear plastic) material is burned in the incinerator. The appearance of a white plume or cloud a short distance above the stack indicates that HCl is condensing. The major concerns about HCl are that it causes respiratory problems in humans, contributes to acid rain problems, and causes material damage to metals and concrete.

Toxic metals include cadmium, arsenic, beryllium, chromium, nickel, lead, and mercury. These metals may be found in municipal wastes. These metals are known to be hazardous to human health.

Organic compounds are compounds that contain primarily carbon and hydrogen and may also contain other elements such as oxygen, nitrogen, and chlorine in smaller amounts. Some organic compounds are known to cause or are suspected of causing cancer and are considered hazardous air pollutants. The public's primary concern is related to dioxin and furan emissions, but other organic compounds such as benzene and vinyl chloride may be emitted.

Carbon Monoxide (CO) also is generated during combustion if the combustor is not operated properly. (Your automobile generates some amount of CO.) CO is toxic to humans if concentrations are high enough, and it also is an indicator of combustion quality.

Solid Waste Ash Quality

One of the major objectives of incineration is to generate a high quality ash for land disposal. All pathogens should be destroyed, and almost all organic material should be completely burned. Ideally, no large chunks of unburned waste material (other than metals or glass) should remain in the waste. A measure of ash quality is "burnout," which is the percentage of organic material remaining in the waste. For example, a burnout of 95 percent means that the ash can contain only 5 percent organics. Adequately burned and quenched ash may be disposed of in a sanitary (municipal) landfill. The ash should be stored in covered containers or kept wet prior to transport to the landfill to prevent 'fugitive \ emissions.' Individual landfills may have requirements that must be followed in order for your waste to be accepted. You should familiarize yourself with these requirements to prevent refusal of the waste.

The Operator – Your Role


It is the operator's role and responsibility to protect the environment by:

- 1 Complying with all emission limits and operating practices specified in the permit to operate.
- 2 Minimizing emissions of particulate matter, HCl, toxic metals, carbon monoxide, and organic compounds through proper incineration;
- 3 Operating the incinerator to generate high quality ash that is sterile and can be disposed of in landfills;
- 4 Minimizing particulate matter emissions from ash handling;
- 5 Disposing of ash properly by sending it to appropriate disposal sites; and
- 6 Performing the regular maintenance inspections to catch any operational problems early.

Basic Combustion Principles

The Combustion Process

Combustion of Municipal Solid Waste (MSW) is a chemical reaction. In the incinerator, organic materials and oxygen react rapidly and violently to produce combustion gases and energy in the form of heat and light.



For the reaction to begin and to keep going, all three elements - organic material, oxygen, and heat-must be present. The organic material used in the reaction comes from two sources, waste and auxiliary fuel. Some organic material is contained in most solid waste types. Depending on the fraction of organics and the specific organic composition, the waste may be adequate to sustain combustion. Auxiliary fuel may be used to maintain combustion if the waste material does not contain enough organic material to maintain high temperatures. The combustion reaction between the organic material and oxygen that causes the organics to burn will occur only after the temperature of the organic material is raised to the point that combustion can begin.

Energy in the form of heat is required to raise the temperatures of the incinerator chamber and organic material and O₂. This energy usually is supplied by the auxiliary fuel burners.

Rate of Combustion Air

The oxygen needed for the combustion reaction is supplied by the ambient combustion air. Combustion air is supplied to the combustion chambers through air ports by natural draft. In general, this air contains about 21 percent oxygen (O₂) and 79 percent nitrogen (N₂), so about 21 percent of the total combustion air fed to the incinerator is oxygen that is available to react with the organic material in the waste and fuel. The nitrogen passes through the chamber mostly unreacted; some nitrogen oxides are formed.

Oxygen Reaction

Solid waste contains two types of organic materials

1. Volatile Matter
2. Fixed Carbon

These two types of materials are involved in distinct types of combustion reactions, and the operating variables that control the two types of reaction are different.

Volatile matter is that portion of the waste that is vaporized (or evaporated) when the waste is heated. Combustion occurs after the material becomes a gas. The combustion variables that influence this reaction are gas temperature, residence time, and mixing.

- A minimum temperature is needed to start and sustain the chemical reaction.
- Residence time is the length of time, generally measured in seconds that the combustion gas spends in the high temperature combustion chamber. The residence time must be long enough for the reaction to be completed before it leaves the high temperature zone.
- Turbulent mixing of the volatile matter and combustion air is required to ensure that the organic material and oxygen are well mixed.

Fixed carbon is the nonvolatile organic portion of the waste. The combustion reaction is a solid-phase reaction that occurs primarily in the waste bed (although some materials may burn in suspension). Key operating parameters are bed temperature, solids retention time, and mechanical turbulence in the bed.

- The solids retention time is the length of time that the waste bed remains in the Primary Chamber.
- Mechanical turbulence of the bed is needed to expose all the solid waste to oxygen for complete burnout. Without mechanical turbulence, the ash formed during combustion can cover the unburned waste and prevent the oxygen necessary for combustion from contacting the waste.

Products of complete combustion are:

- Carbon dioxide
- Water

One example of volatile waste is backyard charcoal grill with starting fluid. The starting fluid is highly volatile. When put on the charcoal and ignited with a match, it rapidly volatilizes and burns. The charcoal contains less volatile matter and primarily burns slowly as a fixed carbon bed.

Operating Factors Related to Combustion

The three operating factors that have the greatest effects on the combustion reaction are:

- Combustion airflow rate and distribution,
- Operating temperatures, and
- Waste feed rate and characteristics.

These three factors are all related. Controlling them controls the combustion reaction.

Stoichiometric Air

In the chemical reaction between organic materials and oxygen, the amount of oxygen required under ideal or "perfect" conditions to burn all of the organic materials with no oxygen left over is called the stoichiometric (or theoretical) oxygen level. The amount of combustion air associated with that oxygen level is called the stoichiometric air level. At stoichiometric air level the combustion gas would contain no oxygen because it would all be used in the combustion reaction.

Substoichiometric Air


Airflows less than those required at stoichiometric levels are called deficient air or substoichiometric starved-air levels. Under starved-air conditions, the combustion gas would again contain no oxygen, but organics also would remain because combustion is not complete.

Excess Air

Air flows greater than those required at stoichiometric levels are called excess-air levels. Typically an incinerator operates with an overall 140 to 200 percent excess air level. That is, the incinerator operates with one and one-half to two times more air than required at stoichiometric levels. Excess air is used to assure that enough oxygen is available for complete combustion.

Control of Temperature as a Function of Air Level

Maximum combustion temperatures are always attained at stoichiometric conditions. As the amount of excess air is increased above the stoichiometric point, the temperature in the incinerator drops because energy is used to heat the combustion air. If the amount of combustion air is too great, the temperature drops below "good combustion temperature," and undesirable combustion products are generated as a result of incomplete combustion. As the amount of excess air is decreased, the combustion temperature increases until it becomes maximum at the stoichiometric point. Below the stoichiometric point, the temperature decreases because complete combustion has not occurred.



CONTROL OF TEMPERATURE AS A FUNCTION OF EXCESS AIR

The relationship of how combustion air level can affect temperature has just been shown. Temperature also plays an important role in the combustion of waste. Temperatures need to be maintained at levels high enough to ensure pathogen destruction and to sustain the combustion reaction. However, temperatures that are too high also cause problems. Continuous exposure of the combustor refractory to high temperatures is generally not desirable because it can cause the ash to fuse and can cause damage to the refractory.

Waste Characteristics

The primary characteristics of the waste that affect the combustion reaction are:

- The heating value
- The moisture content
- The chlorine content

Different wastes have different heating values and moisture contents. They will affect the combustion process.

The HEATING VALUE of a waste is a measure of the energy released when the waste is burned. It is measured in units of Btu/lb (J/kg). A heating value of about 5,000 Btu/lb (11.6×10^6 J/kg) or greater is needed to sustain combustion. Wastes with lower heating values can be burned but they will not maintain adequate temperature without the addition of auxiliary fuel. The heating value of the waste can be used to calculate total heat input to the incinerator where:

Heat Input (Btu/h) = Feed Rate (lb/h) x Heating Value (Btu/lb)

Heat input to the incinerator will affect temperature. More heat input yields higher temperature. Heat input also will affect air requirements; more air is required (1 SCF/100 Btu).

MOISTURE is evaporated from the waste as the temperature of the waste is raised in the combustion chamber. It passes through the incinerator, unchanged, as water vapor. Evaporation of moisture uses energy and reduces the temperature in the combustion chamber.

CHLORINE in plastics or solvents in the waste feed will react to form hydrochloric acid (HCl). This HCl can be an emission problem. It can create corrosion problems of the equipment downstream from the incinerator.

The heating value (Btu value) and moisture varies widely. Compare plastics (high Btu, no moisture) to beddings, shavings, etc. to anatomical.

Summary of Key Operation Factors Affecting Combustion

- 1 Key factors are interrelated.
- 2 Air quality/distribution
- 3 Sufficient air for complete reaction
- 4 Distributed to promote mixing
- 5 Mixing
- 6 Assure contact of oxygen and organics
- 7 Temperature
- 8 High enough to sustain combustion
- 9 High enough to have complete reaction
- 10 Residence/retention time
- 11 Sufficient time to allow reaction to complete

Waste Characteristics are also important

- 12 Heating value
- 13 Measure of energy released

- 14 Heat input determines air required
- 15 Moisture content
- 16 Requires energy to vaporize water
- 17 Chlorine content
- 18 Affects HCl emissions

This summarizes the key parameters affecting combustion.

Products of Combustion Reaction


Complete Combustion

The primary products of waste incineration are:

- Combustion gases
- Solid residue (ash)
- Energy

The primary objectives of the combustion process are to generate an ash residue that is sterile (free of pathogens) and does not contain unburned, recognizable wastes; and to minimize air pollutants in the combustion gas stream.

The organic materials that enter the incinerator with the waste and fuel are primarily made up of carbon, hydrogen, and oxygen. Ideally, these organic materials react with oxygen in the combustion gas to form carbon dioxide and water vapor. The chemical reaction for this ideal situation is



This ideal reaction represents complete combustion.

Incomplete Combustion

However, this ideal reaction does not occur in operating waste combustion systems. Factors that lead to a less than ideal reaction are poor mixing, too little combustion air, and low temperatures. Under those conditions products of incomplete combustion are emitted with the stack gases. The most common product of incomplete combustion is CO. Another product of incomplete combustion that often is emitted under poor mixing conditions or high temperature, low excess air conditions, is elemental carbon (or soot). The soot particles are very fine and generally result in high opacity at the combustion stack. Other products of incomplete combustion that cause concern because of their health impacts are hazardous organic compounds such as benzene, dioxins, and furans. Although these compounds are not found in the waste, under incomplete combustion conditions they can be formed as intermediate combustion products.

The waste feed also includes inorganic materials; generally, they are not involved in the combustion reaction. The inorganic materials in the waste feed (ash) are either retained in the ash or are emitted as particulate matter in the combustion gas. Air velocities in the combustion bed are controlled to reduce the amount of inorganic material entrained (picked up by) the combustion gas and emitted with the combustion gas. If combustion is not complete, organics

will remain in ash; this is typical...it is atypical to have 100 percent combustion of ash bed. Under poor conditions (low temperature, low turbulence in ash bed) may have pathogens remaining in ash; i.e., may not sterilize ash.

Combustion Indicators

The information presented in the above section suggests that the following indicators can be used to monitor combustion quality.

Opacity

The opacity of the combustion gas stream is a measure of the degree to which the stack gas plume blocks light.

- High opacities indicate high emissions.
- Opacity is primarily caused by noncombustible ash or uncombusted carbon (soot) in the flue gas.
- High opacities can indicate poor mixing or low levels of combustion air.
- High opacities also may be generated by high levels of HCl emissions or poor burner operation in the secondary chamber.

If a large amount of water vapor is present in the combustion gas, the water can condense when it cools as it leaves the stack forming a dense white "steam plume." This is not an indicator of poor combustion and should not be confused with a black or white smoke plume caused by soot or acid gases. Opacity can be visually determined by a person or measured by an instrument.

Other indicators which provide information about combustion conditions are measurements of the combustion gas oxygen and CO levels. However, these measurements require instruments and most facilities do not have those instruments.

Ash Quality

Visual appearance of ash can be an indicator of combustion problems. If an incinerator is operating properly, little organic material will remain in the ash. Whitish gray ash indicates better burnout and less carbon than black. The extent of organics combustion can be measured by the quantity of combustible materials remaining in the ash. Noted increases in combustibles in the ash indicate a combustion problem which may include bed temperatures that are too low, improper distribution of combustion air in the bed, or insufficient waste retention times.

SECTION 3

PHOTOS OF THE INCINERATOR

NOTE some of these are sample photos and may not depict the actual Incinerator components

Primary (right) & Secondary (left) Chambers




NOTE Stack sections and breech have not been installed.


Primary Chamber Access Door View



Primary Chamber Interior View (sample picture)



Floor and grate detail



Secondary Chamber Door View



Secondary Chamber / T-section View



Primary Chamber Blower



Secondary Chamber Blower



Adjustable Damper and Modutrol Motor



Primary Chamber Burner



NOTE Burner is shown without cover installed.

Diesel Tank (4,500lt)



Secondary Chamber Burner



Waste Oil Tank (5,000lt)



Main Control Panel



Thermocouple, Viewport and Limit Switch



T-Stack and Stack Sections



Spark Arrestor



SECTION 4

ASSEMBLY & INSTALLATION INSTRUCTIONS

General Assembly and Installation Overview

The incinerator is factory pre-assembled to ensure proper fit then shipped disassembled. On-site assembly by certified trade's people is required. Trades people (Riggers, Mechanical Contractors, Millwrights, Electricians, Gas Fitters, etc) are to be arranged by Purchaser and/or Contractor.

This is a **general overview**, therefore, project specific details must still be considered. Please refer to relevant data and drawings supplied by EWS.

Purchaser/Contractor Responsibilities

These responsibilities include, but are not limited to, the following:

1. Ensure all concrete and structural steelwork, as may be required, is adequate to support the incinerator and associated equipment. The Purchaser/Contractor is responsible for all concrete design such as slab thickness, footing depths and dimensions and any placement reinforcement so as to be consistent with all applicable building codes.
2. Supply of any anchor bolts when applicable.
3. Provide all utility services to the equipment including fuel, electrical, water, air, etc, as may be required.
4. Provide adequate air makeup to the incinerator room through forced air circulation blowers, air intakes and/or opened louvers to avoid the creation of negative pressures within the building.
5. Observe caution in the selection of materials and coating of building walls or other structural components to the incinerator area giving due consideration to high-localized temperatures of the incinerator.
6. Provide all external thermal insulation when required on steam piping, water piping, etc.

NOTE External thermal insulation should never be applied to any surface of the incinerator or refractory lined stacks and breeching. If applied to these surfaces, structural damage may result.

7. Provide proper roof thimbles, clearances, flashing and counter flashing around all roof penetrations, including the incinerator stack.
8. Guying of all stacks (if required) is to be done by the Purchaser/Contractor. Guying should be at three points at 120° apart or four points at 90° apart. The Purchaser/Contractor provides design of guying and guying connection points to the stacks. Torque draw band bolts to 35 lbs. during stack assembly.

9. Provide proper protection of all equipment from damage, vandalism and weather, while on-site and/or when installation is in progress.
10. Provide all touch up painting and cleanup of equipment after erection.
11. Inspect and field weld miscellaneous flanges, when applicable.
12. Supply all main fuel line regulators at connection points to the Incinerator. Fuel lines should be sized for maximum pressures and instantaneous fuel flow at cold starting. Pressures should be based under flow conditions, not static. Static pressure should never exceed the design pressure of the pressure regulator. Gas volume includes burner pilot requirements.
13. General Arrangement drawings are normally provided by EWS. As soon as possible after acknowledgement of a Purchaser/Contractor's order, it is the responsibility of the Purchaser/Contractor to provide EWS with all applicable sketches, layouts, building drawings, roof and floor elevations and other pertinent information to allow preparation of the General Arrangement drawings. With this information, the Purchaser/Contractor's will provide desired orientation of the chambers.
14. The Purchaser/Contractor must recognize the importance of proper waste material descriptions concerning physical and chemical properties. Changes in waste composition to be incinerated should be made known to EWS, as soon as possible.
15. It is the Purchaser/Contractor's responsibility to obtain all construction, operating and environmental/air emissions permits as may be required in the area of jurisdiction for the incinerator equipment. EWS will assist in supplying all technical information required for these permits to the Purchaser/Contractor.
16. The Purchaser/Contractor must be aware that certain components will be broken down for shipment purposes and reassembly will be required in the field by the Purchaser/Contractor.
17. Locating and mounting the incinerator in a confined area should be avoided. The Purchaser/Contractor should maintain ample space around all equipment for maintenance, cleaning and safety considerations. A rule of thumb would be to provide a minimum of six feet from all major equipment surfaces and edges. Always allow proper space for the swing radius of loading doors, cleanout doors and electrical panel doors. If space limitations exist, it is the Purchaser/Contractor's responsibility to make EWS aware of these dimensional restraints so that modifications may be considered.
18. Do not scale drawings: If certain dimensions are required which are not shown on drawings, the Purchaser/Contractor should contact EWS Project Manager. EWS will not be responsible for any dimensional conflicts resulting from dimensions not shown on a certified drawing. Do not use general sales literature or other general equipment submittals for construction unless so indicated. EWS reserves the right to change equipment dimensions as required for design purposes.
19. All drawing dimensions are typically subject to ¼" tolerances.

20. If the refractory is shipped in the green condition, the refractory has not been heat cured. This curing process must be accomplished in the field after final erection and assembly. It is understood that the Purchaser/Contractor will provide all required utilities for this curing process and initial equipment operation for adjustments at no expense to EWS including but not limited to fuel, electrical, water, etc.
21. Due to the physical size of the incinerator, the unit is shipped partially dismantled and will, therefore, require reassembly in the field. Consult EWS for maximum component weights so that properly sized cranes are available at the site for unloading and erecting. Purchaser/Contractor may, also therefore, have to reinstall electrical components and control connections, burners, blowers, lifters, etc. These connections are normally of the flexible type with leads marked.
22. Lifting lugs are provided on chambers, stacks, and major accessories. These lugs should be used in setting the pieces into position. Do not attach lifting chains or cables to piping, control panel or mounting flanges as they may be damaged. Avoid dragging lifting gear across painted surfaces as this will cause damage to the high temperature paint. When placing the incinerator into position be extremely careful not to subject the refractory to mechanical shock as this may result in refractory damage.

Step by Step Assembly and Installation Instructions

The following **sequence** applies specifically to the Meliadine Waste Incinerator.

Trades-people required for the following steps:

Forklift Operator, Crane Operator, Riggers, Electrician and Mechanical Contractors (pipe and gas fitter)

Please refer to the supplied drawings and data.

Foundation Drawing: Anchor Bolt and Loading Diagram ECO1.75TN1PVC100L-00D rev.0

1. The incinerator and related components must be installed on a level concrete pad. It is recommended that appropriate consultation with civil engineers and/or architects is taken before designing an appropriate foundation for the equipment.
2. Please refer to General Arrangement Drawing ECO1.75TN1PVC100L-00A rev.1 and its Bill of Materials.

Place the Primary Chamber and Secondary Chamber on the Foundation

3. Locate leg extension for the Secondary Chamber and put into position.
4. Once the leg extensions have been put into place, using a crane, lift the **Secondary Chamber** into position and connect the leg extensions.



Leg extensions

5. Position the Secondary Chamber (item 2) beside the Primary Chamber (Item 1) on the level concrete pad. Ensure that the breach openings on each Chamber are facing each other.
6. Shim with steel shim plates to ensure the Secondary Chamber is level. This is required to prevent rocking, or any movement of the **Secondary Chamber**.



Connecting the Breech to the Secondary Chamber

1. Install the **Secondary Breech Gasket**, by spraying the gasket adhesive on the Breech connecting flange and on the gasket material. Line up holes of the **Secondary Breech Gasket** to line up with the flange bolt holes. Press **Secondary Breech Gasket** onto flange securely.



Gasket adhesive spray being applied




Correctly Installed Gasket

2. Raise the **Breech** (Item 7) with forklift and slings, once the **Breech** is 8 to 13 cm from the flange, use alignment bars to help with the final alignment of the two (2) breech flanges, as shown below.



3. Once breech flanges are aligned and together bolt flanges together using the numerical order described in the pattern below using hardware provided.



Correctly installed Breech on Secondary Chamber

Position the Primary Chamber

1. Install the **Primary Breech Gasket**, by spraying the gasket adhesive on the Breech connecting flange and on the gasket material. Line up holes of the **Primary Breech Gasket** to line up with the flange bolt holes. Press **Primary Breech Gasket** onto flange securely.



Gasket NOT installed




Correctly Installed Gasket


2. While constantly checking alignment of the **Breech** move **Primary Chamber** along the floor using the forklift and skates until the flanges are aligned.

NOTE Do NOT pull the **Primary Chamber** closer to the **Secondary Chamber** with the flange bolts. Doing so will bow the steep plate, in turn damaging the breech refractory.

3. Once breech flanges are aligned bolt flanges together, shim and level the Primary Chamber with steel shim plates. Support pads should be shimmed as required to prevent rocking, or any movement of the Primary Chamber.
4. Using the numerical order described in the pattern below using hardware provided.



Correctly Installed Breech on Primary Chamber




NOTE The diagram above shows the burners and blowers already attached to the Primary and Secondary Chambers. When positioning the Primary Chamber, Breech and Secondary Chamber, these items will not be attached.

Installing the Stack

Install stack gaskets between stack sections.



Install refractory-lined *T-Stack Section* on top of the *Secondary Chamber* using the hardware provided. Then install the next four *Stack Sections* and the *spark arrestor* as per the drawing using hardware provided.




T-Stack and Stack Sections



This is a Sample Photo only of Erection of the Stack Sections

Installing the Lid Lifters

1. Place the lid lifters (item 27) on either end of the Primary Chamber. The slave column, the one without the hydraulic power pack, is to be located in between the chambers.





2. Once lifters are in place, shim and level, do not exceed 2.54 cm under the column. Anchor the columns to the floor.
3. Install the pre-assembled hydraulic pump on the master column reinforcement and connect the hydraulic hose and piping.
4. Install the limit switches, proximity switches and solenoid valves with the hardware provided.
5. Install the control stations for the lid lifters (attached to junction box at the master column). Location determined by customer.

For further detail consult the OEM manual of this lifter in 6515-S-265-008-280-EDS-0015_Sub002.pages175to190

Assembling and Installing the Primary Chamber Blower

1. Place the **Primary Blower** mounting frame where the **Primary Blower** is to be installed.
2. Install **Primary Blower**, shim and level as required with steel shim plates until the flanges are align. Support pads should be shimmed as required to prevent rocking.
3. Bolt together using bolts provided after alignment of all bolt holes





Assembling and Installing the Secondary Chamber Blower

1. Place the **Secondary Blower** mounting frame where the **Secondary Blower** is to be installed.
2. Install **Secondary Blower**, shim and level as required with steel shim plates until the connecting flanges are level.
3. Bolt together using bolts provided after alignment of all bolt holes.




Secondary Chamber Blower

Installing the View Ports

1. Install four (5) 2" threaded **Viewports** at **positions indicated in red** below on **Primary Chamber door**, the left hand side of the **Primary Chamber Burner**, the **Secondary Chamber door** and the right hand side of the **Secondary Chamber Burner**.

NOTE The viewports should be hand tightened only, do **NOT** over tighten.




Installing the Primary Chamber Burner

1. Install the **Primary Burner** and burner gasket in the burner port located on the right side of the **Primary Chamber**.
2. Bolt together using provided hardware after alignment of all bolt holes.




Primary Burner shown without red cover installed.



Installing the Secondary Chamber Dual Burner

1. Install the **Secondary Chamber Burner** and gasket in secondary burner ports using the hardware provided. The fuel train is pre-assembled and the final installation to follow the P&ID drawing





It is the customer's responsibility to conform to any local codes when installing the Waste Oil System.



Positioning and Installing the Diesel Tank

The Fuel Tanks are to be installed at ground level as per the site layout. Locations are to be determined by the customer to satisfy all local codes. Interconnecting piping and filters for each burner have been shipped with the equipment

Fuel Connections

Reference: General Arrangement ECO1.75TN1PVC100L-00A rev.1 and P&ID ECO1.75TN1PVC100L-00B rev.1 drawings

NOTE All fuel connections to be done by a certified technician and should satisfy all local codes (all lines to be pressure tested), including the distance between the incinerator system and the fuel tanks. If not properly installed and maintained, the waste oil tank (see image) can become a serious threat to the environment. Ensure the installation follows all local regulations and environmental protection measures.

Even though the tank is double walled, it is highly recommended that the installation site of the storage tank be equipped with a secondary containment system consisting of the following: dikes, berms, or retaining walls and a floor. The floor should cover the entire area within the dike, berm or retaining wall.

WASTE OIL PIPING TRAIN

The Waste Oil piping train consists of:

1. Pump skid.
2. Interconnecting piping.
3. Fuel train to dual burner.

When installing the waste oil piping train check to ensure that:

- Piping is clean.
- That the pipe has been reamed and free of burrs
- The work is done to trade standards

To perform the installation a ($\frac{1}{2}$ " and 1") pipe threader is needed.


Note: When the pipe installation is complete flush out the line to remove any sediment and dirt that may have contaminated the pipes.

This incinerator system includes two (2) waste oil totes and their correspondent containment, as well as spill kits according to the volume, these items are to be deployed by the customer according with their waste management plan.

Also, two (2) ash bins are included for the storage of the ash removed from the incinerator.

Installing the Thermocouples

1. Install the four (4) $\frac{3}{4}$ " threaded **Thermocouples** at the positions indicated in red below: two (2) in the **Primary Chamber**, one (1) on **Secondary Chamber** and one (1) on **T-Stack**



Installing the Weigh Scale

The weigh scale is to be installed closer to the loading point (to be determined by customer) and anchor it (note: the loading of this incinerator is intended to be through the roof when the lid is in the open position).

Electrical Connections

Reference: Electrical Drawings ECO1.75TN1PVC100L-10A / B/ C/ D rev.0 (17drawings)

NOTE All electrical connections, terminations and conduit installation to be done by a certified electrician and should satisfy all local codes.

1. The **Main Control Panel** should be installed at a minimum of 8' from the Incinerator system.
2. Wiring is necessary (customer's scope) from the power source to the **Main Control Panel** and between the **Main Control Panel** and the **Junction Boxes** on the incinerator and all Teck Cable from the junction boxes to the components.
3. The **Thermocouples** must be wired directly to the thermocouple input card on the **PLC** with the thermocouple wire provided, without splicing the wire. Interconnecting cable has been shipped with the equipment

4. Connect terminal wires. Connect main electrical feed through conduit connection in the bottom of the panel enclosure to the line terminals on the disconnect switch.
5. Run cables to scale and tank

Start Up and Commissioning EWS Field Services



Do not attempt to place the equipment into operation until an EWS Service Technician has inspected all equipment and interlocks.

1. Upon completion of mechanical erection, interconnection of equipment and provisions of utilities as described above, arrangements should be made with the EWS field service department for scheduling of a service technician for initial start-up.
2. An EWS representative must perform start-up of all incinerator systems unless specifically arranged otherwise in writing by EWS.
3. Attempts to start-up incinerator systems by the buyer without prior written approval may result in revocation of all expressed or implied warranties.

SECTION 5

OPERATING INSTRUCTIONS

Important Information

Proper operating and maintenance procedures must be followed in order for the ECO Model Incinerator system to perform at maximum efficiency.



Do not attempt to start or operate this equipment until this Operator Manual is read thoroughly and is understood.

The equipment has been designed with many safety features, however, like all thermal processes; this equipment is not free from the inherent hazards of high temperature processes.



Safety procedures and precautions must be followed at ALL times during operation.

There are safety procedures outlined in this Manual, however, no amount of written instruction can replace good judgment and safe operating practices.



Responsibility for the safe operation and maintenance of the equipment supplied rests solely on those operating it.

There are many engineered features incorporated into the ECO Model Incinerator system to free the operator of repetitive chores. They do not, however, relieve the operator of maintenance responsibilities. In order to maximize the operating life of the equipment, it is strongly recommended that the maintenance procedures, outlined in Section 6, be followed diligently. It is advisable to keep an equipment log for recording maintenance activities along with unusual operation.

NOTE

In the event that the equipment is not operating in the normal manner, contact Eco Waste Solutions immediately at (905) 634-7022 and ask for Customer Service Manager. It is important to report problems as soon as they are noticed to minimize damage that faulty operation could cause.

Design Specification Criteria

The **ECO 1.75 TN 1PVC100L incinerator systems** was designed specifically for the **Meliadine Mine**. Based on information provided, the EWS team designed an incinerator with the following criteria in mind.

Waste Description and Assumptions

Solid waste:

- Food waste (food, food packaging and containers, plastic and paper waste from food preparation) - 50%
- Domestic waste (paper, plastics, bottles, newsprint, cans, cardboard) - 40% Packaging (cardboard boxes, paper, plastic containers, plastic film, Styrofoam, poly-weave bags) - 10%
- Absorbents (Rags, wipes, spill cleanup materials) - negligible
- Medical waste (bandages, dressings, gloves, swabs, syringes, sharps) - Negligible

Waste Oil:

- Used Oils (hydraulic, transmission, motor, crankcase, gear box, synthetic and brake fluids)

The waste is expected to be bagged or stored in skips/bins around the mine operation and then brought to the incinerator building by truck. The waste oils will be brought to the incinerator by totes (handling by forklift or pallet jack).

Waste Quantity

The incinerator is designed to process and treat the waste generated on site, up to 1,750 kg per day. Therefore the ECO 1.75TN 1PVC100L incinerator system was selected, as it will process up to 1,750 kg of camp waste per day in a single batch.

Incinerator Design Parameters

Incinerator Design Parameters	Unit	Details
Secondary Chamber Operating Temperature	°C	1000
Secondary Chamber Retention Time	s	2 (minimum)
Incineration capacity	Kg/day	1700 1750
Charge per cycle	Kg	1700
Burn Cycle Duration for entire load	h	less than 10
Cool Down Cycle Duration	h	8 to 12

NOTE

This incinerator was only designed for the type of waste and amount of waste mentioned above. It is important that the waste quantities and characteristics described above are processed in the incinerator. Otherwise, the incinerator system will not operate properly.

It is also important to note that some waste-streams are unacceptable and **SHOULD NOT** be processed in the incinerator.

Unacceptable Waste-streams

The following is a list of some of the waste streams that should not be processed in this system.

Waste Materials Not Suitable for Processing in Eco Waste Solutions Technology


Solid Waste	Description	Origin
Bulky Materials	Automotive or heavy equipment parts such as engine blocks and transmissions	From vehicles and equipment maintenance shop
Non-Combustible Materials	Drywall, asbestos, bricks, concrete, soils	Construction activity
Radioactive Materials	Smoke detectors, laboratory wastes	From Buildings, laboratories
Potentially Explosive Materials	Large propane tanks, other pressurized vessels. Actual explosives	From warehouse, plant and production facilities
Heavy Metals	Items containing lead, mercury, cadmium, for example: batteries, electronic devices, fittings, old pipe work, fluorescent light bulbs, electrical switches, thermometers, PVC plastics, aluminum solder, photovoltaic cells	From maintenance activities, operations and construction activities
Liquid Waste	Description	Origin
High Alkaline or High Acid Materials	By-products of industrial processes, unrefined fuels	From warehouse, plant and production facilities
Solvents	Solvents such as acetone, xylene, methanol	From vehicles and equipment maintenance shop

Important Notes:

1. These lists are guides and should not be assumed to be an exhaustive list of materials
2. A waste and procurement audit is highly recommended and encouraged to ensure that all sources of heavy metals (especially mercury) are identified and diverted from the incinerator

General Operating Overview

The operation of the **ECO 1.75TN 1PVC100L Incinerator** package follows 7 general steps that take place over a 24-hour period.



Although all 7 steps are critical in the general operation of the incinerator system, this section of the manual focuses on **Step 1**, **Step 3** and **Step 4** and how to start the system and monitor it during operation.

It is assumed, at this point, that the waste material is properly loaded with the weight, density and type the incinerator is designed for, as outlined on page 5 of this section.

It is also assumed that the waste is loaded after the ash has been removed from the previous burn cycle and any daily maintenance routines have been completed.

This section will also cover **Step 7** on how to use the historical charts, store incinerator data, and access incinerator historical information for record keeping purposes.

Monitoring and Data Acquisition System

Overview

The **Human Machine Interface (HMI)** system automatically monitors the entire process and all system inputs are recorded and logged for record-keeping purposes and also allows for historical trending of key operating conditions.

The integrated **Human Machine Interface (HMI)** in the Main Control Panel monitors and records the following:

1. Temperature sensors
2. Differential pressure sensor with transmitter (draft)
3. Monitoring of burner functions
4. Auxiliary burner operation and fan amperage monitoring via current transducer
5. Door position interlock monitoring
6. High temperature limit and interlock
7. Low Fuel level limit and interlock
8. Air proving switch interlocks
9. Waste loading records

All data can be transferred to storage by using USB port (to transfer to PC to print)

HMI Operator Interface
Main Control Panel Components


Number	Name	Purpose
1	Main Disconnect Switch	Isolates the incinerator from its source of electric power.
2	Human Machine (Operator) Interface	Displays various screens reflecting system performance.
3	Control Power ON	<ol style="list-style-type: none"> Green light indicates the control power in the panel is on. Pushing it if the Emergency-Stop is out will turn on the control power.
4	Emergency Stop Pushbutton	When pushed, shuts down the system and disables any possibility of starting it.
5	Communications Port	Allows for communication to/from the PLC
6	Start Switch	Activates the system

The Human Machine Interface (HMI)


The **Human Machine Interface (HMI)** controls the operation of the incinerator directly from the **Main Control Panel**.

The **Main Menu** screen displays all the available options for viewing the system in operation.

The **Human Machine Interface (HMI)** has a touch-screen and items can be selected by touching them on the screen.

Main Menu

The first screen the operator will view is the **Main Menu** (see below).




Top View

When the **Top View** button is selected, an overview of the incinerator and related components is displayed. This shows key temperatures, flows, and other indicators of what is happening in the process in a real-time basis.

NOTE

The system will not start if there are alarms or faults present. Clear and/or acknowledge faults.

At any time, touch **Main Menu** to go back to the main screen.




System Status

When the **System Status** button is selected from the **Main Menu**, a screen will display the status of all the operating parameters of the incinerator, such as the temperatures and the time remaining in the cycle, as well as displaying other informational items such as status of the door, lid lifter, blowers, etc.

The operator can change the burn time of the cycle by selecting “BURN TIME” and entering a time (in minutes). The operator may do this over time to either prolong the burn time, or decrease the burn time depending on the waste mixture; for example a very wet batch of garbage will take more time to burn than a dryer batch of waste.

At any time, touch **Main Menu** to go back to the main screen.



The screenshot displays the System Status control panel interface. At the top left is a 'MAIN MENU' button. In the center is a large red 'SYSTEM OFF' indicator. At the top right is a green 'PRESS TO CLEAR FAULT' button. The main display area is organized into several sections:

- Temperature and Flow Parameters:** A row of eight digital displays showing '???? °C' for Primary Bottom, Primary Top, and Secondary Temperatures; '??? %' for Primary and Secondary Damper Percent Open; '???? RPM' for Secondary Blower Speed; and '??? Pa' for Primary Chamber Draft.
- Motor and Load Parameters:** A row of four digital displays showing '?.? Amps' for Primary and Secondary Blower Motor Current, '???? Kg' for Total Weight of Load, and '??? %' for Opacity.
- Operational Status Indicators:** A row of five circular indicators: Primary Chamber Door Open (black), Primary Chamber Air Flow Off (black), Primary Chamber Blower Off (black), Primary Chamber Burner Off (black), and Primary Chamber Lid Closed (yellow).
- Control Panel:** A central panel with 'BURN TIME' (displaying '???? MINUTES'), 'TEST BURN TIME', and 'RESET COOLDOWN' buttons.
- Pressure and Safety Indicators:** A row of ten circular indicators: Secondary Chamber Door Open (black), Secondary Chamber Air Flow Off (black), Secondary Chamber Blower Off (black), Waste Oil/Diesel Burner Off (black), Waste Oil/Diesel Pump Off (black), Waste Oil/Diesel Blower Off (black), Waste Oil/Diesel Mixers Off (black), Waste Oil/Diesel Pressure OK (blue), Waste Oil/Diesel Combustion Air Pressure Low (black), and Differential Pressure Across Combustion Air Valve High (black).

On the right side of the panel, there is a large white box with green text that reads 'CYCLE COMPLETE SAFE TO OPEN DOORS'.


Overview of Historical Charts

The **Human Machine Interface (HMI)** monitors and records (every minute) critical operating parameters of the incinerator system like the temperature, motors, draft, load weights and alarms. Each operating parameter has its own graphic display for the operator to view, at any given time. Each display can easily be selected from the **Main Menu** of the **Human Machine Interface (HMI)**. The display will show the specific data collected from previous burn cycles.

This **Incinerator Data** is important for regulatory purposes and for general operating purposes. Also, the incinerator data is to be downloaded on a weekly basis to USB key for record-keeping purposes.


Temperature History

For example, when the **Temperature History** button is selected, the screen will display the trend in temperature during the operation of the system, include date & time of occurrence of that specific temperature.




Motor Currents History

When the **Motor Currents History** is selected a screen will display the motor currents from the Primary Burner and the Secondary Burner, in AMPS, during the operation of the system, including date & time of occurrence of that specific motor current.




Draft History

When the **Draft History** button is selected a screen will display the draft during the operation of the system, include date & time of occurrence of that specific draft trend.




Secondary Blower Speed History

When the **Secondary Blower Speed History** button is selected a screen will display the RPM during the operation of the system, include date & time of occurrence of that specific speed.



Opacity History

When the **Opacity History** button is selected a screen will display the Opacity during the operation of the system, include date & time of occurrence of that specific reading.




Alarm History

When the **Alarm History** button is selected a screen will display the last 128 faults with the date & time of occurrence.

The operator can press the **CLEAR ALARM HISTORY** to clear all of the faults, if they wish to. This does not affect the record-keeping feature of the system.


At any time, touch **Main Menu** to go back to the main screen.



Standard Daily Operating Procedures

Incinerator Daily Start up


1. Ensure that manual slide gates for each blower are in the open position for free airflow into the **Primary and Secondary Chambers**.



1. **Primary Chamber Blower** Manual Slide Gate Open



2. **Primary Chamber Blower** Manual Slide Gate Closed



3. **Secondary Chamber Blower** Manual Slide Gate Open

2. Visually inspect the burner hoses to ensure that there are no fuel leaks. Check to see if lines are brittle or cracked, check for any oil spills near the burner, which would indicate a leak.

3. Ensure the draft gauge hose connection is tight and sealed. This is a clear flexible tubing located in the **Primary Chamber** (see photo below).



Sample picture

4. Unlatch all clamps on the **Primary Chamber** door, open and secure in the open position



5. Ensure the Primary Chamber floor is cool (less than 90°C). Remove all the ash from the previous burn and store ash in ash bins.
6. Lock the **Primary Chamber** Front Loading Door and ensure all latches are properly engaged.



If the floor is too hot the waste may spontaneously catch on fire during loading.

High Output dual Burner Secondary Chamber Start-up

SYSTEM CHECK



Filter & Pump.(sample image)

Do a walk around the Waste Oil System, ensuring that there are no leaks, all ball valves are in the proper and fully open position for either Diesel or Waste Oil according to the fuel to be used for this specific cycle

Ensure that the correspondent storage tank has enough fuel for the entire cycle.

Using Waste Oil: 800 L minimum of Waste Oil and 300 L minimum of Diesel (the Primary Chamber operated with Diesel only)

Using Diesel Only: 1100 L of Diesel minimum

Both the Waste Oil and Diesel Tanks require at least 150L stored at all time to keep the level sensor closed.

Clean the filter if necessary.


Check that all of the ball valves on the burner fuel oil train are fully open

Check that the Incinerator is not in cool down and the Primary temperature is 90°C or less.

Loading Procedure

Operator Stations for Lid Lifter

The Primary Chamber of the ECO 1.75TN 1PVC100L Waste Incinerator has a lid lifter to allow the roof of the chamber to be opened for quick loading of the waste.



Number	Name	Purpose
A1	Raise Lid	Raises the Lid on the Primary Chamber
A2	Lower Lid	Lowers the Lid on the Primary Chamber
A3	Stop Lid	Stops the lid during raising or lowering.

Once the roof is opened, the chamber can be loaded by the operator with the waste going to the incinerator.

Operating the Integrated Weigh Scale

1. The Operator has two options for managing the waste quantity prior to loading the selected Primary Chamber:
 - i. Option 1: The operator will use the hoppers (previously tarred) to load waste onto the weigh scale.
 - ii. Option 2: The operator may load waste/garbage (in bags/boxes) on the weigh scale directly.
2. Regardless of the option selected above, once the waste is on the weigh scale the Operator has to push the RECORD WEIGHT (black button) on the Weigh Scale Push-Button Station. By pressing this button, the weight value of that particular load of waste is sent to the PLC and the weight is recorded. At this time, the MAXIMUM WEIGHT (green button) will flash green once to show that the weight has been logged.
3. Then, the operator must take the waste and load it into the Primary Chamber. The hopper is to be raised just past the top edge of the Primary Chamber (using proper lifting equipment by others).
4. Once the hopper clears the edge of the Primary Chamber, the hopper's content can be dumped inside the chamber.
5. The empty hopper can now be pulled from the edge of the chamber and then lowered.
6. The operator returns to the weigh scale with some more waste and repeats Steps 2 to 6. This entire procedure is repeated until the maximum load weight for the Primary Chamber is reached. The PLC will indicate this to the operator when the MAXIMUM WEIGHT (green light) comes on and remains on. This indicates that the maximum weight permitted, in this case, the incinerator is designed for a maximum of 1,750Kg of waste material.

NOTE

No more waste should be loaded into the Primary Chamber after the load has reached the maximum weight.

7. The Primary Chamber is loaded, and the incinerator is ready to start.

Tips for loading: To decrease burn time and allow for more uniform burn.

- a. Load the less dense waste first
- b. Load dry waste first. Placing wet waste near the top of the Primary Chamber allows moisture to evaporate early in the cycle.

NOTE

Do not load waste greater than 90 Kg using the top loading system. This waste is to be loaded from the front of the unit. Loading waste over 90 Kg from the top will cause refractory floor to fracture.

NOTE

Do not throw the waste towards the sides of the Primary Chamber. Doing so will damage the ceramic blanket refractory.

NOTE


Load only the waste stream that the system has been designed for. DO NOT load a lot of high BTU rated waste for one burn (e.g. do not load more than three (3) gallons of bacon grease, kitchen grease or cooking oil). Doing so will result in excessive temperatures in the system reducing the life of the refractory.

NOTE

Do not load the Primary Chamber above its rated capacity by weight.

NOTE

Do not load the Primary Chamber such that the Breech and Burner section is blocked in any way.



Breech Opening



Burner port


8. Inspect the lid ledge of the Primary Chamber and remove any debris that will prevent a tight seal with the lid.
9. Close the **Primary Chamber** lid by pressing the close button on the Lid Lifter Station. The lid will initially raise, after 0.5 seconds the safety pawls will pull out. Two seconds after sensing that the safety pawls are out the lid will lower.
10. The lid will keep lowering until either the down limit switch is activated or the stop button is pressed.
11. If the stop button was pushed just press the close button to resume lowering. The lid will raise then lower again. When the lid is stopped by either the lower limit switch or the stop button the safety pawls will be released back in.
12. Proceed to the **Main Control Panel**.

NOTE

The burn time will be set to the previous burn, if you wish to change the set time, proceed to the Primary Status screen and click on the **BURN TIME** button. The minimum number of minutes you can enter is 480 (8 hours). When you have finished, the time will be displayed in minutes beside the **BURN TIME** button

NOTE

The burn time value (in minutes) determines the length of the burn cycle before cool down cycle starts.



13. Check that the PRIMARY DOOR AND LID are closed on the **Human Machine Interface (HMI)** screens.
14. Check that no alarms are displayed on the **Human Machine Interface (HMI)**
15. Check that the EMERGENCY STOP BUTTON is out.
16. Check the GREEN CONTROL POWER BUTTON is lit up. Press this button to power on the control panel
17. On the **Main Control Panel** turn the **SELECTOR SWITCH** to the right to start the cycle. The following steps will automatically take place, controlled by the **Main Control Panel**:
 - I. The **Primary Blower and Secondary Blower** will purge the system for 2 minutes.
 - II. The **Secondary Burner** will purge for safety, and upon completion will ignite.
 - III. Once the **Secondary Chamber** temperature reaches 1000°C, the **Primary Burner** on both Primary Chambers will purge for safety and upon completion will ignite.

- IV. The burn time will start counting down when the temperature in the **Primary Chamber** reaches 427°C.

NOTE

The Main Control Panel System will maintain proper operating conditions and will provide continuous monitoring capability

After the burn cycle is completed the system will enter the cool-down cycle when the following things will occur:

- Primary Chamber & Secondary Chamber burners OFF
- Secondary Chamber Blower OFF
- Primary Modutrol 100% open
- Primary Blower ON

Once fully cooled and the temperature is below 90°C, proceed to the **Primary Chamber Clean Out Procedures**.

Primary Chamber Clean Out Procedures



Operators responsible for loading and cleaning out incinerators should wear appropriate protective equipment, including eye protection, dust masks, heavy gloves and safety shoes with puncture-proof toes and soles to avoid injury.

Although the ash from the system is considered sterile and will not contain microorganisms, it may contain a quantity of sharp objects, such as broken glass and other sharps which may not be fully destroyed in the burning process, and may thus still pose a hazard to persons who clean out the ash and residues. Also removing the ash does create dust particles in the air. Dust should not be inhaled. The operator must wear dust protection safety gear.

Please follow these steps when the cycle is complete:

1. When the internal temperature of the **Primary Chamber** has cooled to less than 40°C, lock out the power to the system on the **Main Control Panel** by moving the main disconnect to the “OFF” position.
2. Unlock all door latches on the access door to the **Primary Chamber**.
3. While standing in front of the **Primary Chamber** door, slowly open the door to allow clear entry. Secure **Primary Chamber** Door in the OPEN position.
4. With the **Primary Chamber** Door secured in the open position, raise the lid to fully opened
5. Clean the **Primary Chamber** by using ash handling tool(s) and proper safety equipment (not provided).
6. Inspect the interior of the **Primary Chamber** for wear and inspect around the door seals to ensure the door will maintain a tight seal upon closure.
7. Check the air inlet holes and remove any obstructions if necessary.

8. Inspect the door seals to ensure there are no gaps between the door gasket and the door jamb.
9. Close the **Primary Chamber** access door by clamping each latch until it is tight.
10. Clean the inspection **View Port** (glass) with a mild soap and water. To clean the view port, unscrew it by hand and re-tighten by hand.

In Case of Emergency



1. Go to manual Slide Gates on the **Primary Chamber**, located just after the blower and close them all the way. This will help to put the fire in the **Primary Chamber** out.
2. Check alarms to see what the problem is.
3. Do not open the door of the **Primary Chamber** unless the temperature inside the chamber is below 90°C.
4. Call a certified technician to fix the problem and/or consult with **Eco Waste Solutions Customer Service Department at 905.634.7022, toll free 1-866-326-2876.**

Start Up After Power Failure

1. Once the power is restored turn breaker (main disconnect) back on.
2. The **Human Machine Interface (HMI)** and PLC will begin a boot up procedure.
3. Wait until the **Human Machine Interface (HMI)** on the **Main Control Panel** has booted up before turning the control power to the panel back on by pressing the Control Power ON button.
4. When the power is restored to the **Main Control Panel**, the button should illuminate.
5. If the system was interrupted during a burn cycle, restart the system by turning the selector switch on the main panel to the right to start the cycle . If the system was interrupted during cool-down cycle, it will resume the cycle where it left off.

Dealing with Warning and Faults

Troubleshooting

The burn cycle will not start if one of the following conditions exists:

1. The system is in the “cool-down” part of the cycle. Wait until the “cool down” cycle is complete.
2. There is a fault in the system as indicated on the **HMI**
3. Loss of power due to any one or more of the following:
 - The main disconnect (see image) is off or there is no electrical power. Turn on the disconnect switch or check why there is no power.



Power is OFF in this position



Power is ON in this position


- An open breaker. Check the breakers and replace any that are defective.
- The EMERGENCY STOP is pushed in. Twist the EMERGENCY STOP button to unlock, and then push the CONTROL POWER ON button. The CONTROL POWER BUTTON should now be illuminated.



4. If on the Main Control Panel HMI the **Primary Chamber** door is not closed, the door has not been shut properly. Adjust the limit switch lever arm if necessary. Check the limit switch and that the wiring is in working order.
5. If on the Main Control Panel HMI the **Primary Chamber** roof lid is not closed, the lid has not been shut properly. Adjust the limit switch lever arm if necessary. Check the limit switch and that the wiring is in working order.
6. If on the Main Control Panel HMI the **Secondary Chamber** door is not closed, the door has not been shut properly. Adjust the limit switch lever arm, if necessary. Check the limit switch and that the wiring is in working order.
7. If fuel tank is low, system will not start. Tank on the **HMI** will be red, indicating the level is low and needs to be filled.

PLC Processor Problem

There are several LEDs available on the front panel of each Modicon M340 module or processor, enabling rapid diagnosis of the PLC status:




These LEDs provide information on:

- PLC functioning
- the memory card
- communication with the modules
- serial communication
- communication on the CANopen network
- communication on the Ethernet network

The following diagram shows the diagnostic LEDs on the BMX P34 2020 processor. Note that two displays exist, depending on whether you are using firmware V1 or V2

(or greater) of the processor.



The colors and blink patterns of the LEDs indicate the status and operating conditions of Ethernet communications on the module:

Label	Pattern	Indication
RUN (green): operational state	on	<ul style="list-style-type: none"> PLC hardware and PLC program operations are normal. Module is in RUN state.
	flashing	<ul style="list-style-type: none"> PLC is in STOP mode or a blocking error in the application has been detected. Processor is configured but not in RUN state.
	off	PLC is not configured (application is absent, invalid, or incompatible).
ERR (red): detected error	on	Processor, system, or configuration detected error
	flashing	<ul style="list-style-type: none"> PLC is not configured (application is absent, invalid, or incompatible). PLC is in STOP mode or a blocking error in the application has been detected.
	off	Normal (no detected errors)
ETH STS (green): Ethernet communication status	on	Communication OK
	2 flashes	Invalid MAC address
	3 flashes	Link not connected
	4 flashes	Duplicate IP address
	5 flashes	Waiting for a server IP address
	6 flashes	Secure and safe mode (with default IP address)
	7 flashes	Configuration conflict between rotary switches and internal configuration
CARDERR (red): memory card detected error	on	<ul style="list-style-type: none"> Memory card is missing. Memory card not usable (bad format, unrecognized type). Memory card content is inconsistent with internal RAM application.
	off	<ul style="list-style-type: none"> Memory card is valid and recognized. Application on card is consistent with the internal RAM application.
I/O (red): input/output status	on	<ul style="list-style-type: none"> Error detected on a configured module or CPU channel Configuration mismatch with the application (module missing...)
	off	Normal (no detected errors)

SER COM (yellow): serial data status	flashing	Data exchange (send/receive) on the serial connection in progress
	off	No data exchange on the serial connection
CAN RUN (green): CANopen operations	on	CANopen network operational
	rapid flashing (note 1)	Automatic detection of data flow or LSS services in progress (alternates with CAN ERR).
	slow flashing (note 2)	CANopen network is pre-operational.
	1 flash	CANopen network is stopped.
	3 flashes	Downloading CANopen firmware.
CAN ERR (red): CANopen detected error	on	CANopen bus is stopped.
	rapid flashing (note 1)	Automatic detection of data flow or LSS services in progress (alternates with CAN RUN).
	slow flashing (note 2)	CANopen configuration is not valid.
	1 flash	At least one error counter has reached or exceeded alert level.
	2 flashes	A guard event (NMT slave or NMT master) or a heartbeat event has occurred.
	3 flashes	The SYNC message was not received before the end of the communication cycle period.
	off	No error detected on CANopen.
CARDAC (green): memory card access Note: This LED is located under the memory card door (see <i>The Module</i> , p. 20).	on	Access to the card is enabled.
	flashing	Activity on the card: during each access, the card LED is set to OFF, then back to ON.
	off	Access to the card is disabled. You can remove the card after you disable card access by setting system bit %S65 to 0.
Note 1: Rapid flashing is defined as ON for 50 ms and OFF for 50 ms.		
Note 2: Slow flashing is defined as ON for 200 ms and OFF for 200 ms.		

The following table describes the meaning of the ETH ACT and ETH 100 LEDs on the front panel for firmware V1 NOE and CPU modules.

Label	Pattern	Indication
ETH ACT (green): Ethernet communication (transmission/ reception activity)	on	Ethernet link detected: no communications activity.
	off	No Ethernet link detected.
	flashing	Ethernet link detected: receiving or sending packets.
ETH 100 (green): Ethernet transmission speed	on	Ethernet transmission at 100 Mbit/s (Fast Ethernet).
	off	Ethernet transmission at 10 Mbit/s (Ethernet) or no link detected.

The following table describes the meaning of the ETH ACT and ETH LNK LEDs on the front panel for firmware V2 NOE and CPU modules.

Label	Pattern	Indication
ETH ACT (green): Ethernet communication (transmission/reception) activity	on	Communications activity detected.
	off	No communications activity detected.
ETH LNK (green): Ethernet link status	on	Ethernet link detected.
	off	No Ethernet link detected.



Note:

- Rapid flashing is defined as ON for 50 ms and OFF for 50 ms.
- Slow flashing is defined as ON for 200 ms and OFF for 200 ms.

Possible Problems, Causes and Solutions


Problem	Causes	Solutions
Blower Fails to start	Over load tripped, blown fuse	Turn power off. Open Panel and reset overload. Check fuse and replace.
	Motor starters or contactor coil is burnt out	Locate contactor for Blower and visually observe if the contactor is pulled in. Use a volt meter to check for voltage across the coil. If there is voltage across the coil and the contactor is not pulled in, replace the contactor.
Secondary Burner won't ignite	Bad Electrodes	Refer to Section 6 of this manual.
	Low Oil Pressure	Adjust pressure setting on burner pump. Refer to Riello Manual in Section 10.
	Fuel Line Leak	Visually inspect the lines for the leak. Tighten any fittings that are near the leak.
	Door Switch not making contact Burner alarm has been tripped	Make sure main door is closed and latched shut. Make sure limit switch is hitting striker plate.
	Bad Thermocouple	Replace thermocouple .
Primary Burner won't ignite	Bad Electrode	Refer to Section 6 of this manual.
	Low Oil Pressure	Adjust pressure setting on burner pump. Refer to Riello Manual in Section 8.
	Fuel Line Leak	Visually inspect the lines for the leak. Tighten any fittings that are near the leak.
	Door Switch not making contact or broken	Make sure main door is closed and latched shut. Make sure limit switch is hitting striker plate.
	Secondary temperature not at 1000°C	Wait until Secondary temperature is at 1000°C and try again.
	Burner main switch is turned off	Turn switch on.
	Burner alarm has been tripped	Acknowledge burn alarm and then hit the reset button on control panel.


Problem	Causes	Solutions
Persistent Black Smoke	Insufficient air supply to Secondary Chamber to completely consume emissions	Check to ensure combustion air blower/damper assembly is operating properly.
	Secondary Chamber is not hot enough.	Check that the Secondary temperature is operating at required temperature set point.
	Secondary Chamber is not hot enough.	Too much draft, open barometric damper.
	Overloading or loading highly volatile material	Decrease load size on next batch (confirm by weighing), ensure the waste mix is correct.
	Burner failure	Check burner operation – if no flame or a poor flame is visible through the flame view port adjust air/fuel ratio.
	Operating at a too high Primary Chamber temperature	Check/decrease primary chamber combustion air.
Smoke coming out of Primary	Too much air	Check dampers on primary blower.
	Too much volatile material loaded	Decrease load size on next batch to ensure the waste mix is correct.
	Primary Chamber temperature too high	Waste loaded may not be a good mix of heat value.
	Low draft	Close barometric damper on stack's T-section
Too much fuel usage	Too much secondary combustion air	Check/reduce secondary combustion air.
	Too much air infiltration	Reduce air flow by adjusting the damper.
	Fuel leakage	Check fuel trains and burners for fuel leakage.
	Wet waste	Spread wet waste with other waste through several loads – do not charge all of the wet waste at one time.
	Excessive draft	Check/reduce draft – check door seals and other seals for leakage adjust damper.
	Burner setting too high	Check air/fuel mix.

Problem	Causes	Solutions
		Correct Maximum Flame Adjustment (Proper Oil and Air Pressure with correct supply of combustion air)
		Incorrect Flame Adjustment (Not enough Combustion Air)
		Incorrect Flame Adjustment (Air Pressure too high; too much air)
Incomplete burnout/poor ash quality	Build-up around air holes – clogged with ash from previous burn	Check around air holes and clean.
	Poor draft	Draft should be -0.2-0.06 KPa (or 0.8-0.25" W.C).
	Too much wet waste – overloading system	Spread wet waste with other waste through several loads – do not charge all of the wet waste at one time.
	Insufficient burn time	Allow longer burn time period.

Possible Alarms (Faults)

#	ALARM (System Fault)	SOLUTION
1	The Primary Chamber top/bottom thermocouple is faulted	Refer to Section 6 of this manual for corrective maintenance procedures.
2	The Secondary Chamber thermocouple is faulted	Refer to Section 6 of this manual for corrective maintenance procedures.
3	The Secondary Stack Thermocouple is faulted	Refer to Section 6 of this manual for corrective maintenance procedures.
4	The primary burner is faulted	<p>The primary burner has failed to light when it received a signal to start. To reset the burner, press the reset button located on the Burner.</p> <p>If this does not start the burner, refer to Supplier Catalogue (Riello Burner) in Section 8</p>
5	The secondary burner is faulted	The secondary burner has failed to light when it received a signal to start. To reset the burner,
6	The system has shut down due to primary blower low air flow.	<p>Visually examine the primary blower for any obstructions that may be causing low air flow.</p> <p>Check slide gate located between Primary chamber and blower, ensure it is open.</p> <p>Check damper assembly, ensuring modutrol crank arm is still connected and that butterfly damper is open, allowing air flow.</p> <p>Air proving switch may be defective. Refer to Section 6 of this manual.</p> <p>There are two ports on the air flow switch marked V and P. Ensure the inlet tube is attached to the port marked "P" for pressure. V stands for vacuum. Ensure the "V" port is open to atmosphere and is not blocked.</p> <p>If no air restriction is observed (i.e. blockage in the tube) change the air proving switch. Refer to Section 6 of this manual.</p>
7	The primary blower motor overload is tripped.	<p>Turn power off on Control panel by turning the Main Disconnect to the OFF position.</p> <p>Reset overload.</p>




#	ALARM (System Fault)	SOLUTION
8	<p>The system has shut down due to secondary blower low air flow</p> 	<p>Visually examine the Secondary Blower for any obstructions that may be causing low air flow.</p> <p>Check slide gate located between Secondary chamber and blower, ensure it is open.</p> <p>Check damper assembly, ensuring Modutrol crank arm is still connected and that butterfly damper is open, allowing air flow.</p> <p>Air flow switch may be defective. Refer to Section 6 of this manual.</p> <p>There are two ports on the air flow switch marked V and P. Ensure the inlet tube is attached to the port marked "P" for pressure. V stands for vacuum. Ensure the "V" port is open to atmosphere and is not blocked.</p> <p>If no air restriction is observed (i.e. blockage in the tube) change the air proving switch. Refer to Section 6 of this manual.</p>
9	<p>The Secondary blower variable frequency drive is faulted</p>	<p>Push fault reset button on the HMI</p> <p>If fault persist check the error code on the variable frequency drive and check manual for troubleshooting alarm.</p>
10	<p>The burner fuel level is low.</p>	<p>Add fuel to the fuel tank and the alarm should reset itself.</p> <p>If alarm persists, replace the low level switch.</p>
11	<p>Primary Chamber – lid lifter hydraulic pump overload.</p>	<p>Turn power off on Control panel by turning the Main Disconnect to the OFF position.</p> <p>Reset overload.</p>
12	<p>Primary Chamber – lid lifter stuck while rising.</p>	<p>Check to see if anything is blocking the lifts or roof from raising</p> <p>Check the power pack fluid level to ensure enough hydraulic oil is available</p> <p>Check the limit switch is working</p>

#	ALARM (System Fault)	SOLUTION
13	Primary Chamber - lid lifter stuck while lowering.	<p>Check to see if anything is blocking the lifts or roof from lowering</p> <p>Check the power pack fluid level to ensure enough hydraulic oil is available</p> <p>Check the limit switch is working</p> <p>This can be caused by a burnt out solenoid valve. Check that the control valve is open.</p>
14	Primary Chamber - lid lifter left or right safety pawl failed to retract.	<p>Check the proximity switch that senses that the safety catch is out</p> <p>Check the solenoid valves (located on each column)</p>


Record Keeping

Accessing Historical Information

1. It is recommended that a dedicated folder be set on the destination computer that is used for storing data from the Incinerator Package (e.g. “Incinerator Data”)
2. Turn power off to the Main Control panel by turning the Main Disconnect to the OFF position.
3. Open the Main Control Panel door and remove the USB from the back of the HMI panel and insert the USB into the destination computer.
4. Open an Excel File, once opened go to File/Open locate the USB on your computer, in the bottom right corner choose “All Files”.




5. Click on the “logging” file and press open.




6. Excel will prompt you with a text import wizard, follow the next 3 steps to ensure the log files is displayed properly:


7. Steps 1 of 3 choose delimited – character such as commas or tabs separate each field, and choose Next:




8. Steps 2 of 3 choose Comma as the delimiting item, and choose Next:



9. Steps 3 of 3 Column data format should be Date with DMY – character such as commas or tabs separate each field, choose Finish.




10. Once the data is open, it will look similar to the following:



	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q
1																	
2																	
3	19/08/2016	8:33:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
4	19/08/2016	8:34:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
5	19/08/2016	8:35:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
6	19/08/2016	8:36:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
7	19/08/2016	8:37:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
8	19/08/2016	8:38:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
9	19/08/2016	8:39:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
10	19/08/2016	8:40:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
11	19/08/2016	8:41:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
12	19/08/2016	8:42:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
13	19/08/2016	8:43:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
14	19/08/2016	8:44:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
15	19/08/2016	8:45:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
16	19/08/2016	9:32:16	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
17	19/08/2016	9:33:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
18	19/08/2016	9:34:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
19	19/08/2016	9:35:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
20	19/08/2016	9:36:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
21	19/08/2016	9:37:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
22	19/08/2016	9:38:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
23	19/08/2016	9:39:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
24	19/08/2016	9:40:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
25	19/08/2016	9:41:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
26	19/08/2016	9:42:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
27	19/08/2016	9:43:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
28	19/08/2016	9:44:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
29	19/08/2016	9:45:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
30	19/08/2016	9:46:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
31	19/08/2016	9:47:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
32	19/08/2016	9:48:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low

11. From the electronic template file located on the USB for the manual copy the first row and paste into your log file:



	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q
1	D/M/Y	Time	Primary Chamber Temp °C	Primary Chamber Temp °C	Secondary Chamber Temp °C	Stack Temp °C	Draft Pascals	Primary Chamber Blower Fan Amps	Secondary Chamber Blower Fan Amps	Primary Chamber Damper Position % Open	Secondary Chamber Damper Position % Open	Primary Chamber Burner Fault	Secondary Chamber Burner Fault	Primary Chamber Door Position	Secondary Chamber Door Position	Stack Hi Temp Limit	Fuel Level
2																	
3	19/08/2016	8:33:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
4	19/08/2016	8:34:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
5	19/08/2016	8:35:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
6	19/08/2016	8:36:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
7	19/08/2016	8:37:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
8	19/08/2016	8:38:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
9	19/08/2016	8:39:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
10	19/08/2016	8:40:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
11	19/08/2016	8:41:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
12	19/08/2016	8:42:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
13	19/08/2016	8:43:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
14	19/08/2016	8:44:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
15	19/08/2016	8:45:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
16	19/08/2016	9:32:16	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
17	19/08/2016	9:33:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
18	19/08/2016	9:34:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
19	19/08/2016	9:35:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
20	19/08/2016	9:36:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
21	19/08/2016	9:37:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
22	19/08/2016	9:38:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
23	19/08/2016	9:39:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
24	19/08/2016	9:40:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
25	19/08/2016	9:41:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
26	19/08/2016	9:42:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
27	19/08/2016	9:43:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low
28	19/08/2016	9:44:00	0	0	0	0	0	0	0	0	0	OK	OK	Open	Open	Tripped	Low

12. Save your excel file with the date in the designated folder.

13. Reinstall the USB to the back of the HMI, close the Main Control Panel door and turn power back on to the system.

SECTION 6

MAINTENANCE INSTRUCTIONS

Zero Mechanical State & Lock Out Procedures

Proper maintenance of the equipment is essential to ensure long term, reliable operation of the EWS Incinerator.

NOTE The warranty will become void if proper maintenance is not performed as instructed.

Safety

During maintenance of the EWS mobile incinerator, it is very important to be aware of special hazards. Two safety programs are described in the following sections:

1. Zero Mechanical State
2. Power Lock Out Procedures



Failure to comply with these instructions during maintenance could result in injury or death. The responsibility for implementation of a comprehensive safety program rests with the operating staff and supervision. The safety procedures in this *Manual* should be considered only as a starting point for the safety program at site.



ACCIDENTS CAN BE PREVENTED A CAREFUL WORKER IS THE BEST SAFETY DEVICE

Zero Mechanical State

Zero Mechanical State (ZMS) exists when the possibility of an unexpected mechanical movement has been eliminated. During maintenance, it is absolutely mandatory to totally deactivate the incinerator so that there is no possibility of an unexpected machine movement. Power lock-out, described in the next section, is commonly used for this purpose. Most machines are powered by electrical, hydraulic or pneumatic drives. Energy may be stored in a shutdown machine in various ways: Air pressure in a cylinder, hydraulic pressure fluid stored in pressurized hoses, or machine members whose weight can generate fluid pressure. Therefore, just cutting off the electrical power may not be enough to neutralize all power sources. Certain maintenance procedures at site should require ZMS condition as a matter of course.

Zero Mechanical State (ZMS) Checklist:

1. Every electrical power source to the incinerator must be cut off and locked out (to prevent others who may not be aware of maintenance work from turning the power back on inadvertently).
2. Ensure that the mechanical potential energy of the incinerator is at its lowest practical value so that opening of pipe, tubing, hose or actuation of any valve will not produce an unexpected movement that could cause injury.

3. Check that there is no pressurized fluid (air, oil, gas or other) trapped in the incinerator lines, cylinders or other components. This will ensure that there will be no incinerator motion when a valve is actuated.
4. Secure loose or freely moving parts so that there is no possibility of accidental movement.

Power Lock Out Procedures



Unexpected operation of electrical equipment started by automatic or manual remote control may cause injuries to persons who happen to be nearby. For this reason, when repair work is to be done on motors or other electrical equipment the circuit should be opened at the switch box and the switch pad locked in the OFF position. Tag the switch with a lock out tag indicating who must be contacted before the power is turned back on again.

BECAUSE OF THE SEVERE CONSEQUENCES, INCLUDING DEATH, OF NOT PROPERLY LOCKING OUT ELECTRICITY SUPPLIES DURING MAINTENANCE, THE SUPERVISOR SHOULD ENSURE THAT THERE IS ONLY 1 KEY FOR THE LOCK USED TO LOCK OUT THE POWER SUPPLY.

For identification, locks may be color coded to indicate different crews or shifts.

The Supervisor should maintain the master key and list of key numbers, and should keep an extra key to each lock for his department. The master key should not be loaned out under any circumstances.

No matter what method is used to lock out power to electricity, strict discipline and constant supervision should be employed during any equipment maintenance work.

Power Lock Out Checklist

1. Alert the operator of the equipment.
2. Before starting the work on an engine or motor, line shaft or other power transmission equipment or power-driven machine, make sure it can not be set in motion without your knowledge.
3. Place your own padlock on the control switch, lever, or valve, even if someone has locked the control panel before you. You will not be protected unless you put your own padlock on it. (Another maintenance person could remove their lock and then someone else could start the equipment if they were not aware of maintenance work being done.)

When finished working at the end of your shift remove your own padlock. Never permit someone else to remove it for you. Be sure you are not exposing someone else to danger by removing your padlock

Instruction Classification

Each component is associated with an identification number, see table below:

System Component	Identification number
Primary Blower	01-001
Secondary Blower	02-001
Primary Burner	01-002
Secondary Burner	02-002
Refractory	05-001
Air Compressor	03-001
Thermocouple	05-002
Main Control Panel	03-010
Paint	05-003
Electrical	05-004
Limit Switch	05-005
Lid Lifters	06-001

To differentiate if the instruction is weekly, monthly, quarterly or yearly, the above identification number will be followed by a letter:

Daily: D
 Weekly: W
 Monthly: M
 Quarterly: Q
 Yearly: Y

For example, **01-001.Q.01** Primary blower assembly quarterly instruction number 1.

i. Daily Instructions

Primary Chamber Burner: (01-002.D)




Do not store flammable or hazardous materials in the vicinity of fuel burning appliances.

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or death.


Burner shall be installed and maintained in accordance with manufacturer's requirements as outlined in the Burner manual, local codes and authorities having jurisdiction.

INSTRUCTION 01-002.D.01: INSPECTING AND CLEANING ELECTRODES

1. Remove the cover from the Burners as described in 01-002.W.01
2. Inspect the electrodes (PN: 3003796) for any soot build-up.



1. Electrode
2. U-bolt
3. Diffuser Disc




4. HT Leads

3. Clean/wipe down the ignition electrode with a cloth should there be a build-up of soot.

NOTE Do not use sand paper as this will increase the deposit of future soot.

- If electrodes are damaged remove the screws and u-bolt (see above photo) and install new electrodes. When reinstalling the electrodes make sure that they are positioned as shown below.



Primary Burner

Check the High Temperature (HT) Leads (PN: 3012995) for any heat damage. If HT Leads are severely damaged (ie, you can see the wire beneath the sheathing) then replace. (See *CMI 6.3.3/01-002A*)

INSTRUCTION 01/02-002.D.02: INSPECTING THE FUEL LINES

- Visually inspect all fuel lines to the Primary and Secondary Burner for any leaks.
- The Primary Burner have two oil lines, one feed and one return. the Secondary Burner has only a feed line
- If any leaks are observed tighten or replace the fitting where the leak is occurring

INSTRUCTION 01-002.D.03: INSPECT AND CLEAN BURNER NOZZLES

Primary Burner:

- Remove the burner cover as outlined in 01/02-002.W.01 REMOVAL OF BURNER COVERS
- Remove the centre retaining bolt.
- Slide burner out.
- Check nozzle. If there is carbon, remove the nozzle and clean.
- Reinstall or replace if necessary (PN: C5222433)

Refractory: (05-001.D)



When working with the refractory make sure you use the proper tools; wear goggles, approved dust mask and gloves

INSTRUCTION 05-001.D.01: INSPECTING THE REFRACTORY

Ensure power is locked out.

Please follow all instructions outlined in *Section 6.1 Zero Mechanical State & Lock Out Instructions*.

1. Open Primary Chamber door by unlatching all four clamps.
2. Tie-off door to open position to ensure that it will not close unintentionally.
3. Enter Primary Chamber and check the refractory for shrinkage, any gap between the modules greater than 2.5 cm should be patched with the blanket refractory
4. Check for any exposed metal between the modules, if metal is exposed make sure to patch area with blanket material (PN: 1" x 24" 8# 2600) or new module (PN: 6" Mod ZR) (CMI 6.3.2/05-001A & 6.3.2/05-001B)

ii. **Weekly Instructions**

Primary & Secondary Chamber Blowers: (01-001.W & 02-001.W)



Do not attempt any maintenance on a fan unless the electrical supply has been completely disconnected and locked.

Please follow all instructions outlined in *Section 6.1 Zero Mechanical State & Lock Out Instructions*.


A fan can windmill despite removal of all electrical power therefore, take extra care when working with fans in the system.

The rotating assembly should be blocked securely before attempting maintenance of any kind.

INSTRUCTION 01/02-001.W.01: DAMPER CRANK ARM


Check to see that the damper crank arm is connected to the damper and the rod.

Ensure mechanical linkage on damper is tight, if loose tighten with wrench.



PRIMARY BLOWER

1. Air Proving Switch
2. Modutrol Motor
3. Motor Crank Arm
4. Damper Crank Arm
5. Rod
6. Damper



SECONDARY BLOWER

1. Air Proving Switch
2. Modutrol Motor
3. Motor Crank Arm
4. Damper Crank Arm
5. Rod
6. Damper




- A. Damper Crank arm and connection to Damper and Rod

INSTRUCTION 01/02-001.W.02: SLIDE GATES

Check to see if slide gates move freely.


1. Move slide gate in and out to ensure free movement. If sticking, use lubricant to loosen. Lubricant should be rated for a high temperature (>150°F) application.
2. Gates must be opened to allow under fire air to enter the chamber. They should only be closed to reduce air in abnormal operating conditions.



1. Primary Chamber Slide Gate Open



2. Primary Chamber Slide Gate Closed



3. Secondary Chamber Slide gate Open

Primary Chamber Burner: (01-002.W)

 **Do not store flammable or hazardous materials in the vicinity of fuel burning appliances.**

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or death.


Burner shall be installed and maintained in accordance with manufacturer's requirements as outlined in the Burner manual, local codes and authorities having jurisdiction.

INSTRUCTION 01/-002.W.01: REMOVAL OF BURNER COVER

Switch off the electrical power. Please follow all instructions in *Section 6.1 Zero Mechanical State & Lock Out Instructions*. Cover must be removed to perform maintenance on the burner.

To remove the cover and to pull out the Primary or Secondary Burner, follow instructions below:

1. Loosen screw (Item #1, in the following diagrams) and withdraw the cover (Item #2, in the following diagrams)
2. Primary Burner has one screw to remove the cover. The Secondary Burner has four screws to remove the cover.
3. Remove bolt (Item #3) for the Primary Burner, or screws (Item #3) for the Secondary Burner.
4. Pull (Part A) backwards keeping it slightly raised to avoid damaging the diffuser disk (Item #6).



Primary Burner has 1 screw



INSTRUCTION 01/02-002.W.02: CLEANING THE PHOTO ELECTRIC CELL

1. Remove the cover from the Burners as described in Instruction 01-002.W.01.
2. Clean Photo Electric (P.E) cell with a wet cloth (Primary Burner PN: 3006216)
3. P.E. cell (Item #1) can be removed by pulling it outward forcefully. Ensure you take note of the position of the eye while removing, this will help when reinstalling.
4. Once cleaned insert P.E. cell back into position ensuring the eye is not facing directly into the chamber (where the flame will be) but on the same angle as before it was removed.
5. Replace burner cover.

Primary Burner PE Cell

**INSTRUCTION 01-002.W.03: CLEANING THE INSPECTION WINDOWS**


Clean the inspection windows with a wet cloth.



1. Primary Burner Inspection Window

INSTRUCTION 01-002.W.04: INSPECTING THE DIFFUSER DISC ASSEMBLY

1. Remove the cover from the Burners as described in 01-002.W.01.
2. Check the diffuser disc assembly (Primary Burner PN: 3003791) for any heat damage
3. If any heat damage, deformation or excess rust is noted, replace. (*CMI 6.3.8/03-009K*)



1. Electrode
2. U-bolt
3. Diffuser Disc

Secondary Chamber High Output Dual Burner: (02-002.W)

Do not store flammable or hazardous materials in the vicinity of fuel burning appliances.

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or death.

Burner shall be installed and maintained in accordance with manufacturer's requirements as outlined in the Burner manual, local codes and authorities having jurisdiction.


INSTRUCTION 02-002.W.01: SECONDARY BURNER WEEKLY ROUTINE

1. Clean flame sensors.
2. Clean the glass on the flame inspection window.
3. Clean spark ignitors.
4. Clean pilot assemblies.
5. Check spark ignitor lead connections.
6. Check turbulator ring.
7. Clean all filters and filter screens.
8. Lubricate all moving parts (i.e. bearings on doors, door latches & hinges, air and fuel valves, proportioning fuel valves, particularly the shafts on both air modulation valves)

9. Check all motors for bearing noise, loose fans, etc.
10. Inspect fuel lines for leaks

Thermocouple: (05-002.W)

! When working with electrical components ensure lock out instructions are being followed.




Thermocouple Assembly



Thermocouple Element

INSTRUCTION 05-002.W.01: INSPECT THERMOCOUPLE FOR DAMAGE

Turn main power to the system off - Remove thermocouple and visually inspect for damage. If damaged, see *CMI 6.3.1/05-002A*



1. Primary Chamber #1 Thermocouple



2. Two Secondary Thermocouples on Secondary Chamber body and beside the burner



3. Stack Thermocouple on Stack

i. Monthly Instructions

Primary & Secondary Chamber Blowers: (01-001.M & 02-001.M)



Do not attempt any maintenance on a fan unless the electrical supply has been completely disconnected and locked. In many cases, a fan can windmill despite removal of all electrical power. The rotating assembly should be blocked securely before attempting maintenance of any kind.

Please follow all instructions outlined in *Section 6.1 Zero Mechanical State & Lock Out Instructions*.

INSTRUCTION 01/02-001.M.01: CHECK FAN WHEEL



1. Check the fan wheel for any wear or corrosion, as either can cause catastrophic failures, if left in operation.
2. The wheel can be accessed one of two ways.
 - a. Remove the blower assembly from the unit and look down the outlet of the blower.
 - b. Remove the damper assembly from the inlet of the blower and inspect by looking through the inlet of the blower.
3. Check also for the build-up of material which can cause unbalance resulting in vibration, bearing wear and serious safety hazards.
4. Clean the wheel as required.
5. If replacement is necessary follow these steps:
 - a. Remove damper assembly from the unit
 - b. Remove the blower assembly
 - c. Remove the blower housing around the wheel
 - d. Loosen all set screws that are located on the wheel.
 - e. A puller may be required if the wheel hasn't been removed for some time.
 - f. Ensure the shaft "key" is installed on the shaft before installing the new wheel.
 - g. When installing a new wheel, the wheel should be positioned in the housing with the correct spacing between the edge of the inlet cone and the wheel. The wheel to cone clearance on the Primary Blower is 0.3175 cm.
 - h. Ensure that the wheel is installed securely before reassembling the blower assembly.
 - i. Install the blower assembly
 - j. Install the damper assembly

Primary Chamber Burner: (01-002.M)



Do not store flammable or hazardous materials in the vicinity of fuel burning appliances. Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or death. Refer to the Burner manual for instructional or additional information.

INSTRUCTION 01-002.M.01: CHECK FLEXIBLE OIL LINE

1. Check flexible oil lines to make sure that they are still in good condition. This includes frayed, leaking, or worn swivel joints.
2. If any type of damage is observed replace the flexible oil lines see *CMI 6.3.3/01-002F & 6.3.3/02-0002F*



Primary Chamber Burner Flexible lines

INSTRUCTION 01-002.M.02: INSPECT BURNER PUMP DELIVERY PRESSURE

1. Remove the cover from the Burner as described in Instruction 01/02-002.W.01.
2. The pump delivery pressure must be between 180-210 psi, and can be viewed on the gauge shown below.



3. If the pressure is found to be unstable or if the pump is running noisily try the following:
 - a. Detach the flexible hose from the line filter (Shown below as #1).
 - b. At the tank pour fuel into the supply line.
 - c. If there is fuel coming in through the filter it means the filter is not clogged. If no fuel is coming through the filter remove and replace.



Primary Chamber Burner Flexible lines

4. If the pump is found to be responsible:
 - a. Loosen the bleed screw.
 - b. Turn on the burner
 - c. Once all the air has been bled out. Close the bleed screw.

If the pump is still not working after these steps replace the pump.

5. If the problem lies in the suction line, check to make sure that the filter is clean and that air is not entering the piping from a loose fitting or damaged line.

INSTRUCTION 01-002.M.03: CLEAN BURNER OF DUST

1. Remove the cover from the Burners as described in Instruction 01-002.W.01.
2. Check that no dust has accumulated inside the burner fan or on fan blades.
3. If any dust is visible take a clean soft cloth to the fan or the blades and wipe clean.

INSTRUCTION 01-002.M.04: CHECK BURNER COMBUSTION HEAD

1. Remove the cover from the Burners as described in Instruction 01-002.W.01.
2. Check that all parts of the combustion head are in good condition, free of all impurities, and that no deformation has been caused by operation at high temperatures.

(Below is an example of burner in good condition)



If damage is found, please refer to *CMI 6.3.3/01-002D* & *6.3.3/02-002D*

Secondary Chamber High Output Dual Burner: (02-002.M)

Do not store flammable or hazardous materials in the vicinity of fuel burning appliances. Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or death. Refer to the Burner manual for instructional or additional information.

INSTRUCTION 02-002.M.01: SECONDARY BURNER IN-LINE HEATER

1. Check all electrical connections.
2. Remove heater element from casing and inspect for build-up. Clean any deposits. When reinstalling always ensure the bundle will be restarted immersed. **NEVER** use the inline oil heater dry.

INSTRUCTION 02-002.M.02: SECONDARY BURNER SOLENOID VALVES

1. Examine solenoid valves for any deposits. Remove if necessary
2. Check electrical connections.

Refractory: (05-001.M)

When working with the refractory make sure you use the proper tools; wear goggles, dust mask and gloves

Please follow all instructions outlined in *Section 6.1 Zero Mechanical State & Lock Out Instructions*.

INSTRUCTION 05-001.M.01: INSPECT REFRACTORY

1. Ensure power is locked out.
2. Open Secondary Chamber door.
3. Fasten door open, ensuring it will not close by its own weight.
4. Enter Secondary Chamber and check the refractory for shrinkage, any gaps between the modules greater than 2.5 cm should be patched.
5. Fix gaps with supplied blanket by stuffing material into opening. (See *CMI 6.3.2/05-001A*)
6. Check for any exposed metal, if metal is exposed make sure to patch area with blanket material or new module. (See *CMI 6.3.2/05-001A & 6.3.2/05-001B*)
7. Pay special attention to areas where the junction boxes are located, as any excessive heat may melt the wires within the box.
8. From Secondary Chamber interior look up the stack while the cap is in closed position.
9. View the surface of the bottom of the stack cap flap with a flash light
10. Some cracking is normal, however if pieces are missing or have fallen out, (See *CMI 6.3.2/05-001E*)

Lid Lifters: (06-001.M)



Controls are normally closed. Do not modify to by-pass or leave the controls open.

Always remain vigilant and avoid injury.

INSTRUCTION 06-001.M.01: CHECK HYDRAULIC FLUID

Check the level of the hydraulic fluid. Fill if necessary.

1. Always use High temperature hydraulic oil Grade 32 to fill the tank.

ii. Quarterly Instructions

Primary & Secondary Chamber Blowers: (01-001.Q & 02-001.Q)



Do not attempt any maintenance on a fan unless the electrical supply has been completely disconnected and locked. In many cases, a fan can windmill despite removal of all electrical power. The rotating assembly should be blocked securely before attempting maintenance of any kind.

Please follow all instructions outlined in *Section 6.1 Zero Mechanical State & Lock Out Instructions*.

INSTRUCTION 01/02-001.Q.01: LUBRICATE BEARINGS

1. Lubricate the bearings, but do not over lubricate.
2. Bearings are completely filled with grease at the factory; they may run at an elevated temperature during initial operation. Surface temperatures may reach 180°F and grease may bleed from the bearing seals. This is normal and no attempt should be made to replace lost grease. Bearing surface temperatures will decrease when the internal grease quantity reaches a normal operating level.
3. Bearings should be lubricated with premium quality lithium-based grease conforming to NLGI Grade 2. Examples are:

Mobil - Mobilgrease XHP
Texaco - Premium RB
Chevron - Amolith #2
Shell - Alvania #2
4. Add grease to the bearing via the grease nipple while running the fan or rotating the shaft by hand. Be sure all guards are in place if lubrication is performed while the fan is operating. Add just enough grease to cause a slight purging at the seals. Do not over lubricate.




Primary Chamber Burner: (01-002.Q)


 Do not store flammable or hazardous materials in the vicinity of fuel burning appliances. Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or death. Refer to the Burner manual for instructional or additional information.

INSTRUCTION 01-002.Q.01: INSPECT COMPONENTS FOR HEAT DAMAGE

1. Check all components for heat damage.
2. Look for excessive rust, deformation of all the parts including but not limited to the end cone and the diffuser disc.
3. Check to see that the High Temperature Leads (HT leads) are still intact and have not melted from any excessive heat coming back into the burner. If they are damaged replace with new HT Leads (PN: 3012995 Primary). See *CMI 6.3.3/01.002A*.
 - a. The HT leads are attached to the control box and the electrode via a squeeze fitting. Remove the leads from the electrode and control box by simply pulling them out.



1. Electrode
2. U-Bolt
3. Diffuser Disc



4. HT Leads



End cone

Refractory: (05-001.Q)




When working with the refractory make sure you use the proper tools; wear goggles, dust mask and gloves


Please follow all instructions outlined in *Section 6.1 Zero Mechanical State & Lock Out Instructions*.

INSTRUCTION 05-001.Q.01: INSPECT DOOR GASKETS

1. Open Primary and Secondary Chamber doors.
2. Fasten doors open, ensuring the door will not close on its own.
3. Inspect door gasket for damage.
4. Replace any damaged segments of door gasket (PN: GSB 1.5") if necessary. Cut out the damaged section and replace with new door gasket. See *CMI 6.3.2/05-001C*.
5. Doors must close tightly and securely, ensuring a good seal.




Primary Door (refractory lined)



1. Primary Door Gasket



Secondary Door (refractory lined)



1. Secondary Door Gasket

INSTRUCTION 05-001.Q.02: INSPECT REFRACTORY FOR SHRINKAGE

1. Ensure power is locked out.
 2. Open Primary and Secondary Chamber doors.
 3. Fasten doors open, ensuring they will not close on their own.
 4. Enter Primary and Secondary Chamber and check the refractory for shrinkage, anything greater than 2.54 cm should be patched.
 5. Check to make sure the anchoring of the modules is still strong and intact, if any modules seem loose replace complete module with new module.
- A. **REMOVAL:** Remove existing Module (physically pull away existing refractory from underlying Module Anchor).
- B. Remove welded stud from steel casing (cut with hack saw or other device between Module Anchor and Furnace Casing/Shell).




Figure 1: Side view of the Weld Loc Module




Figure 2: Stud Gun with rasp and Torque Tube.

- A. **INSTALLATION:** Once the new module (PN: 433026) is in place take the stud gun (PN: ECO-STUD) with rasp to the Torque Tube and drill into place.
- B. Once it has tightened the Torque Tube should come off with the drill.

Paint: (05-003.Q)



Ensure proper ventilation and proper equipment is being used when using any paint product.

INSTRUCTION 05-003.Q.01: INSPECT AND MAINTAIN EXTERIOR PAINT

1. Maintain paint exterior to protect metal from heat and corrosion damage. This includes all components in the system including containers and incinerator components.
2. If discoloration is noted and painting needs to be performed, on areas where paint will be applied, you must do a light sanding before application.
3. Follow paint manufacturer's application instructions which will include surface preparation, priming and painting.
4. If components within the container need to be painted, for example the Primary Chamber or the Secondary Chamber, proceed as above. Use a type of paint that meets the following specifications:

Paint Specifications:

Incinerator Paint: This is the paint coated directly on the incinerator shell. This includes the following components:

1. Primary Chamber
2. Secondary Chamber
3. Breech Section
4. Hot Stack Section (Black)

Finish needs to be able to withstand temperatures in the 650-750°F (340-400°C) range.


Parts: There are no paint specifications for each individual component. This is left up to the discretion of the customer.

iii. Yearly Instructions**Refractory: (05-001.Y)**

When working with the refractory make sure you use the proper tools; wear goggles, dust mask and gloves

INSTRUCTION 05-001.Y.01:**CHECK DOOR GASKET ALONG PRIMARY & SECONDARY CHAMBER DOORS**

1. If required replace the door gasket. The gasket can last over 2 years but will depend on the careful use by the operator when loading and unloading.
2. Remove the damaged section of door gasket from door and reinstall new gasket (PN: GSB 1.5")



Primary Door (refractory lined)



Primary Door Gasket



Secondary Door (refractory lined)



Secondary Door Gasket

Electrical: (05-004.Y)



When working with electrical components ensure lock out instructions are being followed

Please follow all instructions outlined in *Section 6.1 Zero Mechanical State & Lock Out Instructions*.


INSTRUCTION 05-004.Y.01: CHECK LIMIT SWITCHES

NOTA System must not be running or in cool down to perform this inspection.

1. Open Primary and Secondary Chamber doors and check top view screen on the HMI to ensure that it indicates door is open.
2. Close Primary and Secondary Chamber doors and check top view screen on the HMI to ensure that it indicates door is open.
3. All limit switches located on the unit are checked this way.
4. Replace limit switches (PN: 802T-APE) if necessary.



Primary Chamber Limit Switch



Secondary Chamber Limit Switch

1. See *CMI 6.3.1/05-005A*).
2. Check all other limit switches in the system.
 - a. Limit Switch located at upper limit of lid lifter Primary Chamber
 - b. Limit Switch located at lower limit of lid lifter Primary Chamber

CORRECTIVE MAINTENANCE INSTRUCTIONS (CMI)

The following instructions relate to the replacement or correction (fixing) of components of the EWS Incinerator Package.

These Corrective Instructions are grouped in this section by the following:

- 6.3.1 General Corrective Maintenance Instructions
- 6.3.2 Refractory Corrective Maintenance Instructions
- 6.3.3 Primary & Secondary Burner Corrective Maintenance Instructions
- 6.3.4 Primary & Secondary Blower Corrective Maintenance Instructions
- 6.3.5 Waste Oil Burner Corrective Maintenance Instructions
- 6.3.6 Main Control Panel Corrective Maintenance Instructions

the following table is utilized to identify the components of the system that require corrective maintenance.

System Component	Identification number
Primary Blower	01-001
Air Proving Switch Replacement	6.3.4/01-001A
Damper Calibration	6.3.4/01-001B
Modutrol Resistor Replacement	6.3.4/01-001C
Damper Crank Arm Replacement	6.3.4/01-001D
Motor Replacement	6.3.4/01-001E
Modutrol Motor & Transformer Replacement	6.3.4/01-001F
Secondary Blower	02-001
Air Proving Switch Replacement	6.3.4/02-001A
Damper Calibration	6.3.4/02-001B
Modutrol Resistor Replacement	6.3.4/02-001C
Damper Crank Arm Replacement	6.3.4/02-001D
Motor Replacement	6.3.4/02-001E
Modutrol Motor & Transformer Replacement	6.3.4/02-001F
Primary Burner	01-002
Replacing Fuel Filter	6.3.1/01-002A
HT Lead & Electrode Replacement	6.3.3/01-002A
Diffuser Disc Replacement	6.3.3/01-002B
Nozzle Replacement	6.3.3/01-002C
End Cone Replacement	6.3.3/01-002D
Nozzle Assembly Repair or Replacement	6.3.3/01-002E
Burner Flexible Oil Line Replacement	6.3.3/01-002F
Low Level Switch Replacement	6.3.3/01-002G
Inspection Window Replacement	6.3.3/01-002H
Fuel Pump Replacement	6.3.3/01-002I
Control Box Replacement	6.3.3/01-002J
Oil Tube Replacement	6.3.3/01-002K
Burner PE Cell & UV Detector Replacement	6.3.3/01-002L
Burner Fan Motor Replacement	6.3.3/01-002M

Refractory		05-001	
	Wall Refractory: Gaps between the Modules		6.3.2/05-001A
	Wall Refractory: Replacement of the Modules		6.3.2/05-001B
	Door Gasket		6.3.2/05-001C
	Castable Refractory		6.3.2/05-001D
	Temporary Repair of Castable		6.3.2/05-001E
Main Control Panel		03-010	
	Main Control Panel		6.3.6/03-010A
	Reboot PLC		6.3.6/03-010B
Limit Switch		05-005	
	Limit Switch Replacement		6.3.1/05-005A

iv. General Corrective Maintenance Instructions

LIMIT SWITCH REPLACEMENT (6.3.1/05-005A)

1. Loosen the 2 screws holding the limit switch in place.
2. Remove limit switch, replace with a new one (PN: 802T-APE).
3. Take arm off of old body and mount to new.
4. Tighten the 2 screws holding the limit switch body.

REPLACING THERMOCOUPLE (6.3.1/05-002A)

The thermocouple will require routine replacement. The environment inside the incinerator will erode the protection tube to the point of failure. If the element is exposed to this environment it will be destroyed and will need to be replaced.

1. Unscrew thermocouple lid and remove wires.
2. Remove protection tube. To aid with this a vise and a pipe wrench will be needed.
3. Remove element and replace with new element (PN: TK-K08B-0100-S) and protection tube (PN: TA-A427A-K08B-010).





4. Reinstall on incinerator.
5. After installation turn power back on. Observe the temperature reading of the thermocouple you were just working on. If the wires were installed incorrectly the temperature will read the opposite temperature. (ie 20°C would read as -20°C). If this is the case open the thermocouple housing and switch the wires.

REPLACING FUEL FILTER (6.3.1/01-002A AND 02-002A)

The fuel filter will require routine replacement to ensure clean fuel delivery to the Primary and Secondary Chamber burners.

1. Close the ball valve on the supply line.



2. Unscrew the used filter. Use a bucket to catch the surplus fuel when you unscrew the filter.



3. Before installing the filter lubricate the seal on the new filter.
4. Install the new filter, and open the supply line ball valve.

v. Refractory Corrective Maintenance Instructions



When working with the refractory make sure you use the proper tools; wear goggles, dust mask and gloves



WALL REFRACTORY: GAPS BETWEEN THE MODULES (6.3.2/05-001A)

The ceramic block refractory will shrink over time exposing the exterior metal shell. These gaps need to be filled in with ceramic refractory blanket.

1. Identify gaps in the chamber that are larger than 1" in width between the modules or if you can see exterior shell.
2. With a Utility knife cut a length of ceramic blanket (PN: 1" x 24" 8# 2600) that will fit in the gap between the modules.
3. Stuff the blanket into the space with a straight edge or ruler.

WALL REFRACTORY: REPLACEMENT OF MODULES (6.3.2/05-001B)

Excessive damage to a section of refractory may necessitate the replacement of modules in the incinerator. Such damage is largely due to mechanical wear. The following diagram walks through the removal and installation of new modules.

<p>A. REMOVAL: Remove existing Module (physically pull away existing refractory from underlying Module Anchor)</p> <p>B. Remove welded stud from steel casing (cut with hack saw or other device between Module Anchor and Furnace Casing/Shell)</p>	<p>Figure 1: Side view of the Weld Loc Module</p> 
<p>Figure 2: Stud Gun with rasp and Torque Tube (part of module assembly).</p> 	<p>C. INSTALLATION: Once the new module is in place take the stud gun (PN: Eco-Stud) with rasp to the Torque Tube and drill into place.</p> <p>D. Once it has tightened the Torque Tube should come off with the drill.</p>

DOOR GASKET REFRACTORY (6.3.2/05-001C)

The door gasket will degrade over time and will need to be replaced over time. The bottom of the door will see more degradation due to the waste burning in that vicinity.

1. Identify the damaged section of gasket that will need to be removed
2. With a utility knife cut out the section that needs to be replaced.
3. A new piece of gasket (PN: GSB 1.5") will need to be cut the same length as the removed piece.
4. With contact cement coat the gasket on one side and the door section and install.

CASTABLE REFRACTORY (6.3.2/05-001D)

Operators will notice that the castable refractory will show signs of minor cracking. The minor cracking is normal. Large sections of castable should not separate from the rest of the monolithic cast. Such occurrences are largely due to a sudden impact from machinery or dropping of the units themselves. Mortar (PN: SM3000) is supplied to help with a temporary repair while a permanent repair is resolved. Such permanent repairs are a third level repair and have to be considered on a case by case basis.


TEMPORARY REPAIR OF CASTABLE (6.3.2/05-001E)

1. Find the pieces of castable refractory that have separated.
2. Clean both the pieces of refractory and the area where the separation occurred.
3. Spread an even amount of high temperature mortar on the pieces and the area of separation.
4. Put the pieces back where they originated and support as necessary for a minimum of an hour while the mortar cures.


vi. Burner Corrective Maintenance Instructions


Do not store flammable or hazardous materials in the vicinity of fuel burning appliances.


The Burners are pieces of equipment that will require routine corrective and preventive maintenance. Parts within this assembly will need to be repaired or replaced. The most common parts to be repaired or replaced are located at the front end of the burner where the parts are exposed to high temperatures.



Front End Primary Burner




1. Electrode
2. U-bolt
3. Diffuser Disc



4. HT Leads

HT LEAD & ELECTRODE REPLACEMENT (6.3.3/01-002A)

1. In order to change out the HT leads (PN: 3012995) Primary Burner or Electrode (PN: 3003796) the U-Bolt will have to be removed
2. Remove the electrode by pulling the lead out of the white ceramic tube, replace and re-install.
3. To change the Leads the wire will need to be removed from the burner.
4. Pull the wire out of the burner housing through the rubber grommet.
5. The other end is connected to the back of the control box. Pull the wire straight out and the spring fitting will disengage.
6. Replace the lead with a new one reversing the above directions.
7. When reinstalling the electrodes make sure that they are positioned as shown below:



Primary Burner

DIFFUSER DISC REPLACEMENT (6.3.3/01-002B)

1. Identify the diffuser disc in the above pictures.
2. The disc assembly is secured to the nozzle housing by 2 hex nuts.
3. Remove these nuts and remove the assembly from the burner.
4. The disc is attached to the assembly with 2 screws.
5. Remove the screws and replace the disc.
 - Primary Chamber Burner diffuser disc PN: 3003791
6. Reassemble.

NOZZLE REPLACEMENT (6.3.3/01-002C)

1. Identify the nozzle at the very front end of the burner just behind the diffuser disc.
2. Remove the nozzle with a wrench.
3. Install the new nozzle.
 - Primary Chamber Burner nozzle PN: C5222433

END CONE REPLACEMENT (6.3.3/01-002D)

The end cone will need replacement when the flame becomes unstable from too much heat damage.

1. Loosen and remove the 4 hex bolts that hold the burner on the flange.
2. Remove the burner completely from the incinerator. This will require more than one operator because the burner is heavy.
3. There are two screws that hold the end cone on. Remove and save the screws for the new end cone.
4. Install the new End Cone with the old screws.
 - Primary Chamber burner end cone PN: 3003807
5. Reinstall the burner.

NOZZLE ASSEMBLY REPAIR OR REPLACEMENT (6.3.3/01-002E)

The nozzle assembly is subjected to high heat cycling. The heat cycling will eventually cause the seals and assembly to leak. The assembly will have to be replaced when this occurs. First identify the location of the nozzle assembly.

The parts (seals, nozzle assembly) needed for these replacements are all included under one part number.

- Primary Chamber Burner nozzle assembly: PN: 3003814

Remove all connections to the nozzle assembly and replace with the above parts.

BURNER FLEXIBLE OIL LINE REPLACEMENT (6.3.3/01-002F)

1. Turn the inline ball valve to the closed position to isolate the fuel supply from the burner. This valve is located down line from the burner.
2. Remove flexible lines.
3. Replace with new lines.
 - Primary Chamber Burner flexible oil line: PN: C5281160

4. Open ball valve.



Primary Chamber Burner Flexible lines
(Item # 1 Above)

LEVEL SWITCH REPLACEMENT (6.3.3/01-002G & 02-002G)

The level switch is located in the Fuel Tank.

NOTA

Tanks do not have to be emptied to replace.

1. Unplug the level switch.
2. Disconnect the cord and remove the level switch.
3. Replace level switch (PN: FS301-01) and reconnect the cord.
4. Plug in the level switch.

INSPECTION WINDOW REPLACEMENT (6.3.3/01-002H & 02-002H)

To replace the inspection window simply remove the old inspection window and replace with a new one:

- Primary Burner inspection window PN: 3003763

FUEL PUMP REPLACEMENT (6.3.3/01-002I)

Identify the pump on the burner you wish to replace.

Remove all fuel connections to the pump with the appropriate wrench. Unbolt the pump from the main body of the burner and pull the pump away from the burner to remove.

Reinstall the new pump, and reattach all fuel connections.

- Primary Burner: PN: 3013027

CONTROL BOX REPLACEMENT (6.3.3/01-002J & 02-002J)

Identify the control box on the burner you wish to replace:

Ensuring the power is off unscrew the old control box and install the new one.

- Primary Burner: PN: 3012933

OIL TUBE REPLACEMENT (6.3.3/01-002K)

Oil tubes leak due to heat cycling which causes the fittings to fail or a loose fitting.

1. Identify the oil tubes on the Primary Burner and on the Secondary burner.
2. First try tightening the fittings to see if the leak stops. If the leak does not stop:
3. Remove the old oil tubes with a wrench and install the new ones:

- Primary Burner Tubes: PN: 3003821
PN: 3003822

BURNER PE CELL REPLACEMENT (6.3.3/01-002L)

Primary Burner: If the PE cell has been damaged, then it will need to be replaced. The PE cell while removed needs to be unplugged from the control box. This is accomplished by pulling the connection towards you. With the new PE cell install the control box end first by pushing the connection hard. Reinstall the PE cell in the burner.

BURNER FAN MOTOR REPLACEMENT (6.3.3/01-002M)

Identify the malfunctioning motor in the affected burner:


Unbolt and remove the malfunctioning motor from the housing. Disconnect all electrical connections. Reinstall the new motor exactly how the old motor was installed.

vii. Primary & Secondary Blower Corrective Maintenance Instructions



Do not attempt any maintenance on a fan unless the electrical supply has been completely disconnected and locked. In many cases, a fan can windmill despite removal of all electrical power. The rotating assembly should be blocked securely before attempting maintenance of any kind.


Primary Blower assemblies are not a commonly repaired part on the incinerator. Parts within this assembly will need to be repaired or replaced. They are outlined below.



Primary Blower

1. Air Proving Switch
2. Modutrol Motor
3. Motor Crank Arm
4. Damper Crank Arm
5. Rod
6. Damper

Secondary Blower assemblies are not a commonly repaired part on the incinerator. Parts within this assembly will need to be repaired or replaced. They are outlined below.



Secondary Blower

1. Air Proving Switch
2. Modutrol Motor
3. Motor Crank Arm
4. Damper Crank Arm
5. Rod
6. Damper

*Sample picture of a Secondary Blower and its assembly

AIR PROVING SWITCH REPLACEMENT (6.3.4/01-001A & 02-001A)

1. Ensure all power is locked out.
2. Remove wiring from switch.
3. Remove tubing from switch.
4. Unscrew screws at the two locations and remove switch.
5. Reinstall new switch (PN: SML8221210034) complete with tubing and wiring and then retighten.
6. Turn power back on.

DAMPER CALIBRATION (6.3.4/01-001B & 02-001B)

Sometimes the damper linkage will slip when the connections become loose (Items 3,4,5 in the Secondary Blower photo) In order to ensure that the linkage is correctly calibrated the operator will need to look at the display screen on the control panel while the unit is in operation

1. Read the % Open value on the control panel operator interface (PanelView) for the Primary Blower.
2. During operation the damper is factory preset to be 0% open, or fully closed.
3. Look inside the damper (Item 6) and ensure that the linkage is completely closed.
4. If it is then this maintenance is complete.
5. Should the damper be open even a small percentage the linkages are to be loosened and the damper adjusted to be completely closed, and then retighten.

MODUTROL RESISTOR REPLACEMENT (6.3.4/01-001C & 02-001C)

The Modutrol resistors are located inside the top lid of the Modutrol motor. Remove the lid to the Modutrol motor by unscrewing the top four (4) screws. The connection between the control panel and the Modutrol is made with a small white connector with 3 terminals. Jumpered between these terminals is the resistors.

Remove and replace the resistors one at a time to ensure the correct resistors are replaced. You identify the correct resistor by examining the color band on the center node of the resistor. Replace like resistors.

DAMPER CRANK ARM REPLACEMENT (6.3.4/01-001D & 02-001D)

The crank arm will only need to be replaced if the arm is damaged due to misuse. Identify the damper crank arm (Item #4 in the picture on the previous page).

Identify the location of the linkage on the rod and the damper arm with a marker, so the new crank arm will be in the same spot when reinstalled. Remove the connections to the crank arm and replace with the new one (PN: 26026G) and ensure it is in the same spot as the old one.

MODUTROL MOTOR & TRANSFORMER REPLACEMENT (6.3.4/01-001F & 02-001F)

To replace the Modutrol motor all power needs to be off to the system as you will need to expose electrical connections. Firstly get the new motor and orientate the motor in the same direction as the old motor. Identify where the conduit is connected on the old motor and punch the connector holes for the new motor.

Removal

1. Remove all electrical terminations and remove the transformer.
2. Install the transformer in the new Modutrol motor.
3. Remove all conduit connections on the motor.
4. Remove the damper arm and linkage from the motor.
5. Unbolt the motor from the damper, and ensure all nuts and bolts are kept for the new motor install

Install

1. Bolt the new motor in the same orientation as the old motor.
2. Install the damper arm and linkage to the motor
3. Install all conduit connections

Terminate all electrical connections the same as the old motor.

REPLACE THE BLOWER CONTACTOR 6.3.4/01-001G

1. Turn the Main Disconnect Switch off.
2. Open Panel.
3. Remove the wires from M1.
4. Pull the retaining clip up.
5. Tilt contactor forward and remove.
6. To reinstall tilt new contactor (PN: 100-C09D10) until it clicks back in.
7. Pull the retaining clip back down to lock.
8. Reinstall wires to M1.
9. Close panel.
10. Turn power back on.

viii. Main Control Panel Corrective Maintenance Instructions

MAIN CONTROL PANEL (6.3.6/03-010A)

All control panel diagnostics are to be completed by certified or trained technicians. Electrical drawings / diagrams are provided to aid electricians with any diagnostics.

REBOOT PLC (6.3.6/03-010B)

Turn Main Disconnect to the off position on the front of the Control Panel. Turn the main disconnect back on.

SECTION 7

PARTS LIST



ECO 1.75TN 1PV100L Parts List

General Incinerator Components		Quantity	Part #	Supplier
Primary Door Bearings			F4B-E-200R DGE	Canadian Bearings Ltd.
Secondary Door Bearings		5	F4B-E-104R DGE	Canadian Bearings Ltd.
Stack Bearings		2	P2B-SC-100	Canadian Bearings Ltd.
Toggle Clamps US\$		6	51335A66	McMaster-Carr
View Ports		5	P1030/8	Pegasus
Thermocouple		4	TA-A427A-K08B-010.0	Thermo-Kinetics Company Ltd.
Metal ash bins 2.5 yds with lid		2	JT-2.5-60-188	JT Fabrication Ltd..
Blower Assemblies		Quantity	Part #	Supplier
Primary Chamber Blower		1	B110	Canarm
Secondary Chamber Blower w/flanges		1	B113	Canarm
Modutrol		2	M9184D4009	Yorkland Controls Limited
Air Proving Switch		3	SML 8221210034	Yorkland Controls Limited
Primary Chamber Burner		Quantity	Part #	Supplier
Primary Burner RL 28/2		1	C9511200	Riello
Fuel Tank 4500l		1	6011000	Hassco Industries Inc.
Ktech 37.5" low level switch stainless steel		1	FS301SF-1 28"NC	Ktech Industrial Products Inc.
Diesel filter		1	VF1210	National Energy Equipment Inc.
5 micron pleated paper filter	2	KPP21005B		National Energy Equipment Inc.
High Output Used Oil Burner		Quantity	Part #	Supplier
Special 6514-8-A fireall dual fuel burner complete with refractory tile, standard capacity iron nose	1	6514-8-A/LX/1.0A-X13546		Fives North American Combustion
3/4" Pilot Set	1	4015-0-T		Fives North American Combustion
1/2" std regulator	1	7218-01		Fives North American Combustion
3/8" sensitrol oil valve	1	1813-02-D		Fives North American Combustion
1/2"dia. x 18" AOL; 1/2" mnpt connectors e/e; braided CGA approved and tagged	1	C8777-01/18-CGA		Fives North American Combustion
2" butterfly valve	1	1122-4		Fives North American Combustion
Gauge, 0 - 60" wc and 0 - 35 osi	2	8735-HI		Fives North American Combustion
8" wafer valve	1	1156-9		Fives North American Combustion
Control motor, 310 IN/LBS, 37 second timing,4-20 ma, no feedback signal, 1000 ohm potentiometer, 135 degree travel, 110-120VAC	1	1615-F		Fives North American Combustion
Bracket and Linkage for 1615-A through N, for 1136, 1146, and 1156-9 through -22	1	2-9004-205		Fives North American Combustion
Pressure switch, 12 - 60" wc	1	8757-GAO-A4/4/6		Fives North American Combustion
DIF. PRES. SW 1-20"W.C.AUTO.RST	1	C8757-DG50T-DIF		Fives North American Combustion
1/2" ball valve	4	C1821-01		Fives North American Combustion
1/4" ball valve	5	C1821-03		Fives North American Combustion
Pressure gauge, 2-1/2"; 0-60 psi/400 kPa, dual scale; liquid filled 1/4" bottom; SS case;	2	C8735-M-LF		Fives North American Combustion
1/2" pressure regulator	1	7142-01-25		Fives North American Combustion
1/2" relief valve	1	7177-01-75		Fives North American Combustion



ECO 1.75TN 1PV100L Parts List

Pressure switch #B424B range=0-100 psi	2	C8757-B424B-100 Fives North American Combustion
1/2" oil solenoid valve, NEMA 3R	1	1483-01 Fives North American Combustion
1/2" automatic reset oil shutoff valve 120/1/60	1	1517-01 Fives North American Combustion
1/4" Oil flow meter nickel-plated brass housing Buna o-ring 0.2-0.9 GPM SS orifice and spring vertical flow up	1	8598B-03-0.9-VU Fives North American Combustion
1/2" ratiotrol with gauges	1	7052-01-WG Fives North American Combustion
1/2" expansion chamber	1	C7000-0-HSR Fives North American Combustion
3/4" regulator	2	C1485-01 Fives North American Combustion
Combution Blower -Chicago Blower	1	D53 E4 Canada Blower
Burner control	1	RM7895C1012 Yorkland Controls Limited
1" three way valve	1	4093T25 McMaster-Carr
1/2" three way valve	1	4093T23 McMaster-Carr
Used Oil Pump	1	03HB1131 code10/13 Albany Pump Company Ltd.
Basket suction strainer with 60 mesh	1	SBS-100 Albany Pump Company Ltd.
Ball Valve, 1" NPT, cUL Listed	1	BAVA-100 Albany Pump Company Ltd.
Relief Valve c/w WS spring (30-100 PSI)	1	FVJ-3R-SS Albany Pump Company Ltd.
Pressure gauge, 4" Dial; liquid filled, 100 PSI	1	PG100LF-100 Albany Pump Company Ltd.
Compound Gauge;4" Dial; liquid filled; 30-0-30 PSI	1	CG100LF-30/30 Albany Pump Company Ltd.
Watson McDaniel size 3/4" Series 'B' pressure reducing valve	1	with Viton disc and diaphragm. 1-50 psig Albany Pump Company Ltd.
Waste Oil ciculation heater with controller 600v. 3ph, 4687watts	1	CBLS747E13S Hassco Industries Inc.
Transfer Pump	1	FR450B National Energy Equipment Inc.
Oil Filter	1	VF1210 National Energy Equipment Inc.
5 micron pleated paper filter	2	KPP21005B National Energy Equipment Inc.
Waste oil Tank 5000L	1	CUSTOMTANK Hassco Industries Inc.
Level Switch	1	FS301SF-1 45"NC for 60 dia. tank Ktech Industrial Products Inc.
Mixer	2	NP HGL-3.3 Metex Corporations
Waste oil totes IBC containment	2	H4435 ULINE CANADA CORPORATION
Waste oil totes IBC	2	H-3886 ULINE CANADA CORPORATION
Salt and/or sand box spillage kit	2	S18304 ULINE CANADA CORPORATION
Top Loading Package	Quantity	Part # Supplier
Lid lifter HT 3500 Stoke 72"	1	9-LL-3500-72-BE-575 Canada Hydraulique Equipment Inc.
Lid Lifting Link Assembly	4	ECO5TN2PV-06-XX P.D.S. WELDING LTD
Jaw Only 3/4" - 10 Right Hand Thread 12" max adj	4	3001T23 McMaster-Carr
18-8 Stainless Steel Clevis Pin, 3/4" Dia 2" L	4	92390A521 McMaster-Carr
Opacity Monitor	Quantity	Part # Supplier
Compliance Opacity Monitoring System (EPA PS-1)	1	PN 80-0290 Akrulogic
Includes:		
Transceiver / Reflector		
Stack Mounting Flanges		
Local Control Panel		
1hp Air Purge Assembly		



ECO 1.75TN 1PV100L Parts List

-60C Air Purge Hose (2 pcs @ 20')	1	PN 80-3411 (Upgrade) Akrulogic
Opacity Optic Head Extension Control Cable	1	PN 80-0297 Akrulogic
Scale	Quantity	Part # Supplier
4 x 4 Scale w/ digital indicator, analog output and weather gland	1	Matrix Scale Service Inc.
Electrical	Quantity	Part # Supplier
IEC 60 amp 600 volt rotary disconnect	1	GS2GU3N Graybar
Disconnect operating handle	1	GS2AH420 Graybar
Operating shaft	1	GS2AE81 Graybar
175 amp power distribution block	1	PDB220-3 Graybar
175 amp power distribution block cover	1	CPB162-1 Graybar
Ground lug	1	LAMA2/0-14-QY Graybar
600 volt 30 amp 3 pole class J fuse block	11	JT60030 Graybar
250 volt 30 amp 1 pole class RK1 fuse block	11	H25030-1CR Graybar
600 volt 60 amp class J fuse	3	LPJ-60SP Graybar
600 volt 17 amp class J fuse	3	LPJ-17SP Graybar
600 volt 10 amp class J fuse	3	LPJ-10SP Graybar
600 volt 7 amp class J fuse	8	LPJ-7SP Graybar
600 volt 4 amp class J fuse	9	LPJ-4SP Graybar
250 volt 30 amp class RK1 fuse	1	LPNRK-30SP Graybar
250 volt 10 amp class RK1 fuse	1	LPNRK-10SP Graybar
250 volt 6 amp class RK1 fuse	1	LPNRK-6SP Graybar
250 volt 5 amp class RK1 fuse	2	LPNRK-5SP Graybar
250 volt 2 amp class RK1 fuse	2	LPNRK-2SP Graybar
250 volt 1 amp class RK1 fuse	4	LPNRK-1SP Graybar
12 amp IEC contactor 120 VAC coil	1	LC1D12G7 Graybar
9 amp IEC contactor 120 VAC coil	6	LC1D9F7 Graybar
4 N.O. top mount auxiliary contact	1	LADN40 Graybar
IEC solid state overload relay range 6.4- 32 a	1	LR9D32 Graybar
IEC solid state overload relay range 1.6-8 a	2	LR9D08 Graybar
IEC solid state overload relay range 0.2- 2 a	2	LR9D02 Graybar
16 amp SPDT slim line relay 120 VAC coil	10	RXG15F7 Graybar
Base slim line relay	10	RGZE1S35M Graybar
8 PIN tube based relay 120VAC coil	10	RUMC23F7 Graybar
DPDT 8 PIN tube based relay base	10	RUZC2M Graybar
600 to 120 VAC 3000 VA transformer	1	CE3000JA Graybar
24 VDC 1.3 amp switching power supply	1	PS5R-SC24 SnS
5 port unmanaged ethernet switch US\$99	1	SE-SW5U Automation Direct
Current transducer US\$75.5	1	ACT050-42L-F Automation Direct
10.4" TFT touch panel with Intouch run time	1	TCND1U-10AC-CM2 Wonderware Canada East
600 volt 3 H.P. V.F.D.	1	ACS25-03U-04A1-6 Gerrie
480 volt 8 amp line reactor	1	3PR-004C5H Graybar
0-1" H2O draft transmitter	1	616KD-00 Furneco
Ethernet PLC programing port	1	P-R2-F3R0 Gerrie



ECO 1.75TN 1PV100L Parts List

22mm Green illuminated push button operator	2	ZB5AW333 Graybar
22mm Emergency stop push button operator	1	ZB5AS844 Graybar
22mm 3 position return to center selector switch	1	ZB5AD5 Graybar
22mm Green flush push button operator	2	ZB5AA34 Graybar
22mm Black flush push button operator	2	ZB5AA24 Graybar
22mm Red extended push button operator	2	ZB5AL4 Graybar
Green integrated led module	2	ZBVG3 Graybar
N.O. contact block	5	ZBE101 Graybar
N.C. contact block	3	ZBE102 Graybar
Limit switch	4	802T-AP Gerrie
Limit switch lever	4	802T-W2B Gerrie
18 mm AC inductive proximity switch US\$31	2	VK1-AO-1B Automation Direct
Pt100 RTD for cold junction compensation	1	TFD Omega
Unity CPU cw 1 Enet port and 1 serial port	1	BMXP342020 Graybar Canada Inc.
8 Slot Backplane	1	BMXXBP0800 Graybar Canada Inc.
110Vac Power supply	1	BMXCPS2000 Graybar Canada Inc.
16 point 120 vac input module	2	BMXDAI1604 Graybar Canada Inc.
8 channel analog input module	1	BMXAMI0810 Graybar Canada Inc.
4 channel thermocouple input module	1	BMXART0414 Graybar Canada Inc.
16 point relay output module	1	BMXDRA1605 Graybar Canada Inc.
4 Channel analog output module	1	BMXAMO0410 Graybar Canada Inc.
Connectors for all modules except AMI0810 and ART0814	4	BMXFTB2000 Graybar Canada Inc.
Connector for AMI080	1	BMXFTB2800 Graybar Canada Inc.
Connector	1	BMXFCW301S Graybar Canada Inc.
IEC solid state overload relay range 0.2- 2 a	1	LR9D02 Graybar
1hp VFD ABB	1	ACS250-03U-02A1-6 Gerrie
1hp line reactor	1	REX3PR0002C5H Graybar Canada Inc.
Type K Thermocouple 20AWG	300	K-20S-TT Thermo-Kinetics Company Ltd.

APPENDIX B • SECONDARY INCINERATOR DESIGN REPORT





AGNICO EAGLE

MELIADINE

Meliadine Secondary Incinerator Design Report and Drawings

60-Day Notice to Nunavut Water Board

In Accordance with Water License 2AM-MEL1631
(Part D, Item 1)

Prepared by:

Agnico Eagle Mines Limited – Meliadine Division

Date: July 2023


Document Control

Version	Date (YMD)	Section	Page	Revision
R0	2023-07-31			Incinerator Design Report

Prepared By: Amanda Seguin
E&I Mechanical EIT

Reviewed By: Gary Smordin
Senior Engineer
NAPEG # L1838

Approved By: Gary Smordin
Senior Engineer



August 18, 2023




Table of Contents

List of Appendices	4
1. Introduction	5
1.1 Site Location and Access.....	5
1.2 Existing and Future Site Facilities	5
1.3 Location of the Secondary Incinerator Building	6
Figure 1 Site View – Location of Secondary Meliadine Incinerator	6
Figure 2 Survey View – Location of Secondary Meliadine Incinerator.....	7
2. Design	8
2.1 Overall Waste Management Strategy	8
2.2 Description of Incinerator	8
Figure 3 Ketek – System Schematic.....	9
Figure 4 Ketek – Section View Schematic	10
Primary Chamber	11
Secondary Chamber	11
Burner Controls	11
Chimney Design	12
Diesel Fuel Tank	12
2.3 Ash Removal	12
2.4 Air Quality Monitoring	12
3. Construction Methods and Equipment	13
3.1 Construction Methods and Equipment	13
Quality Control and Assurance	13
3.2 Testing and Inspection.....	13
3.3 Timeline.....	13

List of Appendices

Appendix A: General arrangement survey of area plan view for location of new building

Appendix B: Pile design from BBA

Appendix C: Slab design from BBA

Appendix D: Building plans for structural steel from Honco

Appendix E: Ketek incinerator manufacturer design specifications

Appendix F: Ketek operation and maintenance manual

1. Introduction

1.1 Site Location and Access

Agnico Eagle Mines Limited (Agnico Eagle) is operating the Meliadine gold mine (the Mine) located approximately 25 km North of Rankin Inlet and 80 km Southwest from Chesterfield Inlet in the Kivalliq Region of Nunavut. This site is located on the Western shore of the Hudson Bay and the project site is located on the Peninsula between the East, South and West basins of Meliadine Lake (63°1'23.8" N, 92°13'6.42"W) on Inuit Owned Land. The area is accessible from the All-Weather Access Road (AWAR) linking the Meliadine mine site with Rankin Inlet.

1.2 Existing and Future Site Facilities

The Meliadine mine includes several water management infrastructures, such as water retention dikes, berms, culverts, channels, collection ponds, pumping stations, freshwater intake, and water treatment plants. These infrastructures are required to manage water during pre-production, operation, and interim mine closure. The Nunavut Water Board (NWB) has issued a Type A Water License 2AM-MEL1631 (Water License) to Agnico Eagle for the Meliadine mine, authorizing the use of water and the disposal of waste required by mining and milling and other related associated uses.

This report includes the final design and construction drawings for the secondary incinerator and building, as per the Water License (Part D, Item 1). The secondary incinerator at the Mine is intended to supplement the capacity of the first incinerator already approved under the Water License (Meliadine Incinerator Design Report and Drawings, Agnico Eagle Mines Limited, April 2017).

The location of this secondary incinerator is presented in Figures 1 and 2 below.

1.3 Location of the Secondary Incinerator Building

The location of the secondary incinerator will be in the central North-East side of the Meliadine project and will be constructed 4 meters from the primary incinerator building.

Figure 1 demonstrates the site view location of the primary incinerator area.

Figure 2 represents the survey view of the primary incinerator with respect to the secondary incinerator location.



Figure 1 Site View – Location of Secondary Meliadine Incinerator




Figure 2 Survey View – Location of Secondary Meliadine Incinerator

2. Design

2.1 Overall Waste Management Strategy

At the project site, waste is safely managed from the time it is produced until final disposal as per relevant management plans, namely Landfill and Waste Management Plan, Hazardous Materials Management Plan, and Incineration Management Plan.

All wastes are segregated at the mine site and are predominately landfilled, incinerated, or recycled. Remaining wastes, including hazardous waste, are packaged for shipment to a certified waste management facility for treatment, recycling, and/or disposal.

Incineration is an essential part of waste management at Meliadine mine. The incineration of acceptable solid waste from the accommodation complex, kitchen, lunchrooms, shops, warehouses, and offices diverts waste from directly reporting to the on-site landfill. It has the advantage of eliminating putrescible waste that could potentially attract wildlife to the landfill, thereby reducing possible dangerous interactions between humans and wildlife.

The secondary incinerator will contribute to Meliadine's overall waste management strategy by maintaining continuity of the waste burns when there is maintenance work being conducted on the site's primary incinerator and also by providing additional capacity of waste material that can be burnt, reducing the likelihood of incinerable waste backlog.

2.2 Description of Incinerator

The KETEK CY-100-CA-D incinerator is a dual-chamber system that operates under starved-air conditions.

The incinerator components are presented in Figure 3 and Figure 4 of this document and includes:

- Primary and secondary chambers
- Main control panel
- Diesel fuel tank




Figure 3 Ketek – System Schematic




Figure 4 Ketek – Section View Schematic

Primary Chamber

The primary chamber is the first stage of the incinerator where two (2) Becket 2X WIC-201 770,000 BTU/hr. diesel fired burners are used to increase the temperature of the chamber to ensure that the waste will ignite. To save fuel and reduce pollutants, the burn process becomes self-fueling once the chamber reaches the appropriate temperature. This chamber is insulated and has the appropriate refractory to retain the required heat inside the chamber.

Components of the primary chamber include the auxiliary burners, a thermocouple to regulate the burner temperature, a charging door to load the system, an ash door and the contact switch which turns off the burners when the doors are open.

Secondary Chamber

The primary and secondary chambers are connected by a flame-port.

Combustion air is delivered to the secondary chamber through the flame-port using a blower.

The secondary chamber is the second stage of the incinerator where one (1) Becket WIC-301 1,600,00 BTU/hr. diesel fired burner is used to maintain the high temperature required to keep the waste ignited and maintain turbulence from the delivery of oxygen by the blower which ensures no black smoke is generated from the system.

The components of the secondary chamber include the auxiliary burners which are utilized to initiate the start-up procedure and maintain the minimum required temperatures in the chambers, a ceramic thermocouple to measure the temperature in the chamber, the flame-port plenum to mix the combustible gases and flame-port air, the flame-port blower which is the combustion air supply to the flame-port plenum, the flame-port throttle with controls the airflow and the stack which disperses flue gasses.

Burner Controls

The burner controls include a thermostat, relay protection, the option for limited recycle, limited reset, three (3) status lights, valve-on delay/motor-off delay signals, 15-second lockout time option, interrupted and intermittent duty ignition, technician pump priming mode, disable function and a communication port.

Chimney Design

The stack is refractory-lined and has a diameter of 457mm. The height of the stack is 4.24m with the spark arrestor.

The chimney will abide by the manufacturers installation and preparation instructions and will have a minimum clearance of 2 feet from the highest adjacent building with a minimum 6" flue pipe and an 8"x 8" inside chimney. The chimney flue will be a minimum of 3 feet from the highest point from which it erects from the building and will have an upward pitch toward the chimney of at least 0.25" per foot of length. The incinerator will have adequate space around the burner for ease of service and maintenance.

Diesel Fuel Tank

The diesel fuel tank will be utilized to supply the burners on the incinerator with a 4550L ULC approved diesel fuel storage containment tank manufactured by Granby Industries.

2.3 Ash Removal

The ashes leftover from the burns are left to cool inside the combustion chamber and are manually removed through an 86cm x 70cm ash door. Once cool, the ash is placed inside a large metal container.

The ash disposal process has been defined in the Incineration Management Plan and will follow the same procedure as the first incinerator that was installed at Meliadine.

An ash testing protocol is followed to ensure the ash is suitable for disposal in the landfill and if there is concentration of metals that exceed the Government of Nunavut's Environmental Guideline for Industrial Waste Discharges, the ash will be disposed of according to the Incineration Management Plan.

2.4 Air Quality Monitoring

The incinerator stack will be tested through sampling ports on a yearly basis in accordance with the Canadian Council of Ministers of the Environment (CCME): Canada-Wide Standard for Dioxins and Furans, and Canada-Wide Standards for Mercury Emissions.

3. Construction Methods and Equipment

3.1 Construction Methods and Equipment

Construction of the secondary incinerator facility will be performed on site, by qualified Agnico Eagle employees with the support of the following contractors and specialists:

Company Name	Role
BBA	Civil engineering drawings
Audet & Knight	Ground and civil work
Honco	Building procurement and installation
WSP	MPEI engineering drawings and installation support

The incinerator building will be erected on the existing industrial pad. Therefore, no additional granular fill will be required for this construction and no geochemical analysis of waste rock and fill is to be conducted.

No sedimentation or erosion issues are expected due to the nature of the work. Any required mitigation measures will be put in place as per the Sediment and Erosion Management Plan.

Quality Control and Assurance

A quality control/assurance program is required during construction and will be carried out by qualified Agnico Eagle personnel. It will ensure that the construction is as per the Design report and best management practices.

Periodic visual inspections for compliance with the design will be performed. A record of as-built drawings will be produced.

3.2 Testing and Inspection

Prior to start-up, the incinerator will be tested to ensure all mechanisms are functioning properly and the verification will include all the required trades who will be involved in operating the incinerator. The safety functions and requirements will be verified and tested prior to start-up and fire protection requirements will be verified to ensure all CSA and NFPA codes are respected.

The team will receive official training from Ketek on all operational procedures prior to operating the incinerator.

Inspections and maintenance will be carried out as per the Incineration Management Plan.

3.3 Timeline

The proposed date of construction of the secondary incinerator facility is planned for October 2023 and the tentative date for commissioning the permanent infrastructure is November 2023.

Appendix A: General arrangement survey of area plan view for location of new building



File Name: 65-428-142-230-SK-211025

Appendix B: Pile design from BBA


File Name: 65-428-230-001-01

Appendix C: Slab design from BBA


File Name: 65-428-240-002




SLAB - PLAN VIEW
 1: 50
 CV = 12 kPa
 EQUIPMENT: BROME COMPOSTER 632
 KETEK INCINERATOR



A SECTION
 1: 50



B SECTION
 1: 25



C SECTION
 1: 25

SLAB, E.C.
 NOT PLAN

NOTES GENERAL / GENERAL NOTES

- VOID FORM SHALL BE 100mm THICK DYNAVOID 40342 BY BEAVER PLASTICS OR APPROVED EQUIVALENT

DESIGNS EN REFERENCE / REFERENCE DRAWINGS

NO.	DATE	BY	CHK.
ANCHOR BOLTS LOCATION			

NO.	DATE	BY	CHK.
DESIGNER			
CHECKED BY			
APPROVED BY			

REVISIONS

NO.	DATE	BY	CHK.
1	2021-11-10	THIERRY GEMME	
2	2021-11-10	ELIAS ALHADDAD, C.P.I.	
3	2021-11-10	MARIO GIGNAC, Ing.	

AGNICO EAGLE-MELIADINE DIVISION
 428 - INCINERATOR
 SLAB - CONCRETE
 PLAN VIEW, DETAILS AND SECTION
 SLAB
 INCINERATOR

DATE: 2021-11-10

FOR CONSTRUCTION

BBB

NO.	DATE	BY	CHK.
65	00	1	1

Appendix D: Building plans for structural steel from Honco

File Name: C1470-PLAN-STRU-CON


NOTES FOR THE FOUNDATION DESIGN

1. THE FOUNDATION SHALL BE DESIGNED IN ORDER TO RESIST AND TO TRANSMIT ADEQUATELY TO THE GROUND THE SPECIFIED DESIGN LOADS MENTIONED ABOVE.
2. ANCHOR BOLTS DIMENSIONS HAVE BEEN ESTABLISHED ASSUMING 20 MPa CONCRETE STRENGTH AT 28 DAYS. THE FOUNDATION DESIGNER MUST INFORM HONCO INC. IF LESSER CONCRETE STRENGTH IS EXPECTED.
3. MAXIMUM TOLERANCE ON FOUNDATION ALIGNMENT, LEVEL AND DIMENSIONS, ON DIAGONAL DIMENSIONS OR 90 DEGREE ANGLES AND ON ANCHOR BOLTS LOCATION IS ±2mm.
4. THE FOUNDATIONS SHALL BE DESIGNED BY A LICENSED PROFESSIONAL ENGINEER.
5. THE LOAD FACTORS HAVE NOT BEEN INCLUDED.
6. THE COMPANY HONCO INC. OR THE ENGINEER SIGNATORY OF THE PROJECT IS NOT ASSUMING ANY RESPONSIBILITY AS FAR AS CONCRETE FOUNDATION AND CONSTITUTED COMPONENTS, NOT MANUFACTURED BY HONCO INC., ARE CONCERNED.

LOADS ON CONCRETE FOUNDATIONS

LEGEND :	LOADS	INDEX
W	= UNIFORM LOAD	D = DEAD LOAD
P	= PUNCTUAL LOAD	L = LIVE LOAD
W _l	= MAXIMUM TENSION REACTION	M = WIND LOAD
W _c	= MAXIMUM COMPRESSION REACTION	E = EARTHQUAKE LOAD
V	= SHEAR LOAD AT PANEL BASE	T = TENSION
		C = COMPRESSION


1. LOAD REACTION ON CONCRETE WALLS (kN/m)



WALLS	W _d	W _l	W _m	W _{w1}
A	5.1	16.1	-6.8	±3.4
B	1.6	1.8	-	±3.4
C	5.1	16.1	-6.8	±3.4
D	1.6	1.8	-	±3.4

SERVICE LOADS IN kN/m

2. FRAME OPENING REACTIONS



OPENINGS	WIDTH	P _d	P _l	P _w	P _{w1}
(H1)	3000	2.4	2.7	-	±5.1
(H2)	4000	3.2	3.6	-	±6.8

SERVICE LOADS IN kN

BASE PLATE # 01
PL THICK: 10mm HSS254X102 QTY: 02


BASE PLATE # 02
PL THICK: 10mm HSS254X102 QTY: 02

BASE PLATE # 03
PL THICK: 10mm HSS127x76 QTY: 01

BASE PLATE # 04
PL THICK: 10mm HSS127x76 QTY: 01

NOTE 1: REFERENCE ANCHOR FOR THE POSITIONING OF THE BASE PLATES. SEE THE s/c ANCHOR BOLTS LOCATION ON THE PLAN VIEW BE CAREFUL OF THE DIRECTION OF THE BASE PLATE.

ANCHOR BOLT SCHEDULE		
TYPE	DESCRIPTIONS	LOCATION
A	STEEL A36, 16 # S7-400-3014 OTE : 101	TYPICAL ON FOUNDATION WALL, EXCEPT WHERE INDICATED
B	20M GRADE 400MPa S7-400-15014 OTE : 12	SEE LOCATION ON VIEW PLAN



NO.	REV.	DESCRIPTION	DATE
01	01	FOR CONSTRUCTION	2021-07-14

Architect


Mechanical

Honco STEEL BUILDINGS
1100, Chemin Industriel
Lévis, Qc, Canada
G7A 1B1
Phone: (418) 831-2245 Fax: (418) 831-6302
Web: www.honco.ca





SI
Date: 14-07-2021

A: no de detail
B: no de la feuille ou detail exigé
C: no de la feuille ou detail planif. en série dessinée
cales exprimées en millimètres
ou dimensions en millimètres

Name of Consultant, Vendor or Contractor		
Purchase Order: 0P-1056615	Package No.:	Project No.:
Drawing Vendor No.:	Revision No.:	
SK-NI-21-7554-C1470		
Agnico Eagle Mines Ltd Medicine Project, Nunavut, Canada		
Project Title: INCINERATOR - AREA 428		
Drawing Title: ANCHOR BOLTS LOCATION		
Drawn by:	Checked by:	Approved by:
Date: 2021-07-05	Scale: AS INDICATED	Revision:
Client Drawing No.:	Sheet: S101	











ANCHOR BOLTS LOCATION
SCALE 1:100




CONCRETE WORK BY OTHER

IMPORTANT NOTICE
LOCATION OF THE FLOOR DRAINS AND OF THE DRAINAGE SLOPES TO BE COORDINATED WITH THE OWNER.
(A MINIMUM SLOPE OF 1,5% SHALL BE FORESEEN)

BASE PLATE IDENTIFICATION
B.P. No. ## → BASE PLATE No
TYPE: X.X.X → ANCHORS TYPE AND QUANTITY
ELEV.: XX XXX → TOP OF CONCRETE



Client



NO.	REV.	FOR CONSTRUCTION	2021-07-13
na.	by	description	date

Architect

Mechanical

Honco
STEEL BUILDINGS

1190, Chemin Industriel
Lévis, Qc, Canada
G2A 1B1

Phone: (418) 831-2245 Fax: (418) 831-6302
Mail: honco@honco.ca Website: www.honco.ca

PROFESSIONAL ENGINEER
Q. CHAMBERLAIN
P. ENG. 11250


Date 14-07-2021

SI

A: no de detail
B: no de la feuille ou detail exigé
C: no de la feuille ou detailé
SI: cales indiquées en millimètres
ou dimensions en millimètres

Name of Consultant, Vendor or Contractor		
Purchase Order: OP-1056615	Package No.:	Project No.:
Drawing Vendor No.:	Revision No.:	
SK-NL-21-7654-C1470		
Agnico Eagle Mines Ltd Medicine Project, Nunavut, Canada		
Project Title: INCINERATOR - AREA 428		
Drawing Title: CHEMNEY OPENING AND DETAILS		
Drawn by:	Checked by:	Approved by:
Date: 2021-07-05	Scale: AS INDICATED	Revision:
Client Drawing No.:	Sheet: S105	

105.1-5105-2105-7654-C1470-01-001




CROSS SECTION SCAFFOLDING
SCALE 1:50

NOTES :

- LES ÉCHAFFAUDAGES DEVONT ÊTRE EN ACIER EN CONFORMITÉ AVEC LE TABLEAU 1 DE LA NORME CSA-S269.2 (DERNIÈRE ÉDITION).
/THE STEEL MEMBER SCAFFOLDING MUST BE IN CONFORMITY WITH TABLE 1 OF CSA-S269.2 STANDARD (LAST EDITION).
- LA SURFACE DE ROULEMENT ET LE SUPPORT DES ÉCHAFFAUDAGES DOIVENT ÊTRE SUFFISAMMENT COMPACTÉS (95% DU P.M) AFIN D'ÉVITER TOUT RENVERSEMENT DE L'ÉCHAFFAUDAGE.
/RUNNING SURFACE AND THE SUPPORT OF THE SCAFFOLDINGS MUST BE COMPACTED ADEQUATLY TO AVOID ANY TRUN-OVER OR UNSETTLING OF THE SCAFFOLDING.
- L'ENTREPRENEUR DOIT SE CONFORMER AU CODE DE SÉCURITÉ SUR LES CHANTIERS DE CONSTRUCTION.
/THE CONTRACTOR SHOULD CONFORM TO SECURITY CODE ON THE CONSTRUCTION SITE.
- AJOUTER GARDE CORPS AUX ENDROITS APPROPRIÉS
/GUARD RAIL CONFORM TO CONSTRUCTION SECURITY CODE

PORTÉ /SPAN	LISSE /CARD RAIL
INFÉRIEUR A 2,15M /LOWER THAN TO 7'-0"	38 X 89/2" X 4"
SUPÉRIEUR A 2,15M /SUPERIOR TO 7'-0"	38 X 140/2 X 6"

- LEGENDE /LEGEND**
- ① MADRIER /WOOD BEAM
 - ② PLATE-FORME EN ALUMINIUM 483x3048mm /ALUMINIUM PLATFORM 19'x10'-0"
 - ③ ÉCHAFFAUDAGE /SCAFFOLDING
 - ④ WAGON MOBILE /MOBILE WAGON
 - ⑤ ÉQUERRE D'ÉCHAFFAUDAGE /SCAFFOLDINGS SQUARE BRACKET
 - ⑥ CLOTURE À RESSORT /SECURITY FENCE WITH SPRINGS
 - ⑦ VIS D'AJUSTEMENT AVEC POUTRELLE D'ACIER /ADJUSTMENT SCREW WITH STEEL JOIST
 - ⑧ POUTRELLE DE SUPPORT POUR MONTAGE /BEARING JOIST FOR ASSEMBLY
 - ⑨ CONTREPLAQUE 19mm EPMS /PLYWOOD 3/4"
 - ⑩ BATIMENT HONCO /HONCO BUILDING
 - ⑪ STABILISATEUR /STABILIZER



NO	M.C.	FOR CONSTRUCTION	2021-07-14
no	by	description	date

Architect

Mechanical

Honco
STEEL BUILDINGS
1190, Chemin Industriel
Lévis, Qc, Canada
G7A 1B1
Phone: (418) 831-2245 Fax: (418) 831-6302
Web: honco@honco.ca Website: www.honco.ca

Seal

Date **14-07-2021**

A: no de detail
B: no de la feuille ou détail exigé
C: no de la feuille ou détail sheet no. where detail required

SI
cotes exprimées en millimètres
all dimensions in millimeters

Name of Consultant, Vendor or Contractor

Purchase Order: OP-1056615	Package No.:	Project No.:
Drawing Vendor No.:	SK-NI-21-7654-C1470	Revision No.:

Agnico Eagle Mines Ltd
Medicine Project, Nunavut, Canada

Project Title:
INCINERATOR - AREA 428




Drawing Title:
SCAFFOLDING

Drawn by:	Checked by:	Approved by:
Date: 2021-07-05	Scale: 1:50	Revision:
Client Drawing No.:		Sheet: S108

2108-5092-01000-00171710.dwg

Appendix E: Ketek incinerator manufacturer design specifications

File Name: Ketek Incinerator – CY-100_CA Super Assembly



ONE CY-100-CA WITH SEACAN - Mkd - IA-3500

FOR DETAILS & SECTIONS
REFER TO DWG. IA-3500-1 & IA-3500-2

BILL OF MATERIAL

MARK	TOTAL QTY	UNIT	DESCRIPTION	REMARKS	REVISION	DATE
IA-3500	1	1	CY-100-CA WITH SEACAN			
IA-2	3	3	SEC. CHAMBER SADDLE			142 W
IA-21	1	1	FLAMEPORT	YES		146 G
IA-55	1	1	ASH SCRAPER			119 S
IA-28	2	2	UNISTRUT			1.0
IA-48	4	4	UNISTRUT			2.8
IA-40	4	4	UNISTRUT			2.0
IA-56	2	2	UNISTRUT			1.4
IA-51	3	3	UNISTRUT			2.1
IA-52	1	1	UNISTRUT			1.0
IA-63	1	1	UNISTRUT			0.8
IA-54	2	2	UNISTRUT			2.0
IA-56	1	1	CON. PANEL STAND			72.1
IA-58	1	1	UNISTRUT			2.2
IA-60	1	1	PANEL STAND SUPPORT			1.5
IA-2500	1	1	SKID WITH P. CHAMBER			8548
IA-2501	1	1	STACK C/W S. ARRESTER			853.6
IA-2502	1	1	SEC. CHAMBER			3547
IA-2503	1	1	BLOWER PIPE CON.			199.0
BOUGHT ITEMS						
BIA-100	4	4	TOGGLE CLAMP			0.0
BIA-101	0	0	BEARING			0.0
BIA-102	6	6	RBL. SHAFT COLLAR			0.0
BIA-103	1	1	DIRECT DRIVE BLOWER	30.5		MODEL 4C106
BIA-104	8	8	DOOR CATCH			28.9
BIA-105	8	8	STRIPPER PLATE			9.6
BIA-106	1	1	BUTTERFLY GAS VALVE	5.0		FOR 4" PIPE
SEA-100	2	2	4" ID HALF PIPE	0.0		ORNE END THREADED
SHOP BOLTS, NUTS & WASHERS						
TOTAL QTY	UNIT	DESCRIPTION	LENGTH	MAT. GRADE	REMARKS	
2	2	STEIN HEXCAP BOLT	62.3"	GRADE 5		
48	48	STEIN HEXCAP BOLT	62.3"	GRADE 5		
21	21	STEIN HEXCAP BOLT	62.3"	GRADE 5		
1	1	STEIN HEX NUT		GRADE 5		
48	48	STEIN HEX NUT		GRADE 5		
2	2	STEIN HEX NUT		GRADE 5		
1	1	STEIN FLAT WASHER		GRADE 5		
48	48	STEIN FLAT WASHER		GRADE 5		
2	2	STEIN FLAT WASHER		GRADE 5		
1	1	STEIN LOCK WASHER		GRADE 5		
48	48	STEIN LOCK WASHER		GRADE 5		
2	2	STEIN LOCK WASHER		GRADE 5		
MISC. FASTENERS						
10	10	HOLD DOWN CLIPS W/ SCREW	1.8"	S.S.		FRISKER & LUSGOTT
17	17	SEC. CHANNELS BLDG.	N/A			
TOTAL WEIGHT THIS DRAWING						14451.0

Note: Structural components only



April 10, 2014 April 10th, 2014

As per Permit to Practice No. P 06 501

GENERAL NOTES:

- 1.
- 2.
- 3.
- 4.
- 5.

REV #	DESCRIPTION	DATE
1	ISSUED FOR FABRICATION	MAR-09-13

CLIENT: INCINERATOR CY_100_CA_D

TITLE: CY-100-CA WITH SEACAN

KETEK MANUFACTURING

2020A - 110 AVENUE EDMONTON, AB T5S 1W8
PH: (780) 447-9900 FAX: (780) 447-4912
www.ketekgroup.com

PROJECT: INCINERATOR CY_100_CA_D

DESK: VP, CHK: MHA, Job N°

TITLE: CY-100-CA WITH SEACAN, Dwg N°

UNITS: SCALE, INCH: N.T.S., 1A-3500

Sheet N° 1/3

Appendix F: Ketek operation and maintenance manual

File Name: CY-100-CA-Operation Manual



Results Driven.

KETEK
GROUP

20204-110 Avenue NW
Edmonton, AB, Canada, T5S 1X8
Phone: 1-855-447-5050
Fax: (780) 447-4912
Email: info@ketek.ca
www.ketek.ca

CY-100-CA

MANUAL

**OPERATION &
MAINTENANCE**



1.	Introduction	
2.	Waste incineration and general guidelines for waste management	- 5 -
3.	Roles and responsibilities	
3.1	Waste management in charge/site services	- 6 -
3.2	Incinerator operator	- 6 -
3.3	Maintenance personnel	- 6 -
4.	Principles of waste incineration	
4.1	Combustion	- 7 -
4.2	Why incinerate waste?	- 7 -
4.3	Waste components	- 7 -
4.4	Heating value	- 8 -
4.5	Different expressions for heating value	- 9 -
4.6	Examples of waste characteristics	- 10 -
4.7	Incinerator capacity and load size	- 11 -
5.	System description	
5.1	Overview	- 13 -
5.2	Description of system components	- 15 -
5.3	Primary Chamber	- 16 -
5.4	Secondary Chamber	- 16 -
5.5	Control Panel	- 19 -
6.	Operation and maintenance	
6.1	Safety equipment and protocol	- 22 -
6.2	Routine inspection and maintenance	- 22 -
6.3	Waste batch preparation	- 22 -
6.4	Ash removal	- 22 -
6.5	Pre-operational checks	- 23 -
6.6	Operational procedure	- 23 -
6.7	Waste charging: For batch feeding (recommended) see Figure 11.	- 26 -
6.8	Waste incineration record	- 26 -
6.9	Burn-down and cool-down: see Figure 12	- 27 -
6.10	Maintenance and inspection	- 27 -
6.11	Trouble shooting	- 28 -
6.12	Auxiliary fuel consumption rate	- 30 -
7.	Appendix A: Information sheets and manuals	
7.1	Suggested spare parts list	- 35 -
7.2	Burner WIC 201	
7.3	Burner WIC 301	
7.4	Blower Dayton 4C 108	
7.5	Inspection checklist	
7.6	Wiring diagram	

LIST OF TABLES

Table 1	Organization of Manual	- 4 -
Table 2	Classification and properties of common wastes	- 10 -
Table 3	High heating values (approximate) of common waste components	- 11 -
Table 4	Proximate composition of various materials	- 12 -
Table 5	Components in the Primary Chamber (Figure 6 to Figure 8)	- 16 -
Table 6	Components in the Secondary Chamber (Figure 6 to Figure 8)	- 16 -
Table 7	Components in the Control Panel	- 19 -
Table 8	Recommended inspections	- 27 -
Table 9	Trouble shooting guidelines	- 30 -

LIST OF FIGURES

Figure 1	Schematic diagram of incineration process	- 7 -
Figure 2	The concept of heating value	- 8 -
Figure 3	Different bases for expressing heating value (HV)	- 9 -
Figure 4	Schematic of the incineration system	- 14 -
Figure 5	Overall view showing the sections	- 15 -
Figure 6	Components in the Primary and Secondary Chambers (1)	- 17 -
Figure 7	Components in the Primary and Secondary Chambers (2)	- 18 -
Figure 8	Overview of Control Panel, showing the main sections	- 20 -
Figure 9	Steps in the operation of the incinerator	- 21 -
Figure 10	Operating sequence	- 25 -
Figure 11	Procedure for batch waste charging	- 26 -
Figure 12	Procedure for burn down	- 27 -
Figure 13	Consumption rates of propane and diesel	- 32 -

Thank you for selecting Ketek Group to provide you with a reliable, proven and cost-effective system to manage your waste in an environmentally sound manner. This manual has been prepared to allow you to operate and maintain the system safely and efficiently, ensuring its proper operation and continued use for a long time.

It also contains information on the combustion process. We think a good understanding of the basic principles make a knowledgeable, and hence a better, operator.

Table 1 outlines the contents of this manual. We encourage you to read Chapter 2. Chapters 4 and 5 contain the most important information.

TABLE 1 ORGANIZATION OF MANUAL


Chapter	Title / Description
2	Waste Incineration and General Guidelines for Waste Management
3	Roles and Responsibilities
4	Principles of waste incineration What incineration is, how it is affected by waste properties, including incinerator capacity and the design and operational features of the system.
5	System Description List of photographs of the components of the system and their functions
6	Operation and Maintenance How to operate and maintain the system, including discussion of safety

Incineration of waste is recognized as an effective and environmentally sound disposal method for a wide range of wastes, provided the incinerator is properly operated and maintained. However, waste segregation, recycling and reuse should be considered before waste is sent for incineration. Examine the waste to determine the opportunities that exist for:

- reducing the overall quantity of waste generated
- reusing materials, and
- recycling as much as possible before disposal

Incineration of waste can lead to the emission of pollutants. Polychlorinated dibenzodioxins and polychlorinated dibenzofurans (PCDDF), commonly known as dioxins and furans, can be generated if the incinerator is operated inefficiently and combustion is incomplete. Dioxins and furans are toxic, persistent, and bio-accumulative and therefore must be controlled. Mercury is another high priority potential contaminant released from incinerators. It is toxic and bioaccumulates in the environment. Mercury is not emitted unless the waste items incinerated contain mercury. The best method to control mercury is therefore waste segregation to eliminate mercury from the waste fed into the incinerator.

Waste management and segregation before incineration will help reduce waste and provide cleaner emissions, maintaining an environmentally sound way of disposing waste products.



3.1 Waste management in charge/site services

- Ensure that relevant waste handling training is provided to all waste management personnel at site and only properly trained individuals (Incinerator Operators) operate the incinerator.
- Ensure that the operator follows the requirements of the Incinerator Operational Plan, Equipment Operation Manual and other relevant guidelines.
- Ensure that all checklists and data logs are maintained and the records required by this guidance document are collected.
- Ensure adequate re-training is provided to the operators at regular interval.
- Ensure the safety of all personnel and the site.
- Carry out periodic inspections and record observations in supervision checklist appended in this document.

3.2 Incinerator Operator

- Ensure the safe operation of the incinerator and the associated work and storage area.
- Ensure the operation and maintenance of the incinerator is carried out in accordance with the Equipment Operation Manual.
- Ensure that only appropriate wastes are incinerated, and all inappropriate wastes, including plastics, aerosol cans, metallic containers or cans filled with waste oil, are removed and handled accordingly.
- Document and maintain the required logs and records as appended in the document (pre-operational checklist, operational checklist and waste incineration log).
- Notify the supervisor or waste management in charge of any incinerator upsets, malfunctions or required repairs.
- Wear proper Personal Protective Equipment at all times while working with the incinerator or waste.

3.3 Maintenance Personnel

- Carry out timely Inspections and maintain the records
- Carry out preventive maintenance at scheduled intervals; record and report any unusual observations on the equipment.
- Do not alter the electrical wiring or incinerator components.
- Consult Ketek for any clarifications or guidance related to maintenance of the equipment.
- Fill and record the inspection and maintenance checklist and follow the checklist for weekly, monthly and annual inspection and maintenance
- Make sure to lock out/tag out the unit as per the company's existing procedures if there is a problem.

4.1 Combustion

Combustion, burning, incineration, and thermal oxidation all denote the same process, which is the reaction of a combustible materials with oxygen at temperatures higher than the ignition temperature¹ of that matter. The reaction is exothermic, meaning it generates heat in the form of hot gas.

In the case of waste, it may also contain non-combustible matter which does not react with oxygen. In waste incineration, the non-combustible component ends up as ash and a small portion of it is also present in the hot gas in the form of particulate matter or dust.

Figure 1 shows the process of waste incineration. The oxygen used comes from air, which contains 21% oxygen by volume, and the hot gas is typically referred to as flue gas.

4.2 Why incinerate waste?

The main purpose is to reduce the mass and volume for final disposal. Another important reason, since the waste may contain pathogenic, infectious or toxic materials, is to detoxify it. In remote areas, where wildlife is present, scavenging and spreading of diseases can be prevented by incineration.




FIGURE 1 SCHEMATIC DIAGRAM OF INCINERATION PROCESS

In some cases, incineration is used to recover the energy contained in the waste in the form of electricity, steam, hot fluids or hot air. In other cases, valuable materials can be recovered from the ash, or the ash as a whole can be used for soil amendment or as a construction material.

4.3 Waste components

There are different ways of characterizing waste, depending on the purpose for doing it. Here, it is sufficient to characterize the components as follows: ²

A. WATER is an important component because in incineration it has to be evaporated, which requires a lot of energy.³ That, in turn, lowers the temperature of the flue gas.

B. COMBUSTIBLES are those components that react with oxygen and release heat.⁴ The higher the combustible content in the waste, the more air per kilogram of waste is needed for incineration.

This component can be further classified as:

- (i) **Volatile**, which is released to the gas phase when the combustible matter is heated without the presence of oxygen, and
- (ii) **Fixed carbon** which remains in the solid waste after the volatile has been released. This is often referred to as charcoal.

C. NON-COMBUSTIBLE OR ASH is the component that does not react with oxygen.⁵ As previously mentioned, this forms ash, and some of it is in the flue gas in the form of particulate matter or dust. If the waste has a high ash content, less waste can be incinerated before ash must be removed from the combustion chamber. Note also if the waste contains metals, such as lead and cadmium, these metals will be present in the ash.

4.4 Heating Value

Heating value, calorific value and heat of combustion are synonyms that quantify the heat released by the combustible component in the waste. An understanding of the concept can be gained from the hypothetical processes shown in Figure 2.

A measured mass of dry waste and a sufficient amount of oxygen, at room temperature, are ignited, and the resulting hot flue gas is passed through a heat exchanger, where heat is extracted until the flue gas is brought back to room temperature. Let M be the mass (kg) of the dry waste, and H (MJ) is the heat extracted from the heat exchanger. The heating value of the dry waste is H/M (MJ/kg).




FIGURE 2 THE CONCEPT OF HEATING VALUE

1. Below the ignition temperature, combustion does not take place. Consider, for example, gasoline or wood: it has to be ignited for combustion to take place. That is, the temperature in some portion of the matter must be brought up to the ignition temperature for combustion to start.
2. This is referred to as proximate analysis. Another method is elemental analysis, which produces the elemental composition (C, H, O, N, S, Cl ...) of the waste.
3. It takes ~ 2.3 MJ (2200 BTU or 90 cc of propane or 60 cc of diesel) to evaporate 1 L or 1 kg of water. This is referred to as the latent heat of evaporation.
4. The term "organic" is also used, which is strictly incorrect in that some "inorganic" elements or compounds are combustible, such as carbon, sulphur and carbon monoxide.
5. The terms "ash" and "inorganic" are also used. Note that the latter is inaccurate as explained previously.

4.5 Different Expressions for Heating Value

Two different values are reported in the literature (a) "high" or "gross", and (b) "low" or "net". The former corresponds to the case where the moisture in the flue gas is condensed, and hence the high or gross heating value includes the latent heat of evaporation of the water formed in combustion (see Footnote 3). The latter excludes the latent heat evaporation. The low or net heating value thus represents the maximum available energy that can be recovered from the flue gas without condensation.

To be noted also is the basis on which the heating value is expressed, which can be (a) as fired, (b) dry basis or (c) ash free. The distinction is illustrated in Figure 3. An understanding of the different bases can be gained by noting that heating value is a property of the combustible component in the waste. Water and the non-combustible component simply "dilute" the heating value. In terms of incinerator operation, the relevant basis is "as fired".




FIGURE 3 DIFFERENT BASES FOR EXPRESSING HEATING VALUE (HV)

4.6 Examples of waste characteristics

Proximate compositions and heating values of commonly found wastes are given in **Table 2**.

FIGURE 3 DIFFERENT BASES FOR EXPRESSING HEATING VALUE (HV)

Type*	Description	Componets	Weight %			MJ/kg
			Moist	Comb	Non-C	HHV (A/F)
0	Trash	Paper, cardboard, cartons, wood boxes and combustible floor sweepings from commercial and industrial activities. Up to 10% by weight of plastic bags, coated paper, laminated paper, treated corrugated cardboard, oily rags and plastic or rubber scraps.	10%	85%	5%	19.7
1	Rubbish	Trash + Type 3 (up to 20%)	25%	65%	10%	15
2	Refuse	Rubbish and Garbage	50%	43%	7%	10
3	Garbage	Animal and vegetable waste, restaurants, hotels, markets, institutional, agricultural waste (ie. plant material), vegetation, commercial and club sources	70%	25%	5%	5.8
4	Animal/ Pathological	Carcasses, organs, hospital and laboratory, abattoir, animal pound, veterinary sources	85%	10%	5%	2.3

Notes:

Moist= moisture, Comb= Combustible; Non-C = Non-combustible; HHV = High Heating Value; A/F = As Fired

* In some cases, Roman numerals are used. That is Types 0, I, II, III and IV

4.7 Incinerator Capacity and Load Size

Incinerator capacity is dependent on waste composition. In general, the higher the heating value, the lower is the capacity in terms of kg/h that can be incinerated. This can be explained by noting that waste that has a higher heating value requires more air per unit mass than that required to incinerate a waste with a lower heating value. To put it another way, for the same amount of air, more mass of a waste with a lower heating value can be incinerated.

Another important consideration is the size of the batch loaded to the incinerator. The higher the heating value, the smaller (lighter) the load should be. Otherwise, insufficient amount of the air would generate black smoke.

Unfortunately, waste composition is not always known. Nevertheless, there may be indications of the components present. To assist in getting a qualitative estimate of the heating value of a batch of waste, the heating values of common generic waste components are shown in **Table 3**.

TABLE 3 HIGH HEATING VALUES (APPROXIMATE) OF COMMON WASTE COMPONENTS

Component	MJ/kg A/F *	Component	MJ/kg A/F *
Kerosene, diesel ...	44	Leather	16
Plastics	46	Wax paraffin	44
Rubber, latex	23	Rags (linen, cotton)	17
Wood	18	Animal fats	39
Paper	17	Citrus rinds	4
Agricultural waste	17	Linoleum	25

* A/F: As Fired

Another important waste component is the volatile content in the waste. **Table 4** shows the proximate components of various materials and wastes.

In general, this component is responsible for smoke generation. Therefore, as in the case with heating value, the higher the volatile content, the smaller the load that should be charged to the incinerator.

TABLE 4 PROXIMATE COMPOSITION OF VARIOUS MATERIALS

Material	Volatile	Moisture	FC	Ash	FC/V
	%wt	%wt	%wt	%wt	-
Coal (bituminous)	30	5	45	20	1.5
Peat	65	7	20	8	0.3
Wood	85	6	8	1	0.1
Paper	75	4	11	10	0.15
Sewage sludge	30	5	20	45	0.66
MSW	33	40	7	20	0.21
RDF	60	20	8	12	0.13
PDF	73	1	3	13	0.04
TDF	65	2	30	3	0.46
PE, PP, PS	100	0	0	0	0
Plastic + Colour	98	0	0	2	0
PVC	93	0	7	0	0.08

Notes:

FC = Fixed Carbon
 FCN = Ratio of Fixed Carbon to Volatile
 RDF = Refuse Derived Fuel
 PDF = Paper Derived Fuel

TDF = Tire Derived Fuel
 PE = Polyethylene
 PP = Polypropylene
 PS = Polystyrene
 PVC = Polyvinylchloride

5.1 Overview

Regardless of the model of your incinerator, the main components are similar. **Figure 4** shows a schematic diagram of the incineration system. It consists of a Primary Chamber and a Secondary Chamber, which are connected by a flame-port. Combustion air to the Secondary Chamber is delivered via the flame-port by the flame-port blower. Auxiliary burners are provided for start-up and to maintain the minimum temperatures set in the two chambers.

Thermocouples are used to measure the temperatures in the chambers, the outputs of which are used by on-off Omron controllers, which regulate the operation of the auxiliary burners.

The Secondary Chamber combined with high temperatures maintained by the auxiliary burner, and the turbulence created from the delivery of air (oxygen) by the flame-port air blower, ensures that black smoke is not generated (provided the size of the waste load is not too large).

Waste is charged manually and intermittently via the waste charging door (1), and ash is removed manually and batch-wise after operation. The waste charging door is also used to rake the waste in the primary chamber after several loads have been charged, which is necessary to expose the fixed carbon component in the waste to the oxygen.




FIGURE 4 SCHEMATIC OF THE INCINERATION SYSTEM




FIGURE 5 OVERALL VIEW SHOWING THE SECTIONS

5.3 Primary Chamber Section

TABLE 5 COMPONENTS IN THE PRIMARY CHAMBER SECTION (FIGURE 6 & FIGURE 7)

Code	Component	Description	Function
PC	Primary Chamber	Built in-house. Inside Vol: 2.74 m ³ Refractory + Insulation	Pyrolysis and gasification Combustion of fixed carbon
PC_B	Auxiliary Burner	Becket2 x WIC-201; 770,000 BTU/h (Each); 5.5 USG/h (Each)	Start-up and maintains a minimum temperature
PC_T	Thermocouple	Stainless Steel	Used by PC Temp. Controller to regulate burner
PC_D	Charging Door & Ash Door	Built in-house. Feed Door: 90cm (Height) x 70 cm (Width) Ash Door: 86 cm (Height) x 70 cm (Width)	Load waste and ash removal
PC_S	Contact Switch	Square D ZCKJ1H7 (2)	Turn off PC burner when Feed door/Ash door is opened

5.4 Secondary Chamber Section

TABLE 6 COMPONENTS IN THE SECONDARY CHAMBER SECTION (FIGURE 6 & FIGURE 7)

Code	Component	Description	Function
SC	Secondary Chamber	Built in-house. Inside Vol: 2.87m ³ Refractory Insulation	Complete combustion of gases and soot generated in Primary Chamber
SC_B	Auxiliary Burner	Becket WIC-301; 1,600,000 BTU/h; 13.0 USG/h	Start-up and maintain minimum set temperature
SC_T	Thermocouple	Ceramic	Measure temperature in Secondary Chamber
FP_P	Flame-port Plenum	Turbulent vortex flow built inhouse.	Mixing of combustible gases and flame- port air
FP_B	Flame-port Blower	4C 108 Dayton; 1 HP; 3600 rpm	Combustion air supply to flame-port plenum
FP_T	Flame-port Throttle	Butterfly valve	Controls flame-port airflow
ST	Stack	Refractory+ Insulation, built in-house.	Dispersal of flue gas




FIGURE 6 COMPONENTS IN THE PRIMARY AND SECONDARY CHAMBER SECTIONS (1)




FIGURE 7 COMPONENTS IN THE PRIMARY AND SECONDARY CHAMBER SECTIONS (2)

5.5 Control Panel Section

The components are listed in **Table 7**.

Figure 8 Overview of Control Panel, Showing the Main Sections shows a photograph of the whole control panel, which has been divided into sub-sections marked A, B, C, and D.

TABLE 7 COMPONENTS IN THE CONTROL PANEL SECTION

Code	Label	Function
Sub-Section A: Indicator LEDs (ON-OFF)		
C3, C5	Primary Blower	GREEN PC_BL
C8	Secondary Blower	GREEN SC_BL
C6	Flameport Blower	GREEN FP_B
C2, C4	Primary Burner	RED PC_B
C7	Secondary Burner	RED SC_B
Sub-Section B: Burn Timer		
T1	Burn Timer	Set burn-cycle duration to the specified time. (Start switch restarts timer)
Sub-Section B and C: Main Controller and Controllers for Burners and Blowers		
PB1	Start Switch	Initiate Pre-Purge, Burn, Burn-Down, Cool-Down Automatic Cycles. Emergency Use Only. For Normal Stop, Set Burn Time to 0. Safety Apparatus, Will Turn ON/OFF Primary Chamber Burner When Feed Door is OPEN/CLOSED.
PB2	Energy Stop	
R1	Contact Switch	
Sub-Section D: Omron Temperature Controllers and Indicators		
TC1	Primary Chamber T.C.	Temperature Displays and Control of Minimum Temperatures in Primary and Secondary Chambers by Setting Adjustable Set Points (OMRON E5CN). Primary Burner Enabled When Secondary Trigger Reaches its Specific Temperature Set Point.
TC2	Secondary T.C.	
TC3	Secondary Trigger T.C.	
Sub-Section E: Touchscreen Digital Display		
	Primary Blower Secondary Blower Flameport Blower	Blower symbol - GREEN "OFF" Blower symbol - BLUE "ON"
	Primary Burner Secondary Burner	Burner Symbol - NO FLAME "OFF" Burner Symbol - FLAME SYMBOL "ON"
	Digital Magnetic Guage	Displays pressure of Primary Chamber Should be Negative Pressure between 0 and -0.5 inches
	Feed Door / Ash Door	Displays if door is open or closed.

Notes:

This panel has been configured with Burner Protection which ensures that if the primary and/or secondary chamber is hot, the corresponding burner-blower will run even if the cool-down period has elapsed, or if there has been a power disruption.




FIGURE 8 OVERVIEW OF CONTROL PANEL, SHOWING THE MAIN SECTIONS

The operation of the incinerator can be described by distinct sequential steps as shown in **Figure 9**. There are additional necessary steps which involve safety, routine inspection and waste batch preparation, which will be first described.




FIGURE 9 STEPS IN THE OPERATION OF THE INCINERATOR

6.1 Safety equipment

The following Personal Protective Equipment should be used while operating the incinerator system:

- Long-sleeved shirt and long pants;
- Long-cuffed, puncture resistant gloves;
- CSA approved, Grade 1 safety footwear;
- CSA/ANSI approved safety glasses.

The personal protective equipment related to specific tasks are listed below:

- Ash removal and handling: NIOSH N95 respirator
- Waste charging: (1) heat protective clothing and gloves, and (2) CSA/ANSI approved full face shield.

The hazards that could be encountered arise from the following (not in any order of importance):

- Contact with waste (infectious or toxic components, or sharps);
- Exposure to heat, from contact with hot surface or radiation from the primary combustion chamber when the waste charging door or ash removal door is opened.

Therefore, the general precautionary actions include: Not opening waste batches

- Not touching hot surfaces, and minimum exposure to heat radiation through open doors (charging / ash doors while combustion is taking place).
- Wearing appropriate PPE for charging waste and raking the primary chamber, AND minimizing the time for those tasks.

6.2 Routine inspection and maintenance

- Check fuel lines for leak and check connections Check spark arrestor to ensure no plugging
- During ash removal (see next section):
 - Inspect refractory for large cracks (not expansion cracks)
 - Inspect door gaskets for damages

6.3 Waste batch preparation

The following cautionary notes should be followed:

- **NO** explosives, aerosol cans or containers containing combustible liquids
- Make sure that every batch can go through the waste charging door easily, regardless of its weight.
If others prepare the batches, the operator should tell them about the maximum batch size.
- **DO NOT** open batches and "rearrange" the contents for health/safety reasons.

6.4 Ash removal

Typically, ash from previous operation is left to cool, and ash removal is done prior to current operation.

- Make sure combustion chamber is sufficiently cool (**DO NOT** spray water into the combustion chamber) While removing ash, avoid damaging the burner tip Use non-combustible container
- Minimize dust generation
- Light water spraying on ash in the container is OK to minimize dust generation Ash to be removed daily (after sufficient cool down period)
- Dispose of ash as specified in the guidelines or regulations


6.5 Pre-operational checks

- When diesel or propane is used, check fuel tank to make sure there is enough fuel (see Figure 14 for estimates of fuel consumption, depending on burner size and length of operation). Conduct inspection around incinerator, make sure there is no debris or fire hazards; area should be clean
- Open fuel valve
- Check fuel lines for leaks and check all connections
- Check for any physical damage on incinerator including stack and spark arrestor Inspect thermocouples, feed door/ash door seals, and blower inlets
- Re-check that the combustion chamber is empty Check power connection
- When diesel is used, bleed the diesel lines to the burners if necessary


6.6 Operational Procedure

1. The first step in managing waste is to understand the quantity and composition of the waste that is generated. A waste audit should be completed. (Ketek Group can provide a waste audit, which can provide the following:
 - Determine the quantity of waste from each type of operation
 - Characterize the waste stream to determine what opportunities exist for:
 - Reducing the quantity of waste generated,
 - Reusing materials and recycling as much as possible before considering disposal.
2. Before operation of an incinerator, the area surrounding the incinerator shall be free of any debris and tripping hazards. Maintaining proper housekeeping for the incinerator is important and will reduce safety hazards such as slips, trips and falls.
3. A pre-operational checklist should be completed prior to operation of the incinerator. (Ketek can prepare a pre-operational checklist for you). Make sure all ash is removed from the previous burn. Record the weight of ash on checklist.
4. The operational checklist should be continually filled out with the required information throughout the day and during operation of the incinerator.
5. The incinerator should be loaded to the limited charging capacity (both in terms of waste quantity and the calorific value of waste charge). The incinerator should be charged with the appropriate mix and quantity of waste, the operator should close the door, ensure all interlocks are engaged, and start the burn cycle.

- Turn the timer to 12 hours and press the green "Start" button.




- Proceed with inspecting of the incinerator and make certain that all burner blowers (two burners in Primary Chamber and one in Secondary Chamber) are functioning correctly.
- After five minutes, primary burner motor will shut off and the secondary burner (flame) should be running. You will see the temperature increase on the temperature display "Secondary Chamber T.C."



- The secondary burner heats up to the specified temperature in "Secondary Temperature

Trigger.”

- At this point, primary burners (flame and blowers) and flame port blower will come on and you will see the temperature increasing on the temperature display "Primary Chamber T.C."



- The temperature will keep increasing until it goes up to the set point and after that burners will continually function on/off to maintain the specified temperature set on the incinerator control system.
- After about 2-3 hours into the burning process, open the door and check the status of the waste and rake if necessary. Always rake from the ash door side.

